State of New Mexico	Form C-103 <sup>1</sup> of 9		
Office District I – (575) 393-6161  Energy, Minerals and Natural Resources	Revised July 18, 2013		
1625 N. French Dr., Hobbs, NM 88240	WELL API NO.		
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210 OIL CONSERVATION DIVISION	5. Indicate Type of Lease		
<u>District III</u> – (505) 334-6178 1220 South St. Francis Dr.	STATE X FEE		
1000 Rio Brazos Rd., Aztec, NM 87410 District IV – (505) 476-3460 Santa Fe, NM 87505	6. State Oil & Gas Lease No.		
1220 S. St. Francis Dr., Santa Fe, NM			
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name EAST KEMNITZ		
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			
1. Type of Well: Oil Well X Gas Well Other	8. Well Number 002		
2. Name of Operator Matador Production Company	9. OGRID Number 228937		
3. Address of Operator	10. Pool name or Wildcat		
5400 LBJ Freeway Ste 1500 Dallas, TX 75240	KEMNITZ; CISCO, SOUTH		
4. Well Location			
Unit Letter G: 1980 feet from the NORTH line and			
Section 27 16S Township 34E Range	NMPM County LEA		
11. Elevation (Show whether DR, RKB, RT, GR, etc.	)		
4086 GR			
12. Check Appropriate Box to Indicate Nature of Notice,	Papert or Other Data		
12. Check Appropriate Box to indicate ivalure of ivolice,	Report of Other Data		
	SEQUENT REPORT OF:		
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WOR			
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DR	<del></del>		
PULL OR ALTER CASING   MULTIPLE COMPL   CASING/CEMEN	I JOB		
DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM			
OTHER:	П		
13. Describe proposed or completed operations. (Clearly state all pertinent details, an	d give pertinent dates, including estimated date		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Co	mpletions: Attach wellbore diagram of		
proposed completion or recompletion.  Matador is requesting to plug and abandon the East Kemnitz #002, per the required COA, following	ng the procedure below:		
Notify NMOCD 24 hrs before MIRU.			
Safety mtg, MIRU, check pressures, ND wellhead, NU BOPs & POOH w/ rods and tbg. Set CIBP @ 11,100'. Pressure test casing to 500 psi for 30 minutes. Circulate and displace hole w	/ MI E		
TIH & spot 25 sks Cl H cmt on top of CIBP; WOC & Tag. (Isolate perfs)	IVILI'.		
Spot 100 sks Cl H cmt at 10,200'; WOC & Tag. (Wolfcamp & Est. TOC) Perf @ 8,160' & sgz 60 sks Cl H cmt. WOC & Tag. (Abo)			
Perf @ 6,150' & sqz 60 sks Cl C cmt. WOC & Tag. (Glorietta)			
Perf @ 4,600' & sqz 75 sks Cl C cmt. WOC & Tag. (Intermediate shoe) Perf @ 3,000' & sqz 50 sks Cl C cmt. WOC & Tag. (Yates)	CONTRIONS		
Perf @ 950' & sqz 40 sks Cl C cmt. WOC & Tag. (Est. Int. TOC)	CONDITIONS		
Perf @ 440' & sqz Cl C cmt to surface. (Surface shoe) Cut off wellhead and ensure cmt to surface on all csg strings.	anoven with com-		
Install dry hole marker per NMOCD specifications. *Current and proposed wellbore diagrams attached	APPROVED WITH CONDITIONS		
**Mud laden fluid (MLF) mixed at 25sx/100 bbls water will be spotted between each plug.			
	TO ALMOOD		
	re to NMOCD		
COAS	s attached.		
The last of the desire from the state of the	11. 11. 6		
I hereby certify that the information above is true and complete to the best of my knowledge	e and belief.		
K. #			
SIGNATURE TITLE Regulatory Analy	DATE07/10/23		
Type or print name Brett Jennings E-mail address: Brett.Jennings@mail	adorresources.com PHONE: 972-629-2160		
For State Use Only	adortesources.com 111OIVE. 7/2-027-2100		
0/0.1.			
APPROVED BY:	DATE 7/12/23		

# CONDITIONS FOR PLUGGING AND ABANDONMENT

#### OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
  operations are conducted. A cement evaluation tool is required in order to ensure isolation of
  producing formations, protection of water and correlative rights. A cement bond log or other
  accepted cement evaluation tool is to be provided to the division for evaluation if one has not
  been previously run or if the well did not have cement circulated to surface during the original
  casing cementing job or subsequent cementing jobs. Insure all bradenheads have been
  exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - 1) Glorieta
  - J) Yates.
  - K) Cherry Canyon Eddy County
  - L) Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

# R-111-P Area

#### T 18S - R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

#### T 19S - R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A-F. Sec 27 Unit A,B,C,F,G,H.

#### T 19S - R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

## T 19S - R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

#### T 20S - R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

## T 20S - R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

# T 20S - R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

### T 21S - R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

#### T 21S - R 30E

Sec 1 – Sec 36

# T 21S - R 31E

Sec 1 – Sec 36

# T 22S - R 28E

Sec 36 Unit A,H,I,P.

### T 22S - R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

#### T 22S - R 30E

Sec 1 – Sec 36

#### T 22S - R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

#### T 23S - R 28E

Sec 1 Unit A

## T 23S - R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

### T 23S - R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

### T 23S - R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

#### T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

#### T 24S - R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

#### T 24S - R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

## T 25S - R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

Matador is requesting to plug and abandon the East Kemnitz #002, per the required COA, following the procedure below:


- Notify NMOCD 24 hrs before MIRU.
- Safety mtg, MIRU, check pressures, ND wellhead, NU BOPs & POOH w/ rods and tbg.
- Set CIBP @ 11,100'. Pressure test casing to 500 psi for 30 minutes. Circulate and displace hole w/ MLF.
- TIH & spot 25 sks Cl H cmt on top of CIBP; WOC & Tag. (Isolate perfs)
- Spot 100 sks Cl H cmt at 10,200'; WOC & Tag. (Wolfcamp & Est. TOC)
- Perf @ 8,160' & sqz 60 sks Cl H cmt. WOC & Tag. (Abo)
- Perf @ 6,150' & sqz 60 sks Cl C cmt. WOC & Tag. (Glorietta)
- Perf @ 4,600' & sqz 75 sks Cl C cmt. WOC & Tag. (Intermediate shoe)
- Perf @ 3,000' & sqz 50 sks Cl C cmt. WOC & Tag. (Yates)
- Perf @ 950' & sqz 40 sks Cl C cmt. WOC & Tag. (Est. Int. TOC)
- Perf @ 440' & sqz CI C cmt to surface. (Surface shoe)
- Cut off wellhead and ensure cmt to surface on all csg strings.
- Install dry hole marker per NMOCD specifications.

<sup>\*</sup>Current and proposed wellbore diagrams attached

<sup>\*\*</sup>Mud laden fluid (MLF) mixed at 25sx/100 bbls water will be spotted between each plug.

Received by OCD: 7/10/2023 2:40:09 PM

#### East Kemnitz #002 1980 FNL 1980 FEL Unit G Sec. 27-T16S-R34E Lea County, NM API: 30-025-28415 CURRENT WELLBORE SCHEMATIC



	Casing Information	tion				
	Hole Size	Casing Size	Туре	Weight (lb/ft)	Joints	Depth Set
Surface	17 1/4	13 3/8		48#		390
Intermediate	11	8 5/8		32#, 24#		4,520
Production	7 7/8	5 1/2		17#		13,145
DV Tool	12095'		·			

ype	TOC	Date Run
Cl C	_	
s Class C	Surface	
00 sxs	900	
0 sxs	9500	
)(	O sxs	0 sxs 900

Geologic Markers MD				
Rustler				
Salt	1,640			
Yates	2,908			
7 Rivers				
Queen	3,810			
Penrose				
Grayburg				
San Andres	4,580			
Glorietta	6,085			
Tubb	7,330			
Abo	8,105			
Wolf Camp	10,140			
Cisco	11,060			
Strawn	11,965			
Atoka	12,185			
Middle Morrow				
Lower Morrow				

	Tubing	Rods - Per W	/ellview 3/24/15
Joints	Unknown	Total	447
Diam.	2 3/8	7/8" Ponies	2', 2', 2'
Grade		7/8"	148
Weight		3/4"	296
Packer			
PBTD	11500'		
TAC	Est. 11,000'	F	Pump
SN	Est. 11,136'	2" x 1-	·1/4" x 24'
BP			

	Perforation Information			
Date	Formation	Depth	Squeezed	Cement
	Wolfcamp D	11,167' - 11,221'		
	Atoka	12,614' - 12,640'		

	Plugging Information	
Date	Туре	Depth
	Bridge Plug	11,500

Released to Imaging: 7/12/2023 8:28:32 AM

Page 8 of 9 Received by OCD: 7/10/2023 2:40:09 PM




100 sks Class H Cmt

25 sks Class H Cmt

TOC:

5 1/2 13,145'

9,500'



[	Casing Informat	ion				
	Hole Size	Casing Size	Туре	Weight (lb/ft)	Joints	Depth Set
Surface	17 1/4	13 3/8		48#		390
Intermediate	11	8 5/8		32#, 24#		4,520
Production	7 7/8	5 1/2		17#		13,145
DV Tool	12095'			l .		

	Cementing Record		
	Туре	TOC	Date Run
Surface	450 sxs Class C	Surface	
Intermediate	2200 sxs	900	
Production	700 sxs	9500	
Production	700 SXS	9500	

Geologic Markers MD			
Rustler			
Salt	1,640		
Yates	2,908		
7 Rivers			
Queen	3,810		
Penrose			
Grayburg			
San Andres	4,580		
Glorietta	6,085		
Tubb	7,330		
Abo	8,105		
Wolf Camp	10,140		
Cisco	11,060		
Strawn	11,965		
Atoka	12,185		
Middle Morrow			
Lower Morrow			

10,200': Spot a 100 sk Class H cmt balanced plug (Est. 9,386' / Req. 9,400') (Wolfcamp & Est. TOC)

11,100': Set CIBP @ Spot 25 sks Class H cmt of top of CIBP; Load Casing & Pressure test to 500 psi for 30 minutes

Wolfcamp D Perfs: 11,167' - 11,221'

Set Bridge Plug @ 11,500' DV Tool at 12,095'

Abadoned Atoka Perfs: 12,614' - 12,640'

	Perioration information			
Date	Formation	Depth	Squeezed	Cement
	Wolfcamp D	11,167' - 11,221'		
	Atoka	12,614' - 12,640'		

	Plugging Information	
Date	Туре	Depth
	Bridge Plug	11,500

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 238144

# **CONDITIONS**

Note that the second se			
Operator:	OGRID:		
MATADOR PRODUCTION COMPANY	228937		
One Lincoln Centre	Action Number:		
Dallas, TX 75240	238144		
	Action Type:		
	[C-103] NOI Plug & Abandon (C-103F)		

### CONDITIONS

Created By	Condition	Condition Date
john.harrison	Approved w/ conditions. Adhere to NMOCD COAs attached.	7/12/2023