

Submit Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-005-62660
5. Indicate Type of Lease STATE [X] FEE []
6. State Oil & Gas Lease No. K2114
7. Lease Name or Unit Agreement Name PLAINS ST. "16"
8. Well Number 1
9. OGRID Number 17820
10. Pool name or Wildcat UND. MISSISSIPPI, GAS
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,695 GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)
1. Type of Well: Oil Well [] Gas Well [X] Other []
2. Name of Operator PLAINS RADIO PET. CO.
3. Address of Operator P.O. BOX 11351, MIDLAND, TX 79702
4. Well Location
Unit Letter B : 1,250 feet from the NORTH line and 2,310 feet from the EAST line
Section 16 Township 11S Range 28E NMPM County CHAVEZ
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,695 GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK [] PLUG AND ABANDON [X]
TEMPORARILY ABANDON [] CHANGE PLANS []
PULL OR ALTER CASING [] MULTIPLE COMPL []
DOWNHOLE COMMINGLE []
CLOSED-LOOP SYSTEM []
OTHER: []
SUBSEQUENT REPORT OF:
REMEDIAL WORK [] ALTERING CASING []
COMMENCE DRILLING OPNS. [] P AND A []
CASING/CEMENT JOB []
OTHER: []
Notify OCD 24 hrs. prior to any work done

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

SEE ATTACHED P&A PROCEDURE FOR DETAILS.

Spud Date: [] Rig Release Date: []

SEE ATTACHED COA's MUST BE PLUGGED BY 11/1/24

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rachael Braden TITLE REGULATORY CONSULTANT DATE 11-06-2023

Type or print name RACHAEL BRADEN E-mail address: RBRADEN@HELMSOIL.COM PHONE: (361) 244-1611

For State Use Only

APPROVED BY: [] TITLE Staff Manager DATE 11/8/23
Conditions of Approval (if any):

Plains Radio Pet Co.**Plains State "16" #1**

1,250' FNL & 2,310' FEL Unit: B Sec: 16 Twp 11S, Rng 28E
Chaves County, NM / API: 30-005-62660

Proposed Plug and Abandonment Procedure

1. Hold pre-job safety meeting. Comply with all NMOCD safety and environmental regulations. Test rig anchors prior to moving in rig.
2. Check & record SI casing, tubing and bradenhead pressures.
3. RU blowdown lines from casing & tubing valves and begin blowing down casing & tubing into ½ frac tank. Kill well as necessary w/ 10 ppg BW. Ensure the well is dead or on a vacuum.
4. MIRU WSU and associated P&A equipment.
5. RD BPU horsehead. Unseat pump and POOH w/ rods & pump laying down all equipment on wooden sills. Record accurate count of all rods by size / grade and pump.
6. ND WH, release possible TAC and NU manual BOP. Function test BOP.
7. TOOH with reported 215 jts (6,715') 2-3/8", 4.7#, J-55, 8rd EUE tubing + SN standing back in derrick. SLM 2-3/8" tubing. Report condition of 2-3/8" tubing to office to decide if can utilize 2-3/8" production tubing as WS for P&A operations.
8. PU 5-1/2" CIBP & RIH on 2-3/8" WS hydrotesting to 6,766' (50' above T/perf). **Set CIBP @ 6,766'**.
9. RU PT. Load 5-1/2" casing. Close BOP rams & pressure test CIBP & casing to 500 psi. If the casing does not test, notify the office. **Run CBL to surface**
10. **Plug 1 (CIBP & Miss Formation Perfs)**
Mix and pump 25 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 33 cuft) and spot a balanced plug on top of CIBP @ 6,766'. Calculated TOC @ 6,519'.
PUH w/ tbg to 6,450'.
Rig up pump on tbg and circulate wellbore with 9.5 ppg salt gel (± 155 bbls) w/ returns to ½ frac tank.
WOC & Tag TOC.
PUH w/ tbg to 5,890' laying down balance on wooden sills.
11. **Plug 2 (Wfmp – T/Wfmp @ 5,840')**
Mix and pump 25 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 33 cuft) and spot a balanced plug @ 5,890' (50' below T/ Wfmp). Calculated TOC 5,643'.
PUH w/ tbg to 5,110' laying down balance.

Plains Radio Pet Co.
Plains "16" State #1 – Proposed P&A Procedure
10/19/23 Page No 2

Plug 3 (Abo – T/Abo @ 5,059')

Mix and pump 25 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 33 cuft) and spot a balanced plug @ 5,110' (51' below T/ Abo). Calculated TOC @ 4,863'.
POOH w/ tbg standing back \pm 3,000' 2-3/8" & LD balance.

12. Plug 4 (Yeso & Glorieta – T/Yeso @ 2,835', T-Glorieta @ 2,775')

MIRU E-Line
RIH w/ guns & perf 5-1/2" casing at 2,910' (57' below T/Yeso).
POOH w/ WL.
RIH w/ Pkr on 2-3/8" WS. Set Pkr \pm 100' above sqz perfs.
RU pump and pump into sqz perfs w/ FW to establish rate.
PUH w/ Pkr to \pm 2,550' & set Pkr.
Mix and pump 100 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 132 cuft) and sqz into perfs at 2,910'.
Displace cement w/ BW mud to 2,650'.
SI Tbg & WOC.
RIH and tag TOC no lower than 2,725'.
If tag below 2,725' mix & spot additional cement as required.
POOH w/ 2-3/8" WS & Pkr.

13. Plug 5 (8-5/8" Shoe Plug @ 2,405')

MIRU E-Line
RIH w/ guns & perf 5-1/2" csg @ 2,455' (50' below 8-5/8" shoe).
POOH w/ WL.
RIH w/ Pkr on 2-3/8" WS. Set Pkr \pm 100' above sqz perfs.
RU pump and pump into sqz perfs w/ FW to establish rate.
PUH w/ Pkr to \pm 2,200'.
Mix and pump 75 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 99 cuft) and sqz into perfs at 2,455'.
Displace cement w/ BW mud to 2,305'.
POOH w/ 2-3/8" WS & Pkr.

14. Plug 6 (San Andres – T/San Andres @ 1,495')

MIRU E-Line
RIH w/ guns & perf 5-1/2" casing at 1,545' (50' below T/San Andres).
POOH w/ WL.
RIH w/ Pkr on 2-3/8" WS. Set Pkr \pm 100' above sqz perfs.
RU pump and pump into sqz perfs w/ FW to establish rate.
PUH w/ Pkr to \pm 1,300'.
Mix and pump 75 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 99 cuft) and sqz into perfs at 1,545'.
Displace cement w/ BW mud to 1,400'.
SI Tbg & WOC.
RIH and tag TOC no lower than 1,445'.
If tag below 1,445' mix & spot additional cement as required.
POOH w/ 2-3/8" WS & Pkr.

Plains Radio Pet Co.
Plains "16" State #1 – Proposed P&A Procedure
10/19/23 Page No 3

15. Plug 7 (7 Rivers / Yates / 13-3/8" Surface – T/7 Rivers @ 514', T/Yates @ 342')

MIRU E-Line

RIH w/ guns & perf 5-1/2" casing at 564' (50' below T/7 Rivers).

POOH w/ WL.

Close BOP blind rams and open 8-5/8" x 5-1/2" annulus to ½ frac tank.

RU pump and pump into sqz perfs @ 564' w/ FW to establish rate and circulate out 8-5/8" x 5-1/2" annulus at surface.

Mix and pump 220 sx, 14.8 ppg, Class C Cement (1.32 cuft/sx - 290 cuft) down 5-1/2" casing from surface w/ returns out 8-5/8" x 5-1/2" annulus.

Circulate minimum 10 sx good quality cement to surface out 8-5/8" x 5-1/2" annulus.

SWI w/ 5-1/2 casing filled w/ cement.

Open BOP to confirm cement inside 5-1/2" casing at surface.

If cement falls, top off cement as required.

16. ND BOP and WH valves.

17. RD WSU and associated plugging equipment.

18. Cut off wellhead minimum 36" below GL.

Verify cement to surface on all casings

Install P&A marker to comply with regulations.

Record GPS coordinate for P&A marker & photograph P&A marker in place.

Fill the cellar.

Cut off WSU anchors minimum 36" below GL.

Back drag location.

Remove all trash.

Plains Radio Pet Co.
 Plains "16" State #1 – Proposed P&A Procedure
 10/19/23 Page No 4

Well Name: Plains State "16" #1			
API: 30-005-62660			
Prospect / Field: Wildcat (Mississippian)			
County: Chaves			
State: New Mexico			
Surface Location: 1,250' FNL & 2,350' FEL			
Section: 16			
Survey: Congressional			
Township: 11S			
Range: 28E			
Source Log: Schlumberger CNL / Litho-Density 1/29/1989			
Elevation:	KB: 3,708'		
	GL: 3,695'		
Formation	Depth	Subsea	Hydro-Carbons
Anhydrite	283'	3,425'	na
Yates	342'		na
Seven Rivers	514'	3,194'	na
Queen	977'	2,731'	na
San Andres	1,495'	2,213'	Wet
Glorieta	2,775'	933'	Wet
Yeso	2,853'	855'	Wet
Abo	5,059'	(1,351)'	Wet
Wolfcamp	5,840'	(2,132)'	O&G
Penn	6,536'	(2,828)'	Gas
Mississippian	6,812'	(3,104)'	O&G
Devonian / Silurian	7,135'	(3,427)'	O&G
TD	7,191'	(3,483)'	

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD at 575-626-0830 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Cherry Canyon - Eddy County
 - L) **Potash**---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

R-111-P Area

T 18S – R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

T 19S – R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A- F. Sec 27 Unit A,B,C,F,G,H.

T 19S – R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

T 19S – R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

T 20S – R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

T 20S – R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 20 – 29. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

T 20S – R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

T 21S – R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

T 21S – R 30E

Sec 1 – Sec 36

T 21S – R 31E

Sec 1 – Sec 36

T 22S – R 28E

Sec 36 Unit A,H,I,P.

T 22S – R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

T 22S – R 30E

Sec 1 – Sec 36

T 22S – R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

T 23S – R 28E

Sec 1 Unit A

T 23S – R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

T 23S – R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

T 23S – R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

T 24S – R 30E


Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.


T 24S – R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

T 25S – R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.





District I
 1625 N. French Dr., Hobbs, NM 88240
 Phone:(575) 393-6161 Fax:(575) 393-0720

District II
 811 S. First St., Artesia, NM 88210
 Phone:(575) 748-1283 Fax:(575) 748-9720

District III
 1000 Rio Brazos Rd., Aztec, NM 87410
 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV
 1220 S. St Francis Dr., Santa Fe, NM 87505
 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 278663

CONDITIONS

Operator: PLAINS RADIO PET CO 3317 Andrews Hwy Midland, TX 79703	OGRID: 17820
	Action Number: 278663
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	None	11/8/2023