Submit 3 Copies	State of New Mexico		Form C-103		
to Appropriate	Energy, Minerals, and Natural Resources Department		Revised 1-1-89		
District Office			<u></u>		
DISTRICT I	OIL CONSERVATION DIVISION P.O. Box 2088			WELL API NO. 30-059-20349	
P.O. Box 1980, Hobbs, NM 88240					
DISTRICT II P.O. Drawer DD, Artesia, NM 88210	Santa Fe, New Mexico 87504-2088		5. Indicate Type of Lease STATE X FEE		
<u>DIŞTRICT III</u>			6. State Oil & Gas Lease No.		
1000 Rio Brazos Rd., Aztec, NM 87410					
SUNDRY	Y NOTICES AND REPORTS ON W	FILS			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			1		
DIFFERENT	RESERVOIR, USE "APPLICATION FOR PERMIT	7. Lease Name or Ur	7. Lease Name or Unit Agreement Name		
	FORM C-101) FOR SUCH PROPOSALS.)		_		
1. Type of Well			BRAVO DOME CO2 GAS UNIT		
	SAS OTHER	CO2			
2. Name of Operator			8. Well No.		
Oxy USA Inc			2134-1	132	
3. Address of Operator				9. Pool name or Wildcat	
P.O. Box 303. AMIST	AD. NEW MEXICO 88410		BRAVO DOME (· · · ·	
4. Well Location Unit Letter P : 6	(60) Feet From The South	Line and 660	Feet From The	Eası Line	
	Township 248				
Section 13		_ <u>`</u>	MPM Cinion	County	
	10. Elevation (Show whet 4823	her DF, RKB, RT, GR, etc.)		1	
		=			
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data					
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:					
PERFORM REMEDIAL WORK	PLUG AND ABANDON X	REMEDIAL WORK	Δ1:	TERING CASING	
) =			<u> </u>	يـــــــــــــــــــــــــــــــــــــ	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OF	PNS. PLI	JG AND ABANDONMENT	
PULL OR ALTER CASING	!	CASING TEST AND CEME	NT JOB		
OTHER:		OTHER:			
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.					
MIRUSU, kill well as necessary, NUBOP, run cement retainer on workstring to 2220 feet, establish preliminary pump rate					
through retainer and then set retainer, pump 12 sacks of Premium Plus cement (125% of Cimarron Anhydrite/Tubb annular					
volume), sting out of retainer, spot 5 sacks of cement on top of retainer, displace casing with corrosion inhibited fluid and					
Itest casing to 500 psi, pull workstring to 1882 feet, spot 16 sacks of cement across Glorietta and Yeso formations, pull					
workstring to 30 feet and pump 3 sacks of cement to fill casing, NDBOP, RDMOSU, cut off wellhead, install PXA marker,					
cut off well anchors and clean location.					
Cut on Well and location.					
[{				ļ	
1 /					
1.1				Ì	
				}	
{				}	
				ļ	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.					
SIGNATURE DE SIGNATURE		Team Leader	DATE	5/17/2005	
TYPE OR PRINT NAME Danny J. H	arcpmpt		TELEPHO	NE NO. (505) 374-3010	
(This space for State Use)					
APPROVED BY & NAME 5/23/05					
CONDITIONS OF APPROVAL, IF ANY:					
	r				