

RICE Operating Company

112 West Taylor • Hobbs, New Mexico 88240 Phone: (575) 393-9174 • Fax: (575) 397-1471

CERTIFIED MAIL RETURN RECEIPT NO. 7007 2560 0000 4569 8852

February 20, 2013

Mr. Edward Hansen

New Mexico Energy, Minerals, & Natural Resources Oil Conservation Division, Environmental Bureau 1220 S. St. Francis Drive Santa Fe, New Mexico 87505

FEB 22 2013

Oil Conservation Division 1220 S. St. Francis Drive Santa Fe, NM 87505

RE: Investigation and Characterization Plan (ICP) Rice Operating Company – Vacuum SWD System Vacuum C-36 EOL (1R425-103): Unit C, Sec. 36, T17S, R34E

Mr. Hansen:

ROC is the service provider (agent) for the Vacuum SWD System and has no ownership of any portion of the pipeline, well, or facility. The system is owned by a consortium of oil producers, System Parties, who provide all operating capital on a percentage/usage basis. Environmental projects of this nature require System Party AFE approval prior to work commencing at the site. In general, project funding is not forthcoming until NMOCD approves the work plan. Therefore, your timely review of this submission is greatly appreciated.

For all such environmental projects, ROC will choose the path forward that:

- Protects public health,
- Provides the greatest net environmental benefit,
- Complies with NMOCD Rules, and
- Is supported by good science.

Each site shall generally have three submissions:

- 1. This <u>Investigation and Characterization Plan</u> (ICP) is proposed for gathering data and site characterization and assessment.
- 2. Upon evaluating the data and results from the ICP, a recommended remedy will be submitted in a <u>Corrective Action Plan</u> (CAP), if warranted.

3. Finally, after implementing the remedy, a <u>Termination Request</u> with final documentation will be submitted.

Background and Previous Work

The site is located approximately 0.8 miles southwest of Buckeye, New Mexico in Unit C, Section 36, T17S, R34E as shown on the Site Location Map (Figure 1). NM OSE records indicate that groundwater will likely be encountered at a depth of approximately 107 +/- feet.

In 2010, ROC initiated work on the former Vacuum C-36 EOL junction box. A backhoe was used to collect soil samples at regular intervals, creating a 5x3x4-ft deep excavation. The backhoe was unable to excavate the site deeper than 4 ft below ground surface (bgs) due to extremely compacted subsoil material. The excavated soil was properly disposed of at a NMOCD approved facility, and imported soil was used to backfill the excavation to ground surface. On October 11, 2010, the site was seeded with a blend of native vegetation. To further investigate depth of chloride presence, a soil bore was initiated on July 25, 2011, at the source of the former junction box. Soil samples were field tested for chloride and organic vapors were measured using a PID to a depth of 12 ft bgs. Laboratory analysis of the 12 ft sample resulted in a chloride concentration of 1,880 mg/kg and a gasoline range organics (GRO) and diesel range organics (DRO) concentration below detectable limits. The bore hole was plugged with bentonite to the ground surface.

NMOCD was notified of potential groundwater impact on April 10, 2012, and a junction box disclosure report (Appendix A) was submitted to NMOCD with all the 2011 junction box closures and disclosures.

ROC proposes additional investigative work at the site to determine if there is potential for groundwater degradation from residual chlorides and hydrocarbons at the site.

Proposed Work Elements

- 1. Conduct vertical and lateral delineation of residual soil chlorides and hydrocarbons from samples taken using a drill rig, hand auger, and/or backhoe (see Appendix B for Quality Procedures).
 - a. Vertical sampling will be conducted until the following criteria are met in the field.
 - i. Three samples in which the chloride concentration decreases and the third sample has a chloride concentration of ≤ 250 ppm; and,
 - ii. Three samples in which PID readings decrease and the third sample has a PID reading of ≤ 100 ppm; or,
 - iii. The sampling reaches the capillary fringe.
 - b. Lateral sampling will be conducted until the following criteria are met in the field.

- i. A decrease is observed in chloride concentrations between lateral bores at similar depths; and,
- ii. A chloride concentration of ≤ 250 ppm is observed in a lateral surface sample; or,
- iii. Safety concerns impede further lateral delineation.
- 2. If warranted, install a monitor well to provide direct measurement of the potential groundwater impact at the site. Additional monitoring wells may be required to fully delineate groundwater quality. (All monitor wells will be installed by EPA, NMOCD, and industry standards.)
- 3. Evaluate the risk of groundwater impact based on the information obtained.

If the evaluation of the site shows no threat to groundwater from residual chlorides, then only a vadose zone remedy will be undertaken. However, if groundwater shows impact from residual chlorides, a CAP will be developed to address these concerns.

ROC appreciates the opportunity to work with you on this project. Please call me at (575) 393-9174 if you have any questions or wish to discuss the site.

Sincerely, Rice Operating Company

Hack Conder Environmental Manager

enclosures



Figures

· · ·

RICE Operating Company (ROC) 112 West Taylor Hobbs, NM 88240 Phone 575.393.9174 Fax 575.397.1471



Appendix A Junction Box Disclosure Report

RICE Operating Company (ROC) 112 West Taylor Hobbs, NM 88240 Phone 575.393.9174 Fax 575.397.1471

RICE OPERATING COMPANY JUNCTION BOX DISCLOSURE* REPORT

					BOX LOCA	TION						
	SWD SYSTEM JUNCTION UNIT S				TOWNSHIP	RANGE	BOX D	IMENSIONS	- FEET			
		C-36 EOL	С	36	17S	245		Length	Width	Depth		
1	Vacuum	0-30 EUL	C	30	1/5	34E	Lea		Eliminated			
	LAND TYPE:	BLM	STATE X	FEE LAI	FEE LANDOWNEROTHER							
	Depth to Grou	ndwater	107	feet	NM	IOCD SITE .	ASSESSMENT	RANKING S	CORE:	10		
	Date Started 10/7/2010			Date Co	Date Completed 7/25/2011 OCD Witness					No		
	Soil Excavated	2.2	cubic yar	ds Ex	cavation Le	ength	5 Widtl	h <u>3</u>	Depth	feet		
•	Soil Disposed	5	cubic yar	ds O	offsite Facility	Sundance	Services, Inc.	_ Location	Eunic	ce, NM		
FINA		CAL RESI	JLTS:	Samp	ole Date	7/25/20)11	Sample De	pth	12'		

Procure 5-point composite sample of bottom and 4-point composite sample of sidewalls. TPH and Chloride laboratory test results completed by using an approved lab and testing procedures pursuant to NMOCD guidelines.

					CHLORI	DE FIELD TE	STS
Sample Location	PID (field) ppm	GRO mg/kg	DRO mg/kg	Chloride mg/kg	LOCATION	DEPTH	mg/kg
Source @ 12'	0.9	<10.0	<10.0	1,880	background	6"	59
						1'	121
General Description of I	Remedial Actio	n: This jund	ction was eliminated	d during the		2'	266
Vacuum SWD system aband	donment program.	An investigation	was conducted at	the former	· · · · · · · · · · · · · · · · · · ·	3'	296
junction box site using a bac	khoe to collect so	I samples at regu	lar intervals produc	cing a		4'	1,282
5x3x4-ft deep excavation. T	he site could not t	e excavated any	deeper due to extr	emely		5'	1,181
compacted subsoil materials	. Chloride field te	sts performed on	each sample yield	ed elevated		6'	1,244
concentrations that did not re	elent with depth.	Drganic vapors w	ere measured usin	g a PID which	- SB-1 at source -	7'	677
yielded relatively low concen	trations. A total o	f 5 yards of soil w	as hauled to a NM	OCD approved	-	8'	1,795
disposal facility. The excava	tion was backfille	d with imported so	oil to ground surfac	e. On		9'	1,253
10/11/2010, the site was see	eded with a blend	of native vegetati	on and is expected	to return to a		10'	947
productive capacity at a norm	nal rate. To furthe		11'	1,016			
initiated on 7/25/2011. The	boring was advan	ced to a total dep	th of 12-ft. below g	round surface		12'	1,651
with soil samples collected a	t regular intervals.	Chloride field te	sts were performed	on each	- (

sample and organic vapors were measured using a PID. The 12-ft. sample was taken to a commercial laboratory for analysis of chloride and

TPH, which yielded low TPH and chloride concentration that did not decrease with depth. The bore was plugged with bentonite to ground surface.

NMOCD was notified of potential groundwater impact on 4/10/2012.

ADDITIONAL EVALUATION IS MEDIUM PRIORITY

		enclosures: photos, soil bore log, lab re	esults, PID (field) screenings, chloride curve, revegetation form
I HEREBY CERTIFY	THAT THE INFORM	ATION ABOVE IS TRUE AND COMPLETE TO	D THE BEST OF MY KNOWLEDGE AND BELIEF.
) .
SITE SUPERVISOR	Kyle Norman	SIGNATURE WALLAND	
5112 301 ERVISOR	Nyie Norman		
REPORT			\wedge
ASSEMBLED BY	Amy C. Ruth	SIGNATURE North Start	COMPANY RICE OPERATING COMPANY
PROJECT LEADER	Zach Conder	SIGNATURE	DATE 17-12

*This site is a *DISCLOSURE." It will be placed on a prioritized list of similar sites for further consideration.

Vacuum C-36 EOL

Unit C, Section 36, T17S, R34E



Excavating/sampling source, facing west 10.7.10



Seeding site, facing west

10.11.10



Sampling drill cuttings, facing south

7.25.11



Spreading imported soil, facing south

10.11.10



Raking seed, facing west

10.11.10



Plugging the soil bore in total with bentonite, facing south 7.25.11

	Iethod: e: ents: Locate	All sam DRAF 12 ft	per, Inc. y 11 ource of ples wer	f the former junction box site. re from cuttings. L. Weinheimer GW = 107 ft	Pro Lo La	Project Name: Well ID Vacuum C-36 EOL SE Project Consultant: Junction box Location: UL/C sec. 36 T17S R34 Lat: 32°47'47.352"N Coun Long: 103°31'0.226"W State				
Depth (feet)	Chloride field test		PID	Description		Lithology	Well Co	onstruction		
1 ft	121		1.2	Regolith						
2 ft	266		1.7		-					
3 ft 4 ft	296		3.8	Light Brown Fine Sand with some Caliche						
5 ft	1181		5.9							
6 ft	1244		5.4	Light Tan Fine Sand with some Caliche				bentonite		
7 ft 8 ft	677		2.7					seal		
	1795		1.8							

Depth (feet)	Chloride field tests	LAB	PID	Description	Lithology	Well Construction
9 ft	1253		3.8			
10 ft	947		2.8			
11 ft	1016		1.8	Light Brown Fine Sand with some Caliche		
12 ft	1651	CI- 1880 GRO <10	0.9			
		DRO <10				



PHONE (575) 393-2326 ° 101 E. MARLAND ° HOBBS, NM 88240

July 28, 2011

Hack Conder Rice Operating Company 112 W. Taylor Hobbs, NM 88240

RE: VACUUM C-36 EOL (17/34)

Enclosed are the results of analyses for samples received by the laboratory on 07/25/11 15:50.

Cardinal Laboratories is accredited through Texas NELAP for:

Method SW-846 8021Benzene, Toluene, Ethyl Benzene, and Total XylenesMethod SW-846 8260Benzene, Toluene, Ethyl Benzene, and Total XylenesMethod TX 1005Total Petroleum Hydorcarbons

Certificate number T104704398-08-TX. Accreditation applies to solid and chemical materials and non-potable water matrices.

Cardinal Laboratories is accreditated through the State of Colorado Department of Public Health and Environment for:

Method EPA 552.2	Haloacetic Acids (HAA-5)
Method EPA 524.2	Total Trihalomethanes (TTHM)
Method EPA 524.4	Regulated VOCs (V2, V3)

Accreditation applies to public drinking water matrices.

This report meets NELAP requirements and is made up of a cover page, analytical results, and a copy of the original chain-of-custody. If you have any questions concerning this report, please feel free to contact me.

Sincerely,

Celey D. Keine

Celey D. Keene Lab Director/Quality Manager



CARDINAL Laboratories

1

PHONE (575) 393-2326 ° 101 E. MARLAND ° HOBBS, NM 88240

· (.

Analytical Results For:

Rice Operating Company Hack Conder 112 W. Taylor Hobbs NM, 88240 Fax To: (575) 397-1471

Received:	07/25/2011	Sampling Date:	07/25/2011
Reported:	07/28/2011	Sampling Type:	Soil
Project Name:	VACUUM C-36 EOL (17/34)	Sampling Condition:	Cool & Intact
Project Number:	NONE GIVEN	Sample Received By:	Jodi Henson
Project Location:	NOT GIVEN		

Sample ID: INITIAL @ 12' (H101544-01)

Chloride, SM4500CI-B	_ mg,	/kg	Analyze	d By: HM					
Analyte	Result	Reporting Limit	Analyzed	Method Blank	BS	% Recovery	True Value QC	RPD	Qualifier
Chloride	1880	16.0	07/26/2011	ND	400	100	400	3.92	
TPH 8015M	mg,	/kg	Analyze	d By: ab					
Analyte	Result	Reporting Limit	Analyzed	Method Blank	BS	% Recovery	True Value QC	RPD	Qualifier
GRO C6-C10	<10.0	10.0	07/26/2011	ND	184	91.8	200	3.23	
DRO >C10-C28	<10.0	10.0	07/26/2011	ND	167	83.4	200	3.62	
Surrogate: 1-Chlorooctane	115	% 70-130)						
Surrogate: 1-Chlorooctadecane	118	% 70-130	•						

Cardinal Laboratories

*=Accredited Analyte

PLEASE NOTE: Liability and Damages. Cardinal's liability and cherk's exclusive remedy for any claim arising, whether based in contract or tort, shall be limited to the amount paid by client for analyses. All claims, including those for negligence and any other cause whatever that he deemed waved urders made in writing and received by Cardinal writin blinky (30) days after completion of the applicable service. In no event shall Cardinal be liable for incidental or consequential damages, including, without limitation, business interruptions, loss of use, or loss of profits incurred by client, its absolidates, affiaites or successors arising out of or related to the performance of the services hereunder by Cardinal, repardees of whether such claims is based upon any of the above started resorms or otherwise. Revise relates only other above started resorms or otherwise.

Celey D. Keine

Celey D. Keene, Lab Director/Quality Manager



PHONE (575) 393-2326 ° 101 E. MARLAND ° HOBBS, NM 88240

()

Notes and Definitions

ND	Analyte NOT DETECTED at or above the reporting limit
RPD	Relative Percent Difference
**	Samples not received at proper temperature of 6°C or below.
***	Insufficient time to reach temperature.
-	Chloride by SM4500CI-B does not require samples be received at or below 6°C
	Samples reported on an as received basis (wet) unless otherwise noted on report

C



Cardinal Laboratories

*=Accredited Analyte

PLEASE NOTE: Liability and Damages. Cardinal's llability and client's exc paid by client for analyses. All claims, including those for neglic ence and any other cause whatsoever shall be deemed waived unless made in writing and received by Cardinal writin thary (30) days after completion including, without limitation, business interruptions, loss of use, or loss of profits incurred by client, its subsidiaries, affliates or successors arisin claim is bated upon any of the above stated reasons or otherwise. Results relate only to the samples identified above. This report shall not be reproduced except in full with In no event shall Cardinal be liable đ zi or conseque ial damages, arising out of or related to the perform Cardinal, regardless of whether such the services heraunder bγ of of Contined La

Celuz D. Kune

Celey D. Keene, Lab Director/Quality Manager

ARDINAL LABORATORIES

Delivered By: (Circle One)

Sampler - UPS - Bus - Other:

CHAIN-OF-CUSTODY AND ANALYSIS REQUEST

Zconder@rice-ecs.com; Bbaker@rice-ecs.com;

hconder@rice-ecs.com; Lweinheimer@rice-ecs.com

101 East Marland, Hobbs, NM 88240 2111 Beechwood, Abilene, TX 79603

(505) 393-2326 FAX (505) 393-2476 (325) 673-7001 FAX (325)673-7020

Company Name: Rice					ANALYSIS REQUEST																
Project Manage	er: Hack Conder				-	.0. #:					T	1					·	1			
Address:					Company:]				S									
City:	State: NM	Zij	<u>p:</u>		AI	ttn:								6		Į					
Phone #:	Fax #:				A	ddres	5:						i i								
Project #:	Project Owne	er:				itý:															
Project Name:					St	tate:		Zip:		ĕ	5		<u>a</u>	5							
Project Locatio	n: 1/acum 6-36 EOL.				Pł	hone #	<i>‡</i> :		•	Chlorides	8015	BTEX	Texas TPH	ati	TDS						
Sampler Name:	: Kyle Norman				F₽	ax #:				읃	17		x X	Ü							
FOR LAB USE ONLY	· · · · · · · · · · · · · · · · · · ·			MATRIX		PRES	SERV	SAMPL	ING	10	TPH		e	te (
	1	MO	0	<u>شا</u> ر	ĺ				ł				-	e e			•				
Lab I.D.	Sample I.D.	C (G)RAB OR (C)OMP	# CONTAINERS	GROUNDWATER WASTEWATER SOIL OIL SLUDGE	i	ы. К	5							Complete Cations/Anions						ĺ	
		ABO	ALN	NUE NO	i m	Vel C	3 8		ļ					Ŭ			·				
H101544		(G)R	00	GROUND WASTEW SOIL OIL SLUDGE	OTH	ACID/BASE	OTHER:	DATE	TIME												
-1	Initial @ 12'	G	1		Γ			7-25-11	10:15	1	V										
					; ≓																
		_			<u> </u>				l		l		\square	2							
			·										$\left(- \right)$	4	\mathcal{T}						
					_				,				9	16	44	\mathcal{L}	Ð	>			
			· '		Ļ	i			i		<u>-</u>			\sim			17				
	· · · · · · · · · · · · · · · · · · ·	-	·		 	╢─┼╴	+-1			i							-4-				
		-	·		<u> </u>	 															
					\mathbf{t}																
	a Ind Demages, Caroinal's bebility and client's exclusive remody for ing there for negligence and any other cause wheleoever shall be														لمستنسب	المنبسيسين ال			i		<u></u>
service. In no event shall C	and in the second s	ng withou	ut ämlte	tilon, business Interruptions, I	loss e	stuse, or li	oss of pro	of the incurred by a	clorit, its subsidisi	rics											
Relinquished By	V: Date: 7-25-1		_	ved By:		*****			Phone Res	suit:	C Ye				Phone #	4 :					
K & NL	Time: 50	-//	α	the the	Ņ	Q.C.	n		Fax Result REMARKS		LI Ye	<u>s 121</u>	NO	Add'l F	·ax #:				*****		
Rolinguished By		8	ceiv	ved By:					email	resu	lts	٠									
-	Time:								kjones	@ri	cesv	vd.co	om								

CHECKED BY:

† Cardinal cannot accept verbal changes. Please fax written changes to 505-393-2476

Sample Condition Cool Intact I Yes Yes No No No .

RICE ENVIRONMENTAL CONSULTING & SAFETY

 $\left(\begin{array}{c} \\ \end{array} \right)$

122 West Taylor Hobbs, NM 88240 PHONE: (505) 393-9174 FAX: (505) 397-1471 PID METER CALIBRATION & FIELD REPORT FORM



MODEL: PGM 7300	SERIAL NO: 590-000508
MODEL: PGM 7300	SERIAL NO: 590-000504
MODEL: PGM 7320	SERIAL NO: 592-903318
MODEL: PGM 7300	SERIAL NO: 590-000183

1.

GAS COMPOSITION: ISOBUTYLENE 100PPM / AIR: BALANCE

LOT NO : 930360	EXPIRATION DATE: 5/24/2013	
	METER READING ACCURACY: 99.9 PPM	

ACCURACY : +/- 2%

	CO	MPANY		· .			
Rice							
SITE	UNIT	SECTION	TOWN SHIP	RANGE			

	UNII	SECTION	TO MALA DITTE	INANGE
Vacuum C-36 EOL	С	36	17	34

SAMPLE ID	PID	SAMPLE ID	PID
Soil Bore @ 1'	1.2	······································	
2'	1.7		
3'	3.8		
4'	10		
5'	5.9		
6'	5.4		
7'	2.7		
8'	1.8		
9'	3.8	9	
10'	2.8		
. 11'	1.8	······································	
12'	,0.9	······································	

I verify that I have calibrated the above instrument in accordance to the manufacture operation manual.

SIGNATURE: Kisle N_____

DATE: 7/25/2011

I

CHLORIDE CONCENTRATION CURVE

Vacuum C-36 EOL

Unit 'C', Sec. 36, T17S, R34E

Soil bore samples at the source

1

7

8



Groundwater = 107 ft



(___)

PO Box 5630 Hobbs, NM 88241 Phone: (575) 393-4411 Fax: (575) 393-0293

REVEGETATION FORM

1. General Inform	ation	NEVEO:		I UNIVI		
Site name		6 EOL 17.34				······
U/L	Section	Township	Range	County	Latitude	Longitude
C	36	175	34E	Lea	32° 47.791'	103° 31.003'
Contact Name:	Bruce Bak					
Email:	bbaker@rice					
	,539	square feet	Map	detail of site atta	ched 🗌	
Additional information	1:					
2. Soils *	De wet sin enlister		unale hununlaan dh	· · · · · · · · · · · · · · · · · · ·		
Salvaged from site	Bioremediate		rocks brought to the	Blended	Depth (in):	
Texture:	Describe soil			d with subsoil ca		
		Depth(in):		epth (in):	Rollerpack	
	11/2010	epui(iii).		epur (m).	Konerpack	
	11/2010					
<u></u>				<u> </u>		
3. Bioremediation						
Fertilizer			Hay 🗌		Other 🗌	
Гуре:					Describe:	
	a and the second second states and					
.bs/acre:						
4. Seeding *	Attach soud has tak	re to this form Sa	ed bag tags shall co	ntain the site nam	a and STP	
Custom seed mix \boxtimes	Prescribed mix			os. blue grama		e: 10/11/2010
			ix nume. 1.5 h	, once granna	became date	0. 10/11/2010
Broadcast 🛛	"1					
Method: Hand broa	dcast					
Soil conditions during	seeding: Dry	Damp	Wet 🗌			
Photos attached	Observatio	ons:			,	
Number of photos:						
					to the best of my know	
Name: Robert	Egans	11	tle: Environmenta	1 Tech	Date: 10/11/20	10
Signature:	ut &					
					^	
	e					
					all	
				~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		
				$\bigcirc$		
					▼,	
				$\gamma \gg \gamma$		
				$\bigtriangledown$		
				$\sim$		
					,	

1997년 - 1994년 1997년 - 1 1997년 - 1997년 -

## Appendix B Quality Procedures

RICE Operating Company (ROC) 112 West Taylor Hobbs, NM 88240 Phone 575.393.9174 Fax 575.397.1471

### **Quality Procedures**

**Table of Contents** 

- QP-1 Soil Samples for Transportation to a Laboratory
- QP-2 Chloride Titration Using 0.282 Normal Silver Nitrate Solution
- QP-3 Development of Cased Water-Monitoring Wells
- QP-4 Sampling of Cased Water-Monitoring Well
- QP-5 Composite Sampling of Excavation Sidewalls and Bottoms for TPH and Chloride Analysis
- QP-6 Sampling and Testing Protocol for VOC in soil
- QP-7 Composite Sampling of Excavation Sidewalls and Bottoms for BTEX
- QP-8 Procedure for Plugging and Abandonment of Cased Water-Monitoring wells

## Quality Procedure Soil Samples for Transportation to a Laboratory

#### 1.0 Purpose

This procedure outlines the methods to be employed when obtaining soil samples to be taken to a laboratory for analysis.

#### 2.0 Scope

This procedure is to be used when collecting soil samples intended for ultimate transfer to a testing laboratory.

#### 3.0 Preliminary

- 3.1 Obtain sterile sampling containers from the testing laboratory designated to conduct analyses of the soil.
- 3.2 If collecting TPH, BTEX, RCRA 8 metals, cation /anions or O&G, the sample jar may be a clear 4 oz. container with Teflon lid. If collecting PAH's, use an amber 4 oz. container.

#### 4.0 Chain of Custody

- 4.1 Prepare a Sample Plan. The plan will list the number, location and designation of each planned sample and the individual tests to be performed on the sample. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label.) Affix the labels to the jars.

#### **5.0 Sampling Procedure**

- 5.1 Do not touch the soil with your bare hands. Use new nitrile gloves to help minimize any contamination.
- 5.2 Go to the sampling point with the sample container. If not analyzing for ions or metals, use a trowel to obtain the soil.

- 5.3 Pack the soil tightly into the container leaving the top slightly domed. Screw the lid down tightly. Enter the time of collection onto the sample collection jar label.
- 5.4 Place the sample directly on ice for transport to the laboratory if required.
- 5.5 Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

#### 6.0 Documentation

6.1 The testing laboratory shall provide the following minimum information:

- a. Project and sample name.
- b. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
- c. Results of the requested analyses
- d. Test Methods employed
- e. Quality Control methods and results

## QUALITY PROCEDURE Chloride Titration Using 0.282 Normal Silver Nitrate Solution

#### 1.0 Purpose

This procedure is to be used to determine the concentration of chloride in soil.

#### 2.0 Scope

This procedure is to be used as the standard field measurement for soil chloride concentrations.

#### **3.0 Sample Collection and Preparation**

- 3.1 Collect at least 80 grams of soil from the sample collection point. Take care to insure that the sample is representative of the general background to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample for soils obtained at several points in the sample area. Take care to insure that no loose vegetation, rocks or liquids are included in the sample(s).
- 3.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag. Care should be taken to insure that no cross-contamination occurs between the soil sample and the collection tools or sample processing equipment.
- 3.3 The sealed sample bag should be massaged to break up any clods.

#### **4.0 Sample Preparation**

- 4.1 Tare a clean glass vial having a minimum 40 ml capacity. Add at least 10 grams of the soil sample and record the weight.
- 4.2 Add at least 20 grams of reverse osmosis water to the soil sample and shake well.
- 4.3 Allow the sample to set for a period of 5 minutes or until the separation of soil and water.

#### **5.0 Titration Procedure**

- 5.1 Using a graduated pipette, remove 10 ml extract and dispense into a clean plastic cup.
- 5.2 Add 2-3 drops potassium chromate ( $K_2CrO_4$ ) to mixture if necessary.

- 5.3 Using a 1 ml pipette, carefully add .282 normal silver nitrate (one drop at a time) to the sample while constantly agitating it. Stop adding silver nitrate when the solution begins to change from yellow to red. Be consistent with endpoint recognition.
- 5.4 Record the ml of silver nitrate used.

#### 6.0 Calculation

To obtain the chloride concentration, insert measured data into the following formula:

<u>.282 X 35,450 X ml AgNO3</u>	Х	grams of water in mixture
ml water extract		grams of soil in mixture

Using Step 5.0, determine the chloride concentration of the RO water used to mix with the soil sample. Record this concentration and subtract it from the formula results to find the net chloride in the soil sample.

Record all results on the delineation form.

### Quality Procedure Development of Cased Water-Monitoring Wells

#### 1.0 Purpose

This procedure outlines the methods to be employed to develop cased monitoring wells.

#### 2.0 Scope

This procedure shall be used for developed, cased water monitoring wells. It is not to be used for standing water samples such as ponds or streams.

#### **3.0 Sample Collection and Preparation**

- 3.1 Prior to development, the static water level and height of the water column within the well casing will be measured with the use of an electric D.C. probe.
- 3.2 All measurements will be recorded within a field log notebook.
- 3.3 All equipment used to measure the static water level will be decontaminated after each use by means of Liquinox, a phosphate free laboratory detergent, and water to reduce the possibility of crosscontamination. The volume of water in each well casing will be calculated.

#### 4.0 Purging

- 4.1 Wells will be purged by using a 2" decontaminated submersible pump or dedicated one liter Teflon bailer. Wells should be purged until the pH and conductivity are stabilized and the turbidity has been reduced to the greatest extent possible.
- 4.2 If a submersible is used the pump will be decontaminated prior to use by scrubbing the outside surface of tubing and wiring with a Liquinox water mixture, pumping a Liquinox-water mixture through the pump, and a final flush with fresh water.

#### 5.0 Water Disposal

5.1 All purge and decontamination water will be temporarily stored within a portable tank to be later disposed of in an appropriate manner.

#### 6.0 Records

6.1 Rice Environmental Consulting and Safety will record the amount of water removed from the well during development procedures. The purge volume will be reported to the appropriate regulatory authority when filing the closure report.

t

### Quality Procedure Sampling of Cased Water-Monitoring Well

#### 1.0 Purpose

This procedure outlines the methods to be employed in obtaining water samples from cased monitoring wells.

#### 2.0 Scope

This procedure shall be used for developed, cased water monitoring wells. It is not to be used for standing water samples such as ponds or streams.

#### **3.0 Preliminary**

- 3.1 Obtain sterile sampling containers from the testing laboratory designated to conduct analyses of the water.
- 3.2 The following table shall be used to select the appropriate sampling container, preservative method and holding times for the various elements and compounds to be analyzed.

Compound to be Analyzed	Sample Container Size	Sample Container Description	Cap Requirements	Preservative	Maximum Hold Time
BTEX	40 ml	VOA Container	Teflon Lined	HCL	14 days
TPH (8015 Extended)	40 ounces	(2) 40ml VOA vials	Teflon Lined	HCL and Ice	14 days
PAH	1 liter	amber glass	Teflon Lined	lce	7 days
Cation/Anion	1 liter	HD polyethylene	Any Plastic	None	48 Hrs
Metals	1 liter	HD polyethylene	Any Plastic	lce/HNO ₃	28 Days
TDS	300 ml	clear glass or 250 ml HD polyethylene	Any Plastic	Ice	7 Days
Cl-	500 ml	HD polyethylene	Any Plastic	None	28 Days

#### 4.0 Chain of Custody

- 4.1 Prepare a Sample Plan. The plan will list the well identification and the individual tests to be performed at that location. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label). Affix the labels to the jars.

#### **5.0 Bailing Procedure**

- 5.1 Identify the well from the sites schematics. Place pre-labeled jar(s) next to the well. Remove the plastic cap from the well bore by first lifting the metal lever and then unscrewing the entire assembly.
- 5.2 Using a dedicated one liter Teflon bailer or submersible pump, purge a minimum of three well volumes. Place the water in storage container for transport to a ROC disposal facility.
- 5.3 If using a bailer, take care to insure that the bailing device and string does not become cross-contaminated. A clean pair of nitrile gloves should be used when handling either the retrieval string or bailer. The retrieval string should not be allowed to come into contact with the ground.

#### **6.0 Sampling Procedure**

- 6.1 Once the well has been bailed in accordance with 5.2 of this procedure, a sample may be decanted into the appropriate sample collection jar directly from the bailer or submersible pump.
- 6.2 Note the time of collection on the sample jar with a fine Sharpie.
- 6.3 Place the sample directly on ice for transport to the laboratory. The preceding table shows the maximum hold times between collection and testing for the various analyses.

6.4 Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

#### 7.0 Documentation

- 7.1 The testing laboratory shall provide the following minimum information:
  - A. Project and sample name.
  - B. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
  - C. Results of the requested analyses
  - D. Test Methods employed
  - E. Quality Control methods and results

#### Calculation for Determining the Minimum Bailing Volume for Monitor Wells Formula V= $(\pi r^2 h)$ 2" well [V/231=gal] X 3 = Purge Volume

V=Volume π=pi r=inside radius of the well bore h=maximum height of well bore in water table

Example:

π	r ²	h(in)	V(cu.in)	V(gal)	X 3 Volumes	Actual
3.1416	1	180	565.488	2.448	7.34 gal	>10 gal

## Quality Procedure Composite Sampling of Excavation Sidewalls and Bottoms For TPH and Chloride Analysis

#### **1.0 Purpose**

This procedure outlines the methods to be employed when obtaining final composite soil samples for TPH and Chloride analysis.

#### 2.0 Scope

This procedure is to be used in conjunction with *Quality Procedure – 02:* Soil Samples for Transportation to a Laboratory and will be inserted at subparagraph 5.2 of Section 5.0: Sampling Procedure.

#### **3.0 Sampling Procedure**

Follow *Quality Procedure – 02: Soil Samples for Transportation to a Laboratory* for all Sections and subparagraphs until subparagraph 5.2 of Section 5.0: Sampling Procedure. Instead of 5.2 instructions, perform the composite sample collection procedure as follows:

- 3.1 Go to the excavation with a new plastic baggie. If not analyzing for ions or metals, use a trowel to obtain the soil. If the excavation is deeper than 6' BGS, do not enter the pit, but use a backhoe to assist in procurement of the sample. (If a backhoe is used, the backhoe will obtain an amount of soil from each composite point; bring the purchase to the surface staging area where a sample-portion of soil will be extracted from the backhoe purchase. The remainder of the backhoe purchase will be staged on the surface with other staged soils.)
- 3.2 Sidewall samples
  - 3.2.1 On each sidewall, procure a 5oz sample from each of five distinct points on the sidewall with distinct points resembling the "W" pattern:



- 3.2.2 Thoroughly blend these five samples in a labeled baggie.
- 3.2.3 Repeat steps 3.2.1 through 3.2.4 for each remaining sidewall.
- 3.2.4 From each labeled baggie, procure a 5 oz portion and pour into a baggie labeled "Sidewall Composite". Blend this soil mixture completely.
- 3.2.5 Obtain proper laboratory sample container for "Sidewall Composite" and continue with subparagraph 5.3 of QP 01.

#### 3.3 Bottom Sample

- 3.3.1 From bottom of excavation, procure a 5oz sample from each of five distinct points with distinct points resembling the "W" pattern as illustrated above.
- 3.3.2 Thoroughly blend these five samples in a clean baggie.
- 3.3.3 Obtain proper laboratory sample container for "Bottom
  - Composite" and continue with subparagraph 5.3 of QP 01.

## QUALITY PROCEDURE Sampling and Testing Protocol for VOC in Soil

#### 1.0 Purpose

This procedure is to be used to determine the concentrations of Volatile Organic Compounds in soils.

#### 2.0 Scope

This procedure is to be used as the standard field measurement for soil VOC concentrations. It is not to be used as a substitute for full spectrographic speciation of organic compounds.

#### **3.0 Procedure**

- 3.1 Sample Collection and Preparation
  - 3.1.1 Collect at least 500 g. of soil from the sample collection point. Take care to insure that the sample is representative of the general background to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample of soils obtained at several points in the sample area. Take care to insure that no loose vegetation, rocks or liquids are included in the sample(s).
  - 3.1.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag and sealed. When sealed, the bag should contain a nearly equal space between the soil sample and trapped air. Record the sample name and the time that the sample was collected on the Field Analytical Report Form.
  - 3.1.3 The sealed samples shall be allowed to set for a minimum of five minutes at a temperature of between 10-15 Celsius, (59-77⁰F). The sample temperatures may be adjusted by cooling the sample in ice, or by heating the sample within a generally controlled environment such as the inside of a vehicle. The samples should not be placed directly on heated surfaces or placed in direct heat sources such as lamps or heater vents.
  - 3.1.4 The sealed sample bag should be massaged to break up any clods, and to provide the soil sample with as much exposed surface area as practically possible.

- 3.2 Sampling Procedure
  - 3.2.1 The instrument to be used in conducting VOC concentration testing shall be a RAE Systems Photoionization device. (Device will be identified on VOC Field Test Report Form.) Prior to use, the instrument shall be zeroed-out in accordance with the appropriate maintenance and calibration procedure outlined in the instrument operation manual. The PID device will be calibrated each day it's used.
  - 3.2.2 Carefully open one end of the collection bag and insert the probe tip into the bag taking care that the probe tip not touch the soil sample or the sidewalls of the bag.
  - 3.2.3 Set the instrument to retain the highest result reading value. Record the reading onto the Field Test Report Form.
  - 3.2.4 If the instrument provides a reading exceeding 100 ppm, proceed to QP-7. If the reading is 100 ppm or less, NMOCD BTEX guideline has been met and no further testing for BTEX is necessary. File the Field Test Report Form in the project file.

#### 4.0 Clean-up

After testing, the soil samples shall be returned to the sampling location, and the bags collected for off-site disposal. IN NO CASE SHALL THE SAME BAG BE USED TWICE. EACH SAMPLE CONTAINER MUST BE DISCARDED AFTER EACH USE.

ſ

## **Rice Operating Company**

## Quality Procedure Composite Sampling of Excavation Sidewalls and Bottoms For BTEX

#### 1.0 Purpose

This procedure outlines the methods to be employed when obtaining final composite soil samples for BTEX analysis.

#### 2.0 Scope

This procedure is to be used when collecting soil samples intended for ultimate transfer to a testing laboratory for BTEX analysis. This procedure is to be used only when the PID field-test results for OVM exceeds 100 ppm.

#### **3.0 Preliminary**

3.1 Obtain sterile, clear, 2 oz. glass containers with Teflon lid from a laboratory supply company or the testing laboratory designated to conduct analyses of the soil.

#### 4.0 Chain of Custody

- 4.1 Prepare a Sample Plan. The plan will list the number, location and designation of each planned sample and the individual tests to be performed on the sample. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label.) Affix the labels to the jars.

#### 5.0 Sampling Procedure

- 5.1.Do not touch the soil with your bare hands. Use new nitrile gloves to help minimize any cross-contamination.
- 5.2.If safe and within OSHA regulations, go to the sampling point with the sample container. If not analyzing for ions or metals, use a trowel to

obtain the soil. If the excavation is deeper than 6' BGS, do not enter the pit, but use a backhoe to assist in procurement of the sample. (If a backhoe is used, the backhoe will obtain an amount of soil from each composite point; bring the purchase to the surface staging area where a sample-portion of soil will be extracted from the backhoe purchase. The remainder of the backhoe purchase will be staged on the surface with other staged soils.)

- 5.3.Sidewall Samples
  - 5.3.1 On each sidewall, procure a 2oz sample from each of five distinct points on the sidewall with distinct points resembling the "W" pattern:



- 5.4.Pack the soil tightly into the container leaving the top slightly domed. Screw the lid down tightly. Enter the time of collection onto the sample collection jar label. Repeat for each sampling point.
- 5.5.Place the samples directly on ice for transport to the laboratory if required.
- 5.6.Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

#### **6.0 Documentation**

- 6.1 The testing laboratory shall provide the following minimum information:
  - a. Project and sample name.
  - b. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
  - c. Results of the requested analyses
  - d. Test Methods employed
  - e. Quality Control methods and results

## Procedure for Plugging & Abandonment of Cased Water Monitoring Wells

#### 1.0 Purpose

This procedure outlines the methods to be employed to plug and abandon cased monitoring wells.

#### 2.0 Scope

This procedure shall be used for developed, cased water monitoring wells located in the State of New Mexico

#### 3.0 Preliminary

3.1 No well may be drilled, modified or plugged without NMOCD approval. Additional approvals may be required if the well is situated in a sensitive area, within municipal jurisdictions or on federal or tribal lands.

#### 4.0 Plugging

4.1 Each bore will be filled with a 1% - 3% bentonite/concrete slurry to three feet bgs. The remaining three feet will be capped with concrete only.

4.2 All wellheads will be removed to below ground surface.

#### 5.0 Records

5.1 The company plugging the well shall prepare a report on their company letter head listing the site name and describing general well construction including total depth of the well, the diameter of casing, material used to plug the well (e.g. bentonite/cement slurry), and date of the plugging operation.

5.2 It is recommended but not required that photographs of the final surface restoration be taken and included within the records.

5.3 Copies of the plugging report shall be submitted to all appropriate agencies and retained by the well operator for a minimum period of ten years.