

1R - 426-259

WORKPLANS

Date:
8-13-10

Rice Environmental Consulting & Safety

P.O. Box 5630 Hobbs, NM 88241

Phone 575.393.4411 Fax 575.393.0293

RECEIVED OCD

2010 AUG 16 P 1:56

CERTIFIED MAIL

RETURN RECEIPT NO. 7009 1680 0001 6619 6293

August 13th, 2010

Mr. Edward Hansen

New Mexico Energy, Minerals, & Natural Resources

Oil Conservation Division, Environmental Bureau

1220 S. St. Francis Drive

Santa Fe, New Mexico 87505

RE: INVESTIGATION & CHARACTERIZATION PLAN

Rice Operating Company – BD SWD System

BD Jct. N-11 boot (1R426-259): UL/N sec. 11 T22S R37E

Mr. Hansen:

RICE Operating Company (ROC) has retained Rice Environmental Consulting and Safety (RECS) to address potential environmental concerns at the above-referenced site in the BD Salt Water Disposal (SWD) system. ROC is the service provider (agent) for the BD SWD System and has no ownership of any portion of the pipeline, well, or facility. The system is owned by a consortium of oil producers, System Parties, who provide all operating capital on a percentage/usage basis. Environmental projects of this nature require System Party AFE approval prior to work commencing at the site. In general, project funding is not forthcoming until NMOCD approves the work plan. Therefore, your timely review of this submission is greatly appreciated.

For all such environmental projects, ROC will choose the path forward that:

- Protects public health,
- Provides the greatest net environmental benefit,
- Complies with NMOCD Rules, and
- Is supported by good science.

Each site shall generally have three submissions:

1. This Investigation and Characterization Plan (ICP) is proposed for gathering data and site characterization and assessment.
2. Upon evaluating the data and results from the ICP, a recommended remedy will be submitted in a Corrective Action Plan (CAP) if warranted.
3. Finally, after implementing the remedy, a Termination Request with final documentation will be submitted.

Background and Previous Work

The site is located approximately 2.5 miles south-east of Eunice, New Mexico at UL/N sec. 11 T22S R37E as shown on the Site Location Map (Figure 1). NM OSE records indicate that groundwater will likely be encountered at a depth of approximately 100 +/- feet.

Between 2005 and 2008, ROC initiated work on the former BD Jct. N-11 boot. The site was delineated using a backhoe to form a trench and soil samples were screened at regular intervals for both hydrocarbons and chlorides. The site was excavated to 30 x 10 x 12 feet. From the excavation, composite samples were collected for laboratory analysis. Laboratory tests of the site showed negligible gasoline range organics (GRO). The diesel range organics (DRO) in the 4-wall composite was 39.7 mg/kg and in the bottom composite was 16.5 mg/kg. Chlorides concentrations from the excavation read 1,152 mg/kg in the 4-wall composite and 1,232 mg/kg in the bottom composite. The site was backfilled with clean imported soil to 4 feet below ground surface where a 1 ft clay layer was installed. A clay compaction test was performed on June 3rd, 2008. The site was brought up to ground surface with the remaining imported soil. The area was contoured to the surrounding landscape, seeded, and an identification plate was placed on the surface of the site to mark its location for future environmental considerations. NMOCD was notified of potential groundwater impact on July 16, 2010 and a junction box disclosure report (Appendix A) was submitted to NMOCD via email on August 6, 2010 and with all the 2010 junction box closures and disclosures.


ROC proposes additional investigative work at the site to determine if there is potential for groundwater degradation from residual chlorides at the site.

Proposed Work Elements

1. Conduct vertical and lateral delineation of residual soil hydrocarbons and chlorides (see Appendix B for Quality Procedures).
 - a. Vertical sampling will be conducted until either one of the following criteria is met in the field.
 - i. Three samples in which the chloride concentration decreases and the third sample has a chloride concentration of ≤ 250 ppm.
 - ii. Three samples in which PID readings decrease and the third sample has a PID reading of ≤ 100 ppm.
 - iii. The sampling reaches the capillary fringe.
2. If warranted, install a monitor well to provide direct measurement of the potential groundwater impact at the site. (All monitor wells will be installed by EPA, NMOCD, and industry standards.)
3. Evaluate the risk of groundwater impact based on the information obtained.

If the evaluation of the site shows no threat to groundwater from residual chlorides, then only a vadose zone remedy will be undertaken. However, if groundwater shows impact from residual chlorides, a CAP will be developed to address these concerns.

ROC appreciates the opportunity to work with you on this project. Please call Hack Conder at (575) 393-9174 or me if you have any questions or wish to discuss the site. Sincerely,

A handwritten signature in black ink, appearing to read 'J.C.W.' followed by a long, horizontal, wavy line.

Lara Weinheimer
Project Scientist
RECS
(575) 441-0431

Attachments:


- Figures – Site location map
- Appendix A – Junction Box Disclosure Report
- Appendix B – Quality Procedures



Figures

RICE Environmental Consulting and Safety (RECS)
P.O. Box 5630 Hobbs, NM 88241
Phone 575.393.4411 Fax 575.393.0293

Site Location



BD jct. N-11 boot

Legals: UL/N sec. 11
T22S R37E
NMOCD Case #: 1R426-259

FIGURE 1



0 1,250 2,500 5,000
Feet

Drawing date: 7-16-10
Drafted by: L. Weinheimer



Appendix A

Junction Box Disclosure Report

RICE Environmental Consulting and Safety (RECS)
P.O. Box 5630 Hobbs, NM 88241
Phone 575.393.4411 Fax 575.393.0293

RICE OPERATING COMPANY JUNCTION BOX DISCLOSURE REPORT

BOX LOCATION

SWD SYSTEM	JUNCTION	UNIT	SECTION	TOWNSHIP	RANGE	COUNTY	BOX DIMENSIONS - FEET		
Blinberry-Drinkard (BD)	N-11 Box	N	11	22S	37S	Lea	Length	Width	Depth
							moved 70' east		

LAND TYPE: BLM STATE: FEE LANDOWNER: Irvin Boyd OTHER:

Depth to Groundwater: -100' feet NMOCD SITE ASSESSMENT RANKING SCORE: 10

Date Started: 5/24/2005 Date Completed: 6/4/2008 OCD Witness: no

Soil Excavated: 133.3 cubic yards Excavation Length: 30 Width: 10 Depth: 12 feet

Soil Disposed: 252 cubic yards Offsite Facility: Sundance Services Location: Eunice

FINAL ANALYTICAL RESULTS: Sample Date: 10/2/2007 Sample Depth: 12 ft

Procure 5-point composite sample of bottom and 4-point composite sample of sidewalls. TPH, BTEX and Chloride laboratory test results completed by using an approved lab and testing procedures pursuant to NMOCD guidelines.

Sample Location	GRO mg/kg	DRO mg/kg	Chlorides mg/kg
NORTH WALL COMP.	<10.0	86.7	848
EAST WALL COMP.	<10.0	107	1,024
WEST WALL COMP.	<10.0	31.8	1,312
SOUTH WALL COMP.	<10.0	55.9	432
4-WALL COMP.	<10.0	39.7	1,152
BOTTOM COMP.	<10.0	16.5	1,232

CHLORIDE FIELD TESTS

LOCATION	DEPTH	mg/kg
Vertical delineation trench 10' east of former junction (source)	1'	1,002
	2'	1,660
	3'	790
	4'	550
	5'	333
	6'	1,174
	7'	262
	8'	664
	9'	734
	10'	554
	11'	338
	12'	955

General Description of Remedial Action: This junction box was addressed during the pipeline replacement/upgrade program. A new watertight junction box was built 70 ft. east of the former. After the former junction box was removed, an investigation was conducted using a backhoe to collect soil samples at regular intervals producing a 30X10X12-ft. deep excavation. Chloride field tests were performed on each sample and yielded concentrations that did not relent with depth. Organic vapors were measured using a PID, which yielded relative low concentrations. Representative composite samples were collected from the bottom of the excavation, and the excavation walls and sent to a commercial laboratory for analysis. Laboratory analysis confirmed some elevated chloride concentrations and low organics. The excavation was backfilled with clean imported soil to 4 ft. below ground surface (BGS). At 4-3 ft. BGS, a 1-ft. thick clay barrier was installed with a compaction test performed on 6/3/2008. The remaining excavation was backfilled with clean imported soil to ground surface and contoured to the surrounding area. On 6/04/2008, the site was seeded with a blend of native vegetation and is expected to return to a productive capacity at a normal rate. A clay marker was installed above excavation to inform of clay barrier below. NMOCD was notified of potential groundwater impact on 7/16/2010.

ADDITIONAL EVALUATION IS HIGH PRIORITY

enclosures: photos, lab results, PID (field screenings), cross-section, compaction test, chloride curve

I HEREBY CERTIFY THAT THE INFORMATION ABOVE IS TRUE AND COMPLETE TO THE BEST OF MY KNOWLEDGE AND BELIEF.

SITE SUPERVISOR: Larry Bruce Baker Jr. SIGNATURE: Larry Bruce Baker Jr. COMPANY: RICE OPERATING COMPANY


REPORT ASSEMBLED BY: Katie Jones INITIAL: KJ

PROJECT LEADER: Larry Bruce Baker Jr. SIGNATURE: Larry Bruce Baker Jr. DATE: 7-16-10


This site is a "DISCLOSURE." It will be placed on a prioritized list of similar sites for further consideration.

BD Jct. N-11 Boot

Unit N, Section 11, T22S, R37E



Site prior to excavating



Compaction test

6/03/2008



Seeding excavation

6/04/2008



Excavation complete

6/04/2008



ARDINAL LABORATORIES

PHONE (325) 673-7001 • 2111 BEECHWOOD • ABILENE, TX 79503

PHONE (505) 393-2326 • 101 E. MARLAND • HOBBS, NM 88240

ANALYTICAL RESULTS FOR
RICE OPERATING
ATTN: HACK CONDER
122 W. TAYLOR
HOBBS, NM 88240
FAX TO: (505) 397-1471


Receiving Date: 10/03/07
Reporting Date: 10/03/07
Project Number: NOT GIVEN
Project Name: BD N-11
Project Location: NOT GIVEN

Analysis Date: 10/03/07
Sampling Date: 10/02/07
Sample Type: SOIL
Sample Condition: COOL & INTACT
Sample Received By: SB
Analyzed By: HM

LAB NUMBER	SAMPLE ID	Cl ⁻ (mg/Kg)
H13426-1	NORTH WALL COMPOSITE	848
H13426-2	EAST WALL COMPOSITE	1,024
H13426-3	WEST WALL COMPOSITE	1,312
H13426-4	SOUTH WALL COMPOSITE	432
H13426-5	4-WALL COMPOSITE	1,152
H13426-6	BOTTOM COMPOSITE	1,232
COPY		
Quality Control		500
True Value QC		500
% Recovery		100
Relative Percent Difference		< 0.1

METHOD: Standard Methods. 4500-ClB

Note: Analyses performed on 1:4 w/v aqueous extracts.


Chemist


Date

H13426 RICE

PLEASE NOTE: Liability and Damages. Cardinal's liability and client's exclusive remedy for any claim arising, whether based in contract or tort, shall be limited to the amount paid by client for analyses. All claims, including those for negligence and any other cause whatsoever shall be deemed waived unless made in writing and received by Cardinal within thirty (30) days after completion of the applicable service. In no event shall Cardinal be liable for incidental or consequential damages, including, without limitation, business interruptions, loss of use, or loss of profits incurred by client, its subsidiaries, affiliates or successors arising out of or related to the performance of services hereunder by Cardinal, regardless of whether such claim is based upon any of the above-stated reasons or otherwise.



CARDINAL LABORATORIES

PHONE (925) 675-7001 • 2111 BEECHWOOD • ABILENE, TX 79603

PHONE (505) 393-2326 • 101 E. MARLAND • HOBBS, NM 88240

ANALYTICAL RESULTS FOR
RICE OPERATING CO.
ATTN: HACK CONDER
122 W. TAYLOR
HOBBS, NM 88240
FAX TO: (505) 397-1471

Receiving Date: 10/03/07
Reporting Date: 10/08/07
Project Number: NOT GIVEN
Project Name: BD.N-11
Project Location: NOT GIVEN

Sampling Date: 10/02/07
Sample Type: SOIL
Sample Condition: COOL & INTACT
Sample Received By: SB
Analyzed By: CK

LAB NUMBER	SAMPLE ID	GRO (C ₆ -C ₁₂) (mg/Kg)	DRO (C ₁₂ -C ₂₈) (mg/Kg)
------------	-----------	--	---

ANALYSIS DATE		10/06/07	10/05/07
H13426-1	NORTH WALL COMPOSITE	<10.0	66.7
H13426-2	EAST WALL COMPOSITE	<10.0	107
H13426-3	WEST WALL COMPOSITE	<10.0	31.8
H13426-4	SOUTH WALL COMPOSITE	<10.0	55.9
H13426-5	4- WALL COMPOSITE	<10.0	39.7
H13426-6	BOTTOM COMPOSITE	<10.0	16.5
Quality Control		459	461
True Value QC		500	500
% Recovery		91.8	92.2
Relative Percent Difference		16.5	16.9

METHODS: TPH GRO & DRO: EPA SW-846 8015 M

COPY


Chemist


Date

H13426T Rice

PLEASE NOTE: Liability and Damages: Cardinal's liability and client's exclusive remedy for any claim arising, whether based in contract or tort, shall be limited to the amount paid by client for analysis. All claims, including those for negligence and any other cause whatsoever shall be deemed waived unless made in writing and received by Cardinal within thirty (30) days after completion of the analytical service. In no event shall Cardinal be liable for incidental or consequential damages, including, without limitation, business interruptions, loss of use, or loss of profits incurred by client, its subsidiaries, affiliates or successors arising out of or related to the performance of services hereunder by Cardinal, regardless of whether such claim is based upon any of the above-stated reasons or otherwise.

ARDINAL LABORATORIES

101 East Marland, Hobbs, NM 88240 2111 Beechwood, Abilene, TX 79603.
(505) 393-2326 FAX (505) 393-2476 (325) 673-7001 FAX (325) 673-7020

(505) 393-2326 FAX (505) 393-2476 (325) 673-7001 FAX (325) 673-7020

Company Name: RICE SPECIALTIES		P.O. #:	
Project Manager: HACK CONDER		Company:	
Address: 126 W. TAYLOR		Attn:	
City: HOUSTON State: TX Zip: 77002		Address:	
Phone #: 505 393 1774 Fax #: 505 397 1471		City:	
Project #: _____ Project Owner:		State:	
Project Name: RTD N-11		Phone #:	
Project Location: _____		Fax #:	
Sampler Name: JOHN GARCIA		PRESERV	
FOR LABOR USE ONLY		MATRIX	
Sample I.D.		# CONTAINERS	
		(G) PAB OR (C) COMP.	
		GROUNDWATER	
		WASTEWATER	
		SOIL	
		SLUDGE	
		OTHER:	
		ACID/BASE	
		ICE/COOL	
		OTHER:	
		DATE	
		TIME	
		ANALYSTS	
		CLIENTS	
1	North wall composite	1	10/2/07 11:00 AM
2	East wall composite	1	10/2/07 11:10 AM
3	West wall composite	1	10/2/07 11:20 AM
4	South wall composite	1	10/2/07 11:30 AM
5	4-wall composite	1	10/2/07 11:40 AM
6	Bottom composite	1	10/2/07 11:50 AM

COPY

Phone Result: ☐ Yes ☐ No ☐ Add'l Phone #:
 Fax Result: ☐ Yes ☐ No ☐ Add'l Fax #:
 REMARKS: **QUALITY RESULTS**
Recorder: [Signature] must not cover
Jpurvis: [Signature] rice sud. com
Egrieco: [Signature] rice sud. com

Received By: **[Signature]** Date: **10/3/07**
 Time: **8:55 AM**
 Received By: _____ Date: _____
 Time: _____

Relinquished By: **[Signature]**
 Relinquished By: _____

Delivered By: (Circle One)
 Sampler - UPS - Bus - Other:

† Cardinal cannot accept verbal changes. Please fax written changes to 505-393-2476

Rice Operating Company
HOBBS, NEW MEXICO 88240
PHONE: (505) 393-9174 FAX: (505) 397-1471
VOC FIELD TEST REPORT FORM

MODEL NO: PGM 76IS
CALIBRATION GAS
GAS COMPOSITION: ISOBUTYLENE AIR

SERIAL NO: 104412

LOT NO: 04-2747
EXP. DATE: 5-19-06
METER READING
ACCURACY: 99.8

100 PPM
BALANCE
FILL DATE: 11-19-04
ACCURACY: ± 2%

SYSTEM	JUNCTION	UNIT	SECTION	TOWNSHIP	RANGE
BD	1st S-11	A	11	22	37

SAMPLE	PID RESULT	SAMPLE	PID RESULT
10 East of Source 1	1.6	3	96.5
2	1.8	4	6.73
3	12.2	5	85.6
4	31.2	6	203
5	24.2	7	19.7
6	40.1	8	17.2
7	12.9	9	29.7
8	16.9	10	27.6
9	32.6	11	39.7
10	23.5	12	55.9
11	17.9	15 East of Source 1	4.0
12	11.0	2	1.8
10 West of Source 1	6.7	3	7.9
2	29.6	4	75.7

I certify that I have calibrated the above instrument in accordance to the manufacture operation manual.


Signature *[Handwritten Signature]*

Date 5/21/05

COPY

BD Jct. N-11 Boot
Unit 'N', Sec. 11, T22S, R37E

Excavation Cross-Section





LABORATORY TEST REPORT
PETTIGREW & ASSOCIATES, P.A.
1110 N. GRIMES
HOBBS, NM 88240
(505) 393-9827



DEBRA P. HICKS, P.E./L.S.I.
WILLIAM M. HICKS, III, P.E./P.S.

To: Rice Operating Company
Attn: Hack Conder
122 W. Taylor
Hobbs, NM 88240

Material: Wallach Red Clay

Project: General Information
BDJC N-11
Project No. 2008.1069

Test Method: ASTM: D 2922

Date of Test: June 3, 2008

Depth: See Below

Depth of Probe: 6"

Test No.	Location	Dry Density % Max	% Moisture	Depth
SG 4	10' E. & 7' N. of SW Corner	93.6	12.5	FSG

RECEIVED

JUN 20 2008

RICE OPERATING
HOBBS, NM

COPY

Control Density: 102.8
ASTM: D 698

Optimum Moisture: 22.6%

Required Compaction: 90% - 95%

Densometer ID: 2505
PETTIGREW & ASSOCIATES

Lab No.: 08 5626-5627

Copies To: Rice Operating

BY: Ernesta Hunt
BY: Dan R P.E.

CHLORIDE CONCENTRATION CURVE


RICE Operating Company

BD Jct. N-11 boot


Unit 'N', Sec. 11, T22S, R37E

Backhoe samples at 10' east of the junction (source)

Depth bgs (ft)	[C] ppm
1	1,002
2	1,660
3	790
4	550
5	333
6	1,174
7	262
8	664
9	734
10	554
11	838
12	955



Groundwater = 100 ft



Appendix B

Quality Procedures

RICE Environmental Consulting and Safety (RECS)
P.O. Box 5630 Hobbs, NM 88241
Phone 575.393.4411 Fax 575.393.0293

Rice Environmental Consulting and Safety

Quality Procedures

Table of Contents

- QP-1 Soil Samples for Transportation to a Laboratory
- QP-2 Chloride Titration Using 0.282 Normal Silver Nitrate Solution
- QP-3 Development of Cased Water-Monitoring Wells
- QP-4 Sampling of Cased Water-Monitoring Well
- QP- 5 Composite Sampling of Excavation Sidewalls and Bottoms for TPH and Chloride Analysis
- QP-6 Sampling and Testing Protocol for VOC in soil
- QP-7 Composite Sampling of Excavation Sidewalls and Bottoms for BTEX
- QP-8 Procedure for Plugging and Abandonment of Cased Water-Monitoring wells

Rice Environmental Consulting and Safety

Quality Procedure Soil Samples for Transportation to a Laboratory

1.0 Purpose

This procedure outlines the methods to be employed when obtaining soil samples to be taken to a laboratory for analysis.

2.0 Scope

This procedure is to be used when collecting soil samples intended for ultimate transfer to a testing laboratory.

3.0 Preliminary

3.1 Obtain sterile sampling containers from the testing laboratory designated to conduct analyses of the soil.

3.2 If collecting TPH, BTEX, RCRA 8 metals, cation /anions or O&G, the sample jar may be a clear 4 oz. container with Teflon lid. If collecting PAH's, use an amber 4 oz. container.

4.0 Chain of Custody

4.1 Prepare a Sample Plan. The plan will list the number, location and designation of each planned sample and the individual tests to be performed on the sample. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.

4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.

4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label.) Affix the labels to the jars.

5.0 Sampling Procedure

5.1 Do not touch the soil with your bare hands. Use new nitrile gloves to help minimize any contamination.

5.2 Go to the sampling point with the sample container. If not analyzing for ions or metals, use a trowel to obtain the soil.

- 5.3 Pack the soil tightly into the container leaving the top slightly domed. Screw the lid down tightly. Enter the time of collection onto the sample collection jar label.
- 5.4 Place the sample directly on ice for transport to the laboratory if required.
- 5.5 Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

6.0 Documentation

- 6.1 The testing laboratory shall provide the following minimum information:
 - a. Project and sample name.
 - b. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
 - c. Results of the requested analyses
 - d. Test Methods employed
 - e. Quality Control methods and results

Rice Environmental Consulting and Safety

QUALITY PROCEDURE Chloride Titration Using 0.282 Normal Silver Nitrate Solution

1.0 Purpose

This procedure is to be used to determine the concentration of chloride in soil.

2.0 Scope

This procedure is to be used as the standard field measurement for soil chloride concentrations.

3.0 Sample Collection and Preparation

- 3.1 Collect at least 80 grams of soil from the sample collection point. Take care to insure that the sample is representative of the general background to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample for soils obtained at several points in the sample area. Take care to insure that no loose vegetation, rocks or liquids are included in the sample(s).
- 3.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag. Care should be taken to insure that no cross-contamination occurs between the soil sample and the collection tools or sample processing equipment.
- 3.3 The sealed sample bag should be massaged to break up any clods.

4.0 Sample Preparation

- 4.1 Tare a clean glass vial having a minimum 40 ml capacity. Add at least 10 grams of the soil sample and record the weight.
- 4.2 Add at least 20 grams of reverse osmosis water to the soil sample and shake well.
- 4.3 Allow the sample to set for a period of 5 minutes or until the separation of soil and water.

5.0 Titration Procedure

- 5.1 Using a graduated pipette, remove 10 ml extract and dispense into a clean plastic cup.
- 5.2 Add 2-3 drops potassium chromate (K_2CrO_4) to mixture if necessary.

5.3 Using a 1 ml pipette, carefully add .282 normal silver nitrate (one drop at a time) to the sample while constantly agitating it. Stop adding silver nitrate when the solution begins to change from yellow to red. Be consistent with endpoint recognition.

5.4 Record the ml of silver nitrate used.

6.0 Calculation

To obtain the chloride concentration, insert measured data into the following formula:

$$\frac{.282 \times 35.450 \times \text{ml AgNO}_3}{\text{ml water extract}} \times \frac{\text{grams of water in mixture}}{\text{grams of soil in mixture}}$$

Using Step 5.0, determine the chloride concentration of the RO water used to mix with the soil sample. Record this concentration and subtract it from the formula results to find the net chloride in the soil sample.

Record all results on the delineation form.

Rice Environmental Consulting and Safety

Quality Procedure
Development of Cased Water-Monitoring Wells

1.0 Purpose

This procedure outlines the methods to be employed to develop cased monitoring wells.

2.0 Scope

This procedure shall be used for developed, cased water monitoring wells. It is not to be used for standing water samples such as ponds or streams.

3.0 Sample Collection and Preparation

- 3.1 Prior to development, the static water level and height of the water column within the well casing will be measured with the use of an electric D.C. probe.
- 3.2 All measurements will be recorded within a field log notebook.
- 3.3 All equipment used to measure the static water level will be decontaminated after each use by means of Liquinox, a phosphate free laboratory detergent, and water to reduce the possibility of cross-contamination. The volume of water in each well casing will be calculated.

4.0 Purging

- 4.1 Wells will be purged by using a 2" decontaminated submersible pump or dedicated one liter Teflon bailer. Wells should be purged until the pH and conductivity are stabilized and the turbidity has been reduced to the greatest extent possible.
- 4.2 If a submersible is used the pump will be decontaminated prior to use by scrubbing the outside surface of tubing and wiring with a Liquinox water mixture, pumping a Liquinox-water mixture through the pump, and a final flush with fresh water.

5.0 Water Disposal

- 5.1 All purge and decontamination water will be temporarily stored within a portable tank to be later disposed of in an appropriate manner.

6.0 Records

- 6.1 Rice Environmental Consulting and Safety will record the amount of water removed from the well during development procedures. The purge volume will be reported to the appropriate regulatory authority when filing the closure report.

Rice Environmental Consulting and Safety

Quality Procedure Sampling of Cased Water-Monitoring Well

1.0 Purpose

This procedure outlines the methods to be employed in obtaining water samples from cased monitoring wells.

2.0 Scope

This procedure shall be used for developed, cased water monitoring wells. It is not to be used for standing water samples such as ponds or streams.

3.0 Preliminary

3.1 Obtain sterile sampling containers from the testing laboratory designated to conduct analyses of the water.

3.2 The following table shall be used to select the appropriate sampling container, preservative method and holding times for the various elements and compounds to be analyzed.

Compound to be Analyzed	Sample Container Size	Sample Container Description	Cap Requirements	Preservative	Maximum Hold Time
BTEX	40 ml	VOA Container	Teflon Lined	HCL	14 days
TPH (8015 Extended)	40 ounces	(2) 40ml VOA vials	Teflon Lined	HCL and Ice	14 days
PAH	1 liter	amber glass	Teflon Lined	Ice	7 days
Cation/Anion	1 liter	HD polyethylene	Any Plastic	None	48 Hrs
Metals	1 liter	HD polyethylene	Any Plastic	Ice/HNO ₃	28 Days
TDS	300 ml	clear glass or 250 ml HD polyethylene	Any Plastic	Ice	7 Days
Cl-	500 ml	HD polyethylene	Any Plastic	None	28 Days

4.0 Chain of Custody

- 4.1 Prepare a Sample Plan. The plan will list the well identification and the individual tests to be performed at that location. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label). Affix the labels to the jars.

5.0 Bailing Procedure

- 5.1 Identify the well from the sites schematics. Place pre-labeled jar(s) next to the well. Remove the plastic cap from the well bore by first lifting the metal lever and then unscrewing the entire assembly.
- 5.2 Using a dedicated one liter Teflon bailer or submersible pump, purge a minimum of three well volumes. Place the water in storage container for transport to a ROC disposal facility.
- 5.3 If using a bailer, take care to insure that the bailing device and string does not become cross-contaminated. A clean pair of nitrile gloves should be used when handling either the retrieval string or bailer. The retrieval string should not be allowed to come into contact with the ground.

6.0 Sampling Procedure

- 6.1 Once the well has been bailed in accordance with 5.2 of this procedure, a sample may be decanted into the appropriate sample collection jar directly from the bailer or submersible pump.
- 6.2 Note the time of collection on the sample jar with a fine Sharpie.
- 6.3 Place the sample directly on ice for transport to the laboratory. The preceding table shows the maximum hold times between collection and testing for the various analyses.

6.4 Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

7.0 Documentation

7.1 The testing laboratory shall provide the following minimum information:

- A. Project and sample name.
- B. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
- C. Results of the requested analyses
- D. Test Methods employed
- E. Quality Control methods and results

Calculation for Determining the Minimum Bailing Volume for Monitor Wells

$$\text{Formula } V = (\pi r^2 h)$$

2" well $[V/231 = \text{gal}] \times 3 = \text{Purge Volume}$

V=Volume

$\pi = \text{pi}$

r=inside radius of the well bore

h=maximum height of well bore in water table

Example:

π	r^2	h(in)	V(cu.in)	V(gal)	X 3 Volumes	Actual
3.1416	1	180	565.488	2.448	7.34 gal	>10 gal

Rice Environmental Consulting and Safety

Quality Procedure Composite Sampling of Excavation Sidewalls and Bottoms For TPH and Chloride Analysis

1.0 Purpose

This procedure outlines the methods to be employed when obtaining final composite soil samples for TPH and Chloride analysis.

2.0 Scope

This procedure is to be used in conjunction with *Quality Procedure – 02: Soil Samples for Transportation to a Laboratory* and will be inserted at subparagraph 5.2 of Section 5.0: Sampling Procedure.


3.0 Sampling Procedure

Follow *Quality Procedure – 02: Soil Samples for Transportation to a Laboratory* for all Sections and subparagraphs until subparagraph 5.2 of Section 5.0: Sampling Procedure. Instead of 5.2 instructions, perform the composite sample collection procedure as follows:

3.1 Go to the excavation with a new plastic baggie. If not analyzing for ions or metals, use a trowel to obtain the soil. If the excavation is deeper than 6' BGS, do not enter the pit, but use a backhoe to assist in procurement of the sample. (If a backhoe is used, the backhoe will obtain an amount of soil from each composite point; bring the purchase to the surface staging area where a sample-portion of soil will be extracted from the backhoe purchase. The remainder of the backhoe purchase will be staged on the surface with other staged soils.)

3.2 Sidewall samples

3.2.1 On each sidewall, procure a 5oz sample from each of five distinct points on the sidewall with distinct points resembling the "W" pattern:



- 3.2.2 Thoroughly blend these five samples in a labeled baggie.
 - 3.2.3 Repeat steps 3.2.1 through 3.2.4 for each remaining sidewall.
 - 3.2.4 From each labeled baggie, procure a 5 oz portion and pour into a baggie labeled "Sidewall Composite". Blend this soil mixture completely.
 - 3.2.5 Obtain proper laboratory sample container for "Sidewall Composite" and continue with subparagraph 5.3 of QP – 01.
- 3.3 Bottom Sample
- 3.3.1 From bottom of excavation, procure a 5oz sample from each of five distinct points with distinct points resembling the "W" pattern as illustrated above.
 - 3.3.2 Thoroughly blend these five samples in a clean baggie.
 - 3.2.3 Obtain proper laboratory sample container for "Bottom Composite" and continue with subparagraph 5.3 of QP – 01.

Rice Environmental Consulting and Safety

QUALITY PROCEDURE

Sampling and Testing Protocol for VOC in Soil

1.0 Purpose

This procedure is to be used to determine the concentrations of Volatile Organic Compounds in soils.

2.0 Scope

This procedure is to be used as the standard field measurement for soil VOC concentrations. It is not to be used as a substitute for full spectrographic speciation of organic compounds.

3.0 Procedure

3.1 Sample Collection and Preparation

3.1.1 Collect at least 500 g. of soil from the sample collection point. Take care to insure that the sample is representative of the general background to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample of soils obtained at several points in the sample area. Take care to insure that no loose vegetation, rocks or liquids are included in the sample(s).

3.1.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag and sealed. When sealed, the bag should contain a nearly equal space between the soil sample and trapped air. Record the sample name and the time that the sample was collected on the Field Analytical Report Form.

3.1.3 The sealed samples shall be allowed to set for a minimum of five minutes at a temperature of between 10-15 Celsius, (59-77⁰F). The sample temperatures may be adjusted by cooling the sample in ice, or by heating the sample within a generally controlled environment such as the inside of a vehicle. The samples should not be placed directly on heated surfaces or placed in direct heat sources such as lamps or heater vents.

3.1.4 The sealed sample bag should be massaged to break up any clods, and to provide the soil sample with as much exposed surface area as practically possible.

3.2 Sampling Procedure

- 3.2.1 The instrument to be used in conducting VOC concentration testing shall be a RAE Systems Photoionization device. (Device will be identified on VOC Field Test Report Form.) Prior to use, the instrument shall be zeroed-out in accordance with the appropriate maintenance and calibration procedure outlined in the instrument operation manual. The PID device will be calibrated each day it's used.
- 3.2.2 Carefully open one end of the collection bag and insert the probe tip into the bag taking care that the probe tip not touch the soil sample or the sidewalls of the bag.
- 3.2.3 Set the instrument to retain the highest result reading value. Record the reading onto the Field Test Report Form.
- 3.2.4 **If the instrument provides a reading exceeding 100 ppm, proceed to QP-7. If the reading is 100 ppm or less, NMOCD BTEX guideline has been met and no further testing for BTEX is necessary. File the Field Test Report Form in the project file.**

4.0 Clean-up

After testing, the soil samples shall be returned to the sampling location, and the bags collected for off-site disposal. **IN NO CASE SHALL THE SAME BAG BE USED TWICE. EACH SAMPLE CONTAINER MUST BE DISCARDED AFTER EACH USE.**

Rice Environmental Consulting and Safety

Quality Procedure Composite Sampling of Excavation Sidewalls and Bottoms For BTEX

1.0 Purpose

This procedure outlines the methods to be employed when obtaining final composite soil samples for BTEX analysis.

2.0 Scope

This procedure is to be used when collecting soil samples intended for ultimate transfer to a testing laboratory for BTEX analysis. This procedure is to be used only when the PID field-test results for OVM exceeds 100 ppm.

3.0 Preliminary

- 3.1 Obtain sterile, clear, 2 oz. glass containers with Teflon lid from a laboratory supply company or the testing laboratory designated to conduct analyses of the soil.

4.0 Chain of Custody

- 4.1 Prepare a Sample Plan. The plan will list the number, location and designation of each planned sample and the individual tests to be performed on the sample. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label.) Affix the labels to the jars.


5.0 Sampling Procedure

- 5.1. Do not touch the soil with your bare hands. Use new nitrile gloves to help minimize any cross-contamination.
- 5.2. If safe and within OSHA regulations, go to the sampling point with the sample container. If not analyzing for ions or metals, use a trowel to

obtain the soil. If the excavation is deeper than 6' BGS, do not enter the pit, but use a backhoe to assist in procurement of the sample. (If a backhoe is used, the backhoe will obtain an amount of soil from each composite point; bring the purchase to the surface staging area where a sample-portion of soil will be extracted from the backhoe purchase. The remainder of the backhoe purchase will be staged on the surface with other staged soils.)

5.3. Sidewall Samples

5.3.1. On each sidewall, procure a 2oz sample from each of five distinct points on the sidewall with distinct points resembling the "W" pattern:



5.4. Pack the soil tightly into the container leaving the top slightly domed. Screw the lid down tightly. Enter the time of collection onto the sample collection jar label. Repeat for each sampling point.

5.5. Place the samples directly on ice for transport to the laboratory if required.

5.6. Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

6.0 Documentation

6.1 The testing laboratory shall provide the following minimum information:

- a. Project and sample name.
- b. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
- c. Results of the requested analyses
- d. Test Methods employed
- e. Quality Control methods and results

Rice Environmental Consulting and Safety

Procedure for Plugging & Abandonment of Cased Water Monitoring Wells

1.0 Purpose

This procedure outlines the methods to be employed to plug and abandon cased monitoring wells.

2.0 Scope

This procedure shall be used for developed, cased water monitoring wells located in the State of New Mexico

3.0 Preliminary

3.1 No well may be drilled, modified or plugged without NMOCD approval. Additional approvals may be required if the well is situated in a sensitive area, within municipal jurisdictions or on federal or tribal lands.

4.0 Plugging

4.1 Each bore will be filled with a 1% - 3% bentonite/concrete slurry to three feet bgs. The remaining three feet will be capped with concrete only.

4.2 All wellheads will be removed to below ground surface.

6.0 Records

6.1 The company plugging the well shall prepare a report on their company letter head listing the site name and describing general well construction including total depth of the well, the diameter of casing, material used to plug the well (e.g. bentonite/cement slurry), and date of the plugging operation.

6.2 It is recommended but not required that photographs of the final surface restoration be taken and included within the records.

6.3 Copies of the plugging report shall be submitted to all appropriate agencies and retained by the well operator for a minimum period of ten years.