

**Advanced Exploration, Inc
SCC # 1436104
Ogrid # 36979
War Deck # 1
30-025-30626
UL B, Section 33, T21S, R35E
North San Simon Yates
Plugging Procedure**

**8 5/8" set at 300ft, Cmt with 175sx, Calc – Circulated
5 1/2" set at 3975ft, Cmt with 200sx, Calc TOC 2600ft
Perfs 3819ft-3902ft
Top Anhy at 1704ft**

- 1. Move in plugging rig**
- 2. Pull any existing production equipment if any**
- 3. Run 5 1/2" gauge ring to 3750ft**
- 4. Run and set CIBP at 3750ft**
- 5. Cap CIBP with 35ft of cmt by dump bailer**
- 6. Run tbg open ended and tag cmt at 3715ft**
- 7. Displace well with gelled brine water**
- 8. Pull tbg**
- 9. Weld on pull nipple and stretch casing**
- 10. Cut and pull csg from 1704ft if free**
- 11. Run tbg to 1754ft**
- 12. Spot 45sx cmt plug, Pull tbg and WOC**
- 13. Run tbg and tag plug**
- 14. Pull tbg to 350ft**
- 15. Spot 45sx cmt plug, Pull tbg and WOC**
- 16. Run tbg and tag cmt plug, Maximum depth 250ft**
- 17. Pull tbg to 60ft**
- 18. Circulate cmt to surface(Est 20sx)**
- 19. Pull tbg, Cut off well head and install PA marker**
- 20. Clean and level location**

BEP 01/3/2004

**Before the OCD
Case 13413
OCD Ex. 7**