

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name <i>Murray #1</i>
2. Name of Operator <i>J.W. Henegar</i>	8. Farm or Lease Name <i>Murray</i>
3. Address of Operator <i>P.O. Box 9 Sperry Oklahoma 74073</i>	9. Well No. <i>#1</i>
4. Location of Well UNIT LETTER <i>K</i> <i>2310</i> FEET FROM THE <i>South</i> LINE AND <i>1650</i> FEET FROM THE <i>West</i> LINE, SECTION <i>21</i> TOWNSHIP <i>11N</i> RANGE <i>33E</i> NMPM.	10. Field and Pool, or Wildcat <i>Wildcat</i>
15. Elevation (Show whether DF, RT, GR, etc.) <i>4062</i>	12. County <i>Quay</i>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Wash well down to 960', pumped 50 sks. cement. Pull tubing and let set, ran tubing and tagged @ 780', pulled tubing to 420' and pumped 25 sks. Pull tubing and let set. Tag cement @ 328', pulled tubing to 200' and pumped 50 sks. cement, went back to 50', pumped 10 sks. from 30' to surface and placed marker on well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Buddy Lumberson* TITLE *President Panhandle Plugger's* DATE *3/25/85*

APPROVED BY *[Signature]* TITLE *SUPERVISOR* DATE *5-4-85*

CONDITIONS OF APPROVAL, IF ANY: