

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised June 10, 2003

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-32950
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name State AZ
8. Well Number #4
9. OGRID Number 022922
10. Pool name or Wildcat Greyburg Jackson

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other

RECEIVED

2. Name of Operator
The Wiser Oil Company

APR 16 2004

3. Address of Operator
P. O. Box 2568 Hobbs, New Mexico

000-ARTESIA

4. Well Location

Unit Letter M : 1310' feet from the SOUTH line and 330' feet from the WEST line
Section 16 Township 17S Range 31E NMPM EDDY County

11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3751'

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☒

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

INTENT: COMPLETE AS SAN ANDRES/GREYBURG PRODUCING OIL AND GAS.

SPUD DATE: 2/27/04

8 5/8" 24# CASING SET @ 423' CEMENT @ SURFACE.

5 1/2" 15.5# CASING SET @ 3800'. TOP OF CEMENT @ 2700' BY CEMENT BOND LOG. HAD WATERFLOW OF 1/4 BPM @ 2700'.

- Perforate lower San Andres 3750-80 with 2 spf.
- Acidize with 2000 gals acid. Swab load back.
- Perforate 3596-08,3636-6666. Acidize with 2000 gals acid. Swab load back.
- Perforate Greyburg @ 3062-42*81-90*3136-45*3185-92*3208-15 Vac-3342-48.
- Acidize with 3000 gals acid. Swab load back. Prepare to fracture treat Greyburg- Vacuumme.
- Perforate casing @ 2650' pump 500 sxs cement. Run TS to determine cement top.
- Place well on pump.

If this work requires an earthen pit, a permit must be approved prior to construction of pit(s).

We plan to start the completion 4/19/04

I hereby certify that the information above is true and correct to the best of my knowledge and belief.

SIGNATURE G. M. Jones TITLE Superintendent DATE 4/13/04

Type or print name G. M. Jones E-mail address: Telephone No. 505-392-9797

APPROVED BY [Signature] TITLE District Supervisor DATE MAY 17 2004

Wiser Oil

ST A2 #4

22-141 50 SHEETS
22-142 100 SHEETS
22-144 200 SHEETS



8 5/8" 24#

Top Cement 2700'

3800'

5 1/2" 15.5#