

file

DISTRICT I

P.O. Box 1980, Hobbs NM 88240

DISTRICT II

P.O. Drawer DD, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

State of New Mexico  
Energy, Minerals and Natural Resources Department

OIL CONSERVATION DIVISION

P.O. Box 2088

Santa Fe, New Mexico 87504-2088



WELL API NO.	30-005-61552
5. Indicate Type of Lease	
State	FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	SHADDEN <del>TX</del> STATE
8. Well No	1
9. Pool Name or Wildcat	PECOS SLOPE ABO

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL ☐ GAS ☐  
WELL ☐ WELL ☒ OTHER ☐

2. Name of Operator  
Yates Petroleum Corporation

3. Address of Operator  
105 South 4th., Artesia, NM 88210

4. Well Location  
Unit Letter M : 990 Feet From The SOUTH Line and 990 Feet From The WEST Line  
Section 10 Township T6S Rang. R26E NMPM CHAVES COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

YATES PETROLEUM CORPORATION respectfully requests permission to plug & abandon this well as follows:

1. MIRU WSU & all safety equipment. Load tubing & casing w/ 2% KCL water; ND wellhead & NU BOP, then release packer @ 3806'. POH w/ tubing & packer. Pump KCL water to keep well dead while pulling tbgs. & pkr..
2. RU wireline & RIH w/ gauge ring to 3850' +/-, then RIH & set 4-1/2" CIBP @ 3800'. MU dump bailer & RIH w/ bailer & dump 35' cement on top of CIBP. RIH w/ tubing to 3750' +/- & circ hole w/ 10.0 ppg mud. POH w/ tbgs..
3. RD BOP & pull 4-1/2" slips in the wellhead. Pull on casing & determine free point in casing, the RIH w/ severing shot & cut off casing @ 3400' +/- or at free point as indicated by amount of stretch pulled on casing. RD wireline. RU tools, POH, & lay down casing.
4. NU BOP on 8-5/8" casing; RIH w/ tubing to 3450' +/- & spot a 50 sack cement plug in 4-1/2" casing stub from 3450' to 3350'; a 50 sk plug from 1800' to 1700'; a 50 sack plug @ base of 8-5/8" casing from 976' to 876', & a 10 sack plug @ surface. <sup>791</sup> <sup>1640' - 1540'</sup> <sup>729</sup> <sup>25 SX</sup>
5. ND BOP & remove the wellhead & install a dry hole marker per regulation. Clean location & move off.

I hereby certify that the information above is a true and complete to the best of my knowledge and belief.

SIGNATURE Donna Clack TITLE Regulatory Technician DATE 1/31/03  
TYPE OR PRINT NAME DONNA CLACK TELEPHONE NO. 505-748-1471  
(This space for State Use)  
APPROVED BY [Signature] TITLE Field Rep ID DATE FEB 10 2003  
CONDITIONS OF APPROVAL, IF ANY

Notify OCD 24 hrs. prior to any work done

<b>OPERATOR:</b> Yates Petroleum Corp.Inc.		<b>API#</b> 30-005-61552	
<b>WELL:</b> Shadden State # 1		<b>LOCATION:</b> M-10-6-26	
<b>SURFACE CSG-HOLE SIZE</b> 14 3/4"	<b>CSG. SIZE</b> 10 3/4"	<b>SET @</b> 926'	<b>SX. CMT.</b> 800 <b>TOC.</b> Circ
<b>LONG STRING- HOLE SIZE</b> 9 7/8"	<b>CSG. SIZE</b> 4.5"	<b>SET @</b> 4284'	<b>SX. CMT.</b> 375 <b>TOC.</b> 3430'
<b>OTHER-</b>			

