

Submit Copy To Appropriate District Office
District I - (575) 393-6161
1625 N French Dr, Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St, Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd, Aztec, NM 87410
District IV - (505) 476-3460
1220 S St Francis Dr, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised August 1, 2011

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-005-61765

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name
Geraldine VG Com

8. Well Number
1

9. OGRID Number
025575

10. Pool name or Wildcat
Pecos Slope Abo

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
Yates Petroleum Corporation

3. Address of Operator
105 South Fourth Street, Artesia, NM 88210

4. Well Location

Unit Letter G : 1980 feet from the North line and 1980 feet from the East line
Section 29 Township 6S Range 26E NMPM County: Chaves

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3660' GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

**Notify OCD 24 hrs. prior
To any work done.**

OTHER ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Yates Petroleum Corporation plans to plug and abandon this well as follows:

1. RU any necessary safety equipment.
2. TOOH with 2 7/8 inch production string.
3. Perforate and spot 50 sx Class "C" cement plug from 1500 feet to 1600 feet. - WOC - Tag
4. Spot a 25 sx Class "C" cement plug from 878 feet to 978 feet. WOC and tag plug.
5. Perforate and spot a 25 sx Class "C" cement plug from 60 feet to surface, outside and inside casing.
6. Remove all surface equipment, weld dry hole marker and clean location ass per regulations.

* - T1H - Set CIBP @ 3660' w/35' damp hole on 25sx cement on top.

**SEE ATTACHED
CONDITIONS OF
APPROVAL**

Rig Release Date:

RECEIVED

JAN 27 2012

NMOCD ARTESIA

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Sharon Coll TITLE Regulatory Compliance Technician DATE 1/25/2012

Type or print name Sharon Coll E-mail address: scoll@yatespetroleum.com PHONE: 575-748-1471 ext 13507

For State Use Only

APPROVED BY: [Signature] TITLE Approval Granted providing work is complete by 4/30/2012 DATE 1/30/2012
Conditions of Approval (if any):

Verbal Regulatory approval _____
AFE approval _____
Regulatory approval _____

Geraldine VG Com #1
Unit G, 1980' FNL & 1980' FEL of Section 29-T6S-R26E
Chaves County, New Mexico
AFE: 11-261-0

PLUGGING PROCEDURE

Sent 1/25/12

Call OCD in Artesia with a 24 hour notice before commencing operations
575-748-1283

Call the BLM in Roswell with a 24 hour notice before commencing operations
575-627-0272

1. MIRU WSU. Rig up safety equipment as needed. No casing recovery will be attempted. TOOH with 2 7/8" production string.
- (*) → 2. TIH and set a CIBP @ 3,668' and cap with 35' cmt. This puts a plug over the Abo perms and across the top of the Abo.
3. Perforate and spot a 50 sx Class "C" cement plug from 1500'-1600'. This puts a 100' cement plug across the top of the Glorieta, inside and outside the casing. - WOC-Tag
4. Spot a 25 sx Class "C" cement plug from 878'-978'. POOH. This puts a 100' plug across the Surface Gasing shoe. WOC and tag plug.
5. Perforate and spot a 25 sx Class "C" Cement plug from 60' up to the surface, outside and inside casing.
6. Remove all surface equipment, weld dry hole marker & clean location as per regulations.

Area Engineer

Margrethe Hotter

date

1/21/14 JWP 11/22/11