(JUNE 1990) DEPARTMEN BUREAU OF SUNDRY NOTICES Do not use this form for proposals to d Use "APPLICATION SUBMI 1. Type of Well Oil Gas Well Well Other 2. Name of Operator STRATA PR 3. Address and Telephone No. P. O. Box 10 Roswell, New 4. Location of Well (Footage, Sec., T., R., M., or Sur	w Mexico 88202-1030 6505-622-1127	5. Lease Designation and Serial No. NM-18293	
		Eddy County, New Mexico	
12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF SUBMISSION TYPE OF ACTION			
Notice of Intent       X       Subsequent Report       Final Abandonment Notice	Abandonment Abandonment Abandonment Plugging Back Casing Repair Altering Casing OTHER Perf/Acidize	Change of Plans New Construction Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*			
<ul> <li>04/30/03: TIH w/pump &amp; 210 3/4" rods. Polish rods &amp; liner. Hang well on. Prep to put on pump. Set 300 bbl tank &amp;roll line.</li> <li>05/02/03: Tie-in electrical system. Set generator. Put well on pump. Pumping.</li> </ul>			
05/03/03: Adjust heater tre	Adjust heater treater. Tie-in gas meter loop. Lay gas lines. Pumping.		
05/05/03: Intermittently flo	Intermittently flowing up csg. Prep to check FL. Pump does not appear to be working properly.		
05/12/03: Not pumping. Lower rods. Clean trash in pump. TOH w/pump & rods. NUBOP. Release tbg anchor. TOH w/tbg. RU. TIH w/4" select fire guns. Perf 3 (.42) holes as follows: 5001', 02', 03'. TOH w/guns. RU GIH w/pkr & RBP. Set RBP at 5047'. RU OK Hot Oil Services. Circ hole w/2% KCL. Test RBP to 2500#. Test okay. RU. Spot 1 bbl 7 1/2% NeFe at 5010'. PU. Set pkr at 4915'. Break down perfs at 3250#. Open by-pass. Spot acid to pkr. Acidize w/750 gal 7 1/2% NeFe & 6 ball sealers. RU swab. Swab well dwn. SISD.			
05/14/03: TP 20#, FL 2600'. Swab well dwn. Release pkr. Latch on to RBP. Move RBP to 4512'. PU. RU. Circ hole. Test plug to 2000#. Test okay. Spot 1 bbl 7 1/2% NeFe at 4446'. TOH w/tbg & pkr. RU. TIH w/4" select fire guns. Perf 3 (.42) holes as follows: 4433', 34', 35'. TOH w/guns. TIH w/pkr. Set pkr at 4353'. Break dwn formation at 2000#. Open by-pass. Spot acid to pkr. Close by-pass. Acidize w/750 gal 7 1/2% NeFe w/6 ball sealers. Ball well out. RU Swab. Swab well dwn. SISD.			
Swab weii Uwii.		ACCEPTED FOR RECORD	
14. I hereby certify that the foregoing is true and correct     MAY     9     2003       Signed     Signed     Date     05/16/03			
(This space for Federal or State office use)		LES BABYAK	
Approved by Conditions of approval, if any:	Title	DatePETROLFUM ENGINEER	

Tile 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\* See Instruction on Reverse Side

F3160-5

5