
Submit 1 Copy To Appropriate District Office	State of New Mexico	Form C-103 Revised August 1, 2011			
<u>District I</u> - (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natural Resources	WELL API NO.			
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	30-015-21678 5. Indicate Type of Lease			
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE FEE			
District IV - (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.			
1220 S. St. Francis Dr., Santa Fe, NM 87505					
	TICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name Jackson AT			
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		8. Well Number			
PROPOSALS.) 1. Type of Well: Oil Well	Gas Well 🔲 Other	7			
2. Name of Operator		9. OGRID Number 025575			
3. Address of Operator	Yates Petroleum Corporation 3. Address of Operator				
105 South Fourth Street, Artesia,	NM 88210	Eagle Creek; San Andres			
4. Well Location Unit Letter N :	990 feet from the South line and	1650 feet from the West line			
Section 14	Township 17S Range 25E	NMPM Eddy County			
	11. Elevation (Show whether DR, RKB, RT, GR, et				
	3495'GR				
12 Check	Appropriate Box to Indicate Nature of Notic	e Report or Other Data			
		•			
NOTICE OF I PERFORM REMEDIAL WORK					
PULL OR ALTER CASING					
	]				
OTHER:					
	npleted operations. (Clearly state all pertinent details,				
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.					
Yates Petroleum Corporation plan	s to plug and abandon this well as follows:				
	needed. NU BOP. TOH with production equipment.				
	t below perfs at 1450' and circulate Class "C" cement t then TOH and set a CIBP above perfs at 1230' before of				
3. Cut off wellhead and verify tha	t there is cement behind all casing strings at surface. I	f so, cement to surface with 60 sx. If not then			
	surface behind each casing string before cementing to s	surface inside production casing.			
4. Install dry hole marker and clea	in location.	Z			
Wellbore schematics attached		pproval Granted providing work			
NOTE: Yates Petroleum Corpora	tion will use steel pits and no earth pits	pproval Granted providing work			
		pproval Granted providing work complete by Une 5-2013 APTES A			
<u>_</u>					
Spud Date:	Rig Release Date:				
L	L				
Lhereby certify that the informatic	on above is true and complete to the best of my knowle	dge and helief			
Thereby certify that the informatic	above is fue and complete to the best of my knowle				
SIGNATURE	TITLE Regulatory Paranting	<u>s Supervisor</u> DATE <u>February 4, 2013</u>			
SIGNATURE CLAR	TITLE Regulatory Reporting	Supervisor_DATE_rebruary 4, 2013			
Type or print name <u>Tina H</u>	luerta E-mail address: <u>tinah@yatespetrole</u>	eum.com PHONE: <u>575-748-4168</u>			
For State Use Only					
APPROVED BY: $(10)000$ TITLE UST approvisit DATE $3/7/20/3$					
Conditions of Approval (if any): See Attached COA's					


Well Name: Jackson AT #7Field: Eagle CreekLocation: 990' FSL & 1650' FWL Sec 14-17S-25ECounty: EddyState: New MexicoGL: 3,495'Zero:KB:Spud Date: 11/14/1975Comments: API # 30015216780000



Casing Program			
Size/Wt/Grade	Depth Set		
10 ¾" 32# K-55	340'		
7" 20# K-55	1,170'		
4 ½" 9.5# & 5 ½" 15.5# K-55	1,496'		

SKETCH NOT TO SCALE

DATE: 1/14/2013



Casing Program			
Size/Wt/Grade	Depth Set		
10 ¾" 32# K-55	340'		
7" 20# K-55	1,170'		
4 ½" 9.5# & 5 ½" 15.5# K-55	1,496'		

DATE: 1/14/2013

## NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF A	PPROVAL FOR P	LUGGING	& ABANDONMENT
Operator: Vates 1	Let. lorp		
Well Name & Number	Jackson AT	#7	
API #: 30.0/5 -	21678		

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- **3.** Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.

where the second se

8. Cement Retainers may not be used.

9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
10. Plugs may be combined after consulting with and getting approval from NMOCD.
11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: Man 7-2013

APPROVED BY: R/Dada

## **GUIDELINES FOR PLUGGING AND ABANDONMENT**

## DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above sait zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
  - Formations to be isolated with plugs placed at the top of each formation are:
    - o Fusselman
    - o Devonian
    - o Morrow
    - o Wolfcamp
    - o Bone Spring
    - o Delaware
    - Any Salt Section (Plug at top and bottom)
    - o Abo
    - o Glorieta
    - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section.
   Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).