
·		. '	
Submit 1 Copy To Appropriate District	State of New Mexico	Form C-103	
District 1 – (575) 393-6161 Ene 1625 N. French Dr., Hobbs, NM 88240	rgy, Minerals and Natural Resources	Revised August 1, 2011 WELL API NO.	
District II (575) 748-1283	L CONSERVATION DIVISION	30-015-23529	
<u>District III</u> – (505) 334-6178	1220 South St. Francis Dr.	5. Indicate Type of Lease STATE FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> - (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM 87505			
SUNDRY NOTICES AND (DO NOT USE THIS FORM FOR PROPOSALS TO D		7. Lease Name or Unit Agreement Name Jackson AT	
DIFFERENT RESERVOIR. USE "APPLICATION FO PROPOSALS.)	R PERMIT" (FORM C-101) FOR SUCH	8. Well Number	
1. Type of Well: Oil Well 🛛 Gas Well	Other	11	
2. Name of Operator Yates Petroleum Corporation	-	9. OGRID Number 025575	
3. Address of Operator		10. Pool name or Wildcat	
105 South Fourth Street, Artesia, NM 88210		Eagle Creek; San Andres	
4. Well Location Unit Letter J : 2310 fe	eet from the South line and	1650 feet from the <u>East</u> line	
	ownship 17S Range 25E	NMPM Eddy County	
11. Elev	ation (Show whether DR, RKB, RT, GR, e 3480'GR	tc.)	
		Bin 440,70 - 327 47, 401 and 200	
12. Check Appropri	ate Box to Indicate Nature of Notic	e, Report or Other Data	
NOTICE OF INTENTION	ON TO: SU	BSEQUENT REPORT OF:	
	ND ABANDON 🛛 🛛 REMEDIAL WO	DRK Image: Altering Casing Image: Alte	
_			
OTHER:	OTHER:		
	ations! (Clearly state all pertinent details, RULE 19.15.7.14 NMAC. For Multiple (and give pertinent dates, including estimated date	
proposed completion or recompletion		completions. Attach wendore diagram of	
Yates Petroleum Corporation plans to plug and	d abandon this well as follows:		
1. MIRU any safety equipment as needed. NU 2 RIH with bit and scraper to just below perfo		to 500' with 115 sx. Note: If fill is tagged and	
you are unable to get below perfs then TOH ar	nd set a CIBP above perfs at 1200' before	circulating cement to 500' (90 sx).	
3. Cut off wellhead and verify that there is cer perforate and circulate cement to surface behin			
4. Install dry hole marker and clean location.			
Wellbore schematics attached		r,	
NOTE: Votes Detroloum Comparation will us		proval Granted providing work	
NOTE: Yates Petroleum Corporation will use	is o		
Spud Date:	Rig Release Date:	D AR	
]	proval Granted providing work complete by <u>June 15-2013</u> EB 0 7 2013 EB 0 7 2013	
I hereby certify that the information above is t	rue and complete to the best of my knowle		
Thereby certify that the information above B t			
SIGNATURE (Jone) Liver to) TITLE Regulatory Reporting	Supervisor DATE February 4, 2013	
Type or print name <u>Tina Huerta</u>	E-mail address: <u>tinah@yatespetrole</u>	eum.com PHONE: <u>575-748-4168</u>	
	1 JULY DAST R. SI	$D_{\text{DATE}} = \frac{3}{13}$	
APPROVED BY: () () () () () () () () () () () () ()	HACKED ADDE	DAIE Of 15	
yo war intered CUTS			


-/ 1



.

Casing Program		
Size/Wt/Grade	Depth Set	
10 ¾" 40.5# K-55	385'	
7" 20# K-55	1,158'	
4 ½° 9.5# K-55	1,499'	

٦



Casing Program		
Size/Wt/Grade	Depth Set	
10 ¾" 40.5# K-55	385'	
7" 20# K-55	1,158'	
4 ½" 9.5# K-55	1,499'	
<u> </u>		

NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: #11 lad KSOn Well Name & Number: API #:

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.

8. Cement Retainers may not be used.

9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
10. Plugs may be combined after consulting with and getting approval from NMOCD.
11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: Mar 7-2013

APPROVED BY: Made

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o **Devonian**
 - o Morrow
 - o Wolfcamp
 - o Bone Spring
 - o Delaware
 - Any Salt Section (Plug at top and bottom)
 - o Abo
 - o Glorieta
 - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section.
 Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).