

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone: (575) 748-1283 Fax: (575) 748-9720
District III
1000 Rio Brazos Road, Aztec, NM 87410
Phone: (505) 334-6178 Fax: (505) 334-6170
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505
Phone: (505) 476-3460 Fax: (505) 476-3462

State of New Mexico
Energy, Minerals & Natural Resources Department
OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-102
Revised August 1, 2011
Submit one copy to appropriate
District Office

☐ AMENDED REPORT

WELL LOCATION AND ACREAGE DEDICATION PLAT

API Number 30-015-42012	Pool Code 96144	Pool Name Carrlsbad Bone Spring, East
Property Code	Property Name SIMPSON-CDM COM	Well Number 1H
OGRID No. 192463	Operator Name OXY USA WTP LP	Elevation 3161.9'

Surface Location


UL or lot no.	Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the	East/West line	County
A	29	21 SOUTH	27 EAST, N.M.P.M.		480'	NORTH	310'	EAST	EDDY

Bottom Hole Location If Different From Surface

UL or lot no.	Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the	East/West line	County
D	29	21 SOUTH	27 EAST, N.M.P.M.		400'	NORTH	350'	WEST	EDDY

Dedicated Acres	Joint or Infill	Consolidation Code	Order No.
160	N		

No allowable will be assigned to this completion until all interests have been consolidated or a non-standard unit has been approved by the division.



OPERATOR CERTIFICATION

I hereby certify that the information contained herein is true and complete to the best of my knowledge and belief, and that this organization either owns a working interest or unleased mineral interest in the land including the proposed bottom hole location or has a right to drill this well at this location pursuant to a contract with an owner of such a mineral or working interest, or to a voluntary pooling agreement or a compulsory pooling order heretofore entered by the division.

Signature: *David Stewart Sr.* Date: **1/26/14**
Printed Name: **David Stewart Sr. Res. Adv.**
E-mail Address: **david_stewart@oxy.com**

SURVEYOR CERTIFICATION

I hereby certify that the well location shown on this plat was plotted from field notes of previous surveys made by me or under my supervision, and that the same is true and correct to the best of my belief.

Date of Survey: **NOVEMBER 21, 2013**
Signature and Seal of Professional Surveyor: *Jerry J. As...*

Certificate Number: **15079** Date: **12/30/2013**

WO# 131121WL-b (KA)

Operator Name/Number:	OXY USA WTP LP	192463
Lease Name/Number:	Simpson-CDM Com #1H	Fee
Pool Name/Number:	Carlsbad Bone Spring, East	96144
Surface Location:	480 FNL 310 FEL A Sec 29 T21S R27E	
Penetration Point:	480 FNL 330 FEL A Sec 29 T21S R27E	
Bottom Hole Location:	400 FNL 350 FWL D Sec 29 T21S R27E	

C-102 Plats: 11/21/13 12/20/13 1/22/14 Elevation: 3161.9' GL Objective: 3rd Bone Spring

Proposed TD: Pilot Hole 8934' TVD Horizontal Lateral 8784' TVD 13089' TMD
SL - Lat: 32.4567894 Long: 104.2040632 X=539873.1 Y=529917.6 NAD - 1927
PP - Lat: 32.4567888 Long: 104.2041280 X=539853.1 Y=529917.3 NAD - 1927
BH - Lat: 32.4568729 Long: 104.2190079 X=535263.4 Y=529942.7 NAD - 1927

Casing Program:

Hole Size	Interval	OD Csg	Weight	Collar	Grade	Condition	Collapse Design Factor	Burst Design Factor	Tension Design Factor
14-3/4"	0-400'	11-3/4"	47	BT&C	J55	New	8.57	1.43	6.38
				Hole filled with 8.5# Mud			1514#	3072#	
10-5/8"	0-3250'	8-5/8"	32	LT&C	J-55	New	2.38	1.29	2.24
				Hole filled with 10.2# Mud			2533#	3928#	
7-7/8"	0-13089'	5-1/2"	17	BT&C	P-110	New	1.75	1.23	2.39
				Hole filled with 9.2# Mud			7480#	10640#	

Collapse and burst loads calculated using Stress Check with anticipated loads

Cement Program:

- 11-3/4" Surface Circulate cement to surface w/ 350sx PPC cmt w/ 2% CaCl₂, 14.8ppg 1.35 yield 1608# 24hr CS 165% Excess
- 8-5/8" Intermediate Circulate cement to surface w/ 600sx HES Light PPC cmt w/ 5% salt + .3% HR-800, 12.9ppg 1.91 yield 734# 24hr CS 105% Excess followed by 180sx PPC cmt w/ 1% CaCl₂, 14.8ppg 1.33 yield 2125# 24hr CS 105% Excess
- Pilot Hole Plug Cement w/ 530sx PPC cmt w/ .85% CFR-3 + .25% HR-601, 18.0ppg .90 yield 690# 24hr CS 50% Excess from 8934' to +/-8000'
- 5-1/2" Production Cement w/ 650sx PP cmt w/ 14.8#/sx Silicalite 50/50 Blend + 15#/sx Scotchlite HGS-6000 + 3#/sx Kol-Seal + .125#/sx Poly-E-Flake + .25#/sx HR-800, 10.2ppg 2.95 yield 900# 24hr CS 100% Excess followed by 690sx Super H cmt w/ 3#/sx salt + .4% CFR-3 + .5% Halad-344 + .3% HR-800 + .125#/sx Poly-E-Flake, 13.2ppg 1.66 yield 620# 24hr CS 40% Excess. Calc TOC-2200'

Description of Cement Additives: Calcium Chloride, Salt (Accelerator); Silicalite (Additive Material); CFR-3 (Dispersant); Bentonite, Scotchlite HGS-6000 (Light Weight Additive); Kol-Seal, Poly-E-Flake (Lost Circulation Additive); Halad-344 (Low Fluid Loss Control); HR-601, HR-800 (Retarder)
The above cement volumes could be revised pending the caliper measurement.

Proposed Mud Circulation System:

Depth	Mud Wt. ppg	Visc sec	Fluid Loss	Type System
0 - 400'	8.5	28-38	NC	Fresh Water/Spud Mud
400 - 3250'	10.2	28-32	NC	Fresh water/NaCl Brine
3250 - 8934' (Pilot Hole)	9.2	28-34	NC	Cut Brine/Sweeps
8000 - 13089' (Curve-Lateral)	9.2	32-50	<18	Duo Vis/Salt Gel/Starch/PAC

Pump high viscosity sweeps as needed for hole cleaning. The mud system will be monitored visually/manually as well as with an electronic PVT. The necessary mud products for additional weight and fluid loss control will be on location at all times.

BOP Program:

Surface None
Intermediate/Production 13-5/8" 10M three ram stack w/ 5M annular preventer, 5M Choke Manifold


Estimated Tops of Geological Markers & Depths of Anticipated Fresh Water, Oil or Gas:

Geological Marker	Depth	Type
a. Rustler	190'	---
b. Top Salt	561'	---
c. Bottom Salt	1586'	---
d. Base Anhydrite	3215'	---
e. Delaware	4000'	Formation
f. 1st Bone Spring	5079'	Oil/Gas
g. 2nd Bone Spring	6570'	Oil/Gas
h. 3rd Bone Spring	7509'	Oil/Gas
i. Wolfcamp	8834'	Oil/Gas

Fresh water may be present above the Rustler formation. Surface casing will be set below the top of the Rustler, which will cover potential fresh water sources.

A closed loop system will be utilized consisting of above ground steel tanks and haul-off bins.
Disposal of liquids, drilling fluids and cuttings will be disposed of at an approved facility.

SECTION 29, TOWNSHIP 21 SOUTH, RANGE 27 EAST, N.M.P.M.,
EDDY COUNTY NEW MEXICO



Basis of Bearings - GPS Geodetic Measurements
NAD East Zone (83) North American Datum of 1983

DRIVING DIRECTIONS:
FROM THE INTERSECTION OF U.S. HWY.
#285 AND U.S. HWY. 62/180 IN CARLSBAD,
GO EAST ON U.S. HWY. #62/180 FOR 3.2
MILES, TURN LEFT ON GEORGE SHOUP
RELIEF ROUTE AND GO NORTH FOR 1.2
MILES, TURN LEFT ON CALICHE ROAD AND
GO WEST FOR 0.6 MILES, TURN RIGHT AND
GO NORTH FOR 0.4 MILES, TURN LEFT AND
GO WEST FOR 0.3 MILES, TURN LEFT ON
PROPOSED ROAD AND GO SOUTH FOR 167.0
FEET TO LOCATION.




SURVEYORS CERTIFICATE

I, TERRY J. ASEL, NEW MEXICO PROFESSIONAL SURVEYOR
NO. 15079, DO HEREBY CERTIFY THAT I CONDUCTED AND AM
RESPONSIBLE FOR THIS SURVEY, THAT THIS SURVEY IS
TRUE AND CORRECT TO THE BEST OF MY KNOWLEDGE AND
BELIEF, AND MEETS THE "MINIMUM STANDARDS FOR
SURVEYING IN NEW MEXICO" AS ADOPTED BY THE NEW
MEXICO STATE BOARD OF REGISTRATION FOR
PROFESSIONAL ENGINEERS AND SURVEYORS.

Terry J. Asel 12/30/2013
Terry J. Asel N.M.R.P.L.S. No. 15079

Asel Surveying

P.O. BOX 393 - 310 W. TAYLOR
HOBBS, NEW MEXICO - 575-393-9146



LEGEND

- - DENOTES FOUND MONUMENT AS NOTED
- ⊗ - DENOTES CALCULATED CORNER

1000' 0 1000' 2000' FEET
SCALE: 1"=1000'

OXY USA INC.

SIMPSON-CDM COM #1H LOCATED AT
480' FNL & 310' FEL IN SECTION 29,
TOWNSHIP 21 SOUTH, RANGE 27 EAST,
N.M.P.M., EDDY COUNTY, NEW MEXICO


Survey Date: 11/21/13	Sheet 1 of 1 Sheets
W.O. Number: 131121WL-b	Drawn By: KA Rev:
Date: 12/18/13	131121WL-b Scale: 1"=1000'

NORTH




I, TERRY J. ASEL, NEW MEXICO PROFESSIONAL SURVEYOR NO. 15079, DO HEREBY CERTIFY THAT I CONDUCTED AND AM RESPONSIBLE FOR THIS SURVEY, THAT THIS SURVEY IS TRUE AND CORRECT TO THE BEST OF MY KNOWLEDGE AND BELIEF, AND MEETS THE "MINIMUM STANDARDS FOR SURVEYING IN NEW MEXICO" AS ADOPTED BY THE NEW MEXICO STATE BOARD OF REGISTRATION FOR PROFESSIONAL ENGINEERS AND SURVEYORS.

Asel Surveying




Survey Date: 11/21/13	Sheet 1 of 1 Sheets	
W.O. Number: 131121WL-b	Drawn By: KA	Rev:
Date: 12/19/13	131121WL-b	Scale: 1"=300'




CONTOUR INTERVAL: 10'

U.S.G.S. TOPOGRAPHIC MAP
CARLSBAD EAST, N.M.

P.O. BOX 393 - 310 W. TAYLOR
HOBBS, NEW MEXICO - 575-393-9146



VICINITY MAP




SEC. 29 TWP. 21-S RGE. 27-E
 SURVEY N.M.P.M.
 COUNTY EDDY
 DESCRIPTION 480' FNL & 310' FEL
 ELEVATION 3161.9'
 OPERATOR OXY USA INC.
 LEASE SIMPSON-CDM COM #1H

SCALE: 1" = 2 MILES

Asel Surveying

P.O. BOX 393 - 310 W. TAYLOR
 HOBBS, NEW MEXICO - 575-393-9146



DIRECTIONS FROM THE INTERSECTION OF U.S. HWY. #285 AND U.S. HWY. #62/180 IN CARLSBAD, GO EAST ON U.S. HWY. #62/180 FOR 3.2 MILES, TURN LEFT ON GEORGE SHOUP RELIEF ROUTE AND GO NORTH FOR 1.2 MILES, TURN LEFT ON CALICHE ROAD AND GO WEST FOR 0.6 MILES, TURN RIGHT AND GO NORTH FOR 0.4 MILES, TURN LEFT AND GO WEST FOR 0.3 MILES, TURN LEFT ON PROPOSED ROAD AND GO SOUTH FOR 167.0 FEET TO LOCATION.



Scientific Drilling

Planning Report



Database:	CompassC	Local Co-ordinate Reference:	Well SCDMC-1H
Company:	OXY	TVD Reference:	KB @ 3185.90usft
Project:	Eddy County, New Mexico	MD Reference:	KB @ 3185.90usft
Site:	Simpson-CDM Com 1H	North Reference:	Grid
Well:	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Pilot Wellpath		
Design:	Design #1		

Project	Eddy County, New Mexico, New Mexico		
Map System:	US State Plane 1927 (Exact solution)	System Datum:	Mean Sea Level
Geo Datum:	NAD 1927 (NADCON CONUS)		
Map Zone:	New Mexico East 3001		

Site	Simpson-CDM Com 1H		
Site Position:		Northing:	529,917.60 usft
From:	Map	Easting:	539,873.10 usft
Position Uncertainty:	0.00 usft	Slot Radius:	13-3/16 "
		Latitude:	32.457
		Longitude:	-104.204
		Grid Convergence:	0.07 °

Well	SCDMC-1H		
Well Position	+N/-S	0.00 usft	Northing:
	+E/-W	0.00 usft	Easting:
Position Uncertainty	0.00 usft	Wellhead Elevation:	0.00 usft
		Latitude:	32.457
		Longitude:	-104.204
		Ground Level:	3,161.90 usft

Wellbore	Pilot Wellpath		
----------	----------------	--	--

Magnetics	Model Name	Sample Date	Declination	Dip Angle	Field Strength
			(°)	(°)	(nT)
	IGRF2010	1/15/2014	7.58	60.23	48,430

Design	Design #1		
Audit Notes:			
Version:	Phase:	PROTOTYPE	Tie On Depth:
			0.00
Vertical Section:	Depth From (TVD)	+N/-S	+E/-W
	(usft)	(usft)	(usft)
	0.00	0.00	0.00
			Direction
			(°)
			0.00

Plan Sections										
Measured	Inclination	Azimuth	Vertical	+N/-S	+E/-W	Dogleg	Build	Turn	TFO	Target
Depth	(°)	(°)	Depth	(usft)	(usft)	Rate	Rate	Rate	(°)	
(usft)			(usft)			(°/100usft)	(°/100usft)	(°/100usft)		
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,933.90	0.00	0.00	8,933.90	0.00	0.00	0.00	0.00	0.00	0.00	




Scientific Drilling

Planning Report




Database:	CompassC	Local Co-ordinate Reference:	Well,SCDMC-1H
Company:	OXY	TVD Reference:	KB @ 3185.90usft
Project:	Eddy County, New Mexico	MD Reference:	KB @ 3185.90usft
Site:	Simpson-CDM Com 1H	North Reference:	Grid
Well:	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Pilot Wellpath		
Design:	Design #1		

Planned Survey									
Measured Depth (usft)	Inclination (°)	Azimuth (°)	Vertical Depth (usft)	+N/-S (usft)	+E/-W (usft)	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
100.00	0.00	0.00	100.00	0.00	0.00	0.00	0.00	0.00	0.00
200.00	0.00	0.00	200.00	0.00	0.00	0.00	0.00	0.00	0.00
300.00	0.00	0.00	300.00	0.00	0.00	0.00	0.00	0.00	0.00
400.00	0.00	0.00	400.00	0.00	0.00	0.00	0.00	0.00	0.00
500.00	0.00	0.00	500.00	0.00	0.00	0.00	0.00	0.00	0.00
600.00	0.00	0.00	600.00	0.00	0.00	0.00	0.00	0.00	0.00
700.00	0.00	0.00	700.00	0.00	0.00	0.00	0.00	0.00	0.00
800.00	0.00	0.00	800.00	0.00	0.00	0.00	0.00	0.00	0.00
900.00	0.00	0.00	900.00	0.00	0.00	0.00	0.00	0.00	0.00
1,000.00	0.00	0.00	1,000.00	0.00	0.00	0.00	0.00	0.00	0.00
1,100.00	0.00	0.00	1,100.00	0.00	0.00	0.00	0.00	0.00	0.00
1,200.00	0.00	0.00	1,200.00	0.00	0.00	0.00	0.00	0.00	0.00
1,300.00	0.00	0.00	1,300.00	0.00	0.00	0.00	0.00	0.00	0.00
1,400.00	0.00	0.00	1,400.00	0.00	0.00	0.00	0.00	0.00	0.00
1,500.00	0.00	0.00	1,500.00	0.00	0.00	0.00	0.00	0.00	0.00
1,600.00	0.00	0.00	1,600.00	0.00	0.00	0.00	0.00	0.00	0.00
1,700.00	0.00	0.00	1,700.00	0.00	0.00	0.00	0.00	0.00	0.00
1,800.00	0.00	0.00	1,800.00	0.00	0.00	0.00	0.00	0.00	0.00
1,900.00	0.00	0.00	1,900.00	0.00	0.00	0.00	0.00	0.00	0.00
2,000.00	0.00	0.00	2,000.00	0.00	0.00	0.00	0.00	0.00	0.00
2,100.00	0.00	0.00	2,100.00	0.00	0.00	0.00	0.00	0.00	0.00
2,200.00	0.00	0.00	2,200.00	0.00	0.00	0.00	0.00	0.00	0.00
2,300.00	0.00	0.00	2,300.00	0.00	0.00	0.00	0.00	0.00	0.00
2,400.00	0.00	0.00	2,400.00	0.00	0.00	0.00	0.00	0.00	0.00
2,500.00	0.00	0.00	2,500.00	0.00	0.00	0.00	0.00	0.00	0.00
2,600.00	0.00	0.00	2,600.00	0.00	0.00	0.00	0.00	0.00	0.00
2,700.00	0.00	0.00	2,700.00	0.00	0.00	0.00	0.00	0.00	0.00
2,800.00	0.00	0.00	2,800.00	0.00	0.00	0.00	0.00	0.00	0.00
2,900.00	0.00	0.00	2,900.00	0.00	0.00	0.00	0.00	0.00	0.00
3,000.00	0.00	0.00	3,000.00	0.00	0.00	0.00	0.00	0.00	0.00
3,100.00	0.00	0.00	3,100.00	0.00	0.00	0.00	0.00	0.00	0.00
3,200.00	0.00	0.00	3,200.00	0.00	0.00	0.00	0.00	0.00	0.00
3,300.00	0.00	0.00	3,300.00	0.00	0.00	0.00	0.00	0.00	0.00
3,400.00	0.00	0.00	3,400.00	0.00	0.00	0.00	0.00	0.00	0.00
3,500.00	0.00	0.00	3,500.00	0.00	0.00	0.00	0.00	0.00	0.00
3,600.00	0.00	0.00	3,600.00	0.00	0.00	0.00	0.00	0.00	0.00
3,700.00	0.00	0.00	3,700.00	0.00	0.00	0.00	0.00	0.00	0.00
3,800.00	0.00	0.00	3,800.00	0.00	0.00	0.00	0.00	0.00	0.00
3,900.00	0.00	0.00	3,900.00	0.00	0.00	0.00	0.00	0.00	0.00
4,000.00	0.00	0.00	4,000.00	0.00	0.00	0.00	0.00	0.00	0.00
4,100.00	0.00	0.00	4,100.00	0.00	0.00	0.00	0.00	0.00	0.00
4,200.00	0.00	0.00	4,200.00	0.00	0.00	0.00	0.00	0.00	0.00
4,300.00	0.00	0.00	4,300.00	0.00	0.00	0.00	0.00	0.00	0.00
4,400.00	0.00	0.00	4,400.00	0.00	0.00	0.00	0.00	0.00	0.00
4,500.00	0.00	0.00	4,500.00	0.00	0.00	0.00	0.00	0.00	0.00
4,600.00	0.00	0.00	4,600.00	0.00	0.00	0.00	0.00	0.00	0.00
4,700.00	0.00	0.00	4,700.00	0.00	0.00	0.00	0.00	0.00	0.00
4,800.00	0.00	0.00	4,800.00	0.00	0.00	0.00	0.00	0.00	0.00
4,900.00	0.00	0.00	4,900.00	0.00	0.00	0.00	0.00	0.00	0.00
5,000.00	0.00	0.00	5,000.00	0.00	0.00	0.00	0.00	0.00	0.00
5,100.00	0.00	0.00	5,100.00	0.00	0.00	0.00	0.00	0.00	0.00
5,200.00	0.00	0.00	5,200.00	0.00	0.00	0.00	0.00	0.00	0.00
5,300.00	0.00	0.00	5,300.00	0.00	0.00	0.00	0.00	0.00	0.00



Scientific Drilling
Planning Report



Database:	CompassC	Local Co-ordinate Reference:	Well: SCDMC-1H
Company:	OXY	TVD Reference:	KB @ 3185.90usft
Project:	Eddy County New Mexico	MD Reference:	KB @ 3185.90usft
Site:	Simpson:CDM Com/1H	North Reference:	Grid
Well:	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Pilot Wellpath		
Design:	Design #1		

Planned Survey										
Measured Depth (usft)	Inclination (°)	Azimuth (°)	Vertical Depth (usft)	+N/-S (usft)	+E/-W (usft)	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)	
5,400.00	0.00	0.00	5,400.00	0.00	0.00	0.00	0.00	0.00	0.00	
5,500.00	0.00	0.00	5,500.00	0.00	0.00	0.00	0.00	0.00	0.00	
5,600.00	0.00	0.00	5,600.00	0.00	0.00	0.00	0.00	0.00	0.00	
5,700.00	0.00	0.00	5,700.00	0.00	0.00	0.00	0.00	0.00	0.00	
5,800.00	0.00	0.00	5,800.00	0.00	0.00	0.00	0.00	0.00	0.00	
5,900.00	0.00	0.00	5,900.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,000.00	0.00	0.00	6,000.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,100.00	0.00	0.00	6,100.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,200.00	0.00	0.00	6,200.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,300.00	0.00	0.00	6,300.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,400.00	0.00	0.00	6,400.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,500.00	0.00	0.00	6,500.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,600.00	0.00	0.00	6,600.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,700.00	0.00	0.00	6,700.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,800.00	0.00	0.00	6,800.00	0.00	0.00	0.00	0.00	0.00	0.00	
6,900.00	0.00	0.00	6,900.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,000.00	0.00	0.00	7,000.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,100.00	0.00	0.00	7,100.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,200.00	0.00	0.00	7,200.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,300.00	0.00	0.00	7,300.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,400.00	0.00	0.00	7,400.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,500.00	0.00	0.00	7,500.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,600.00	0.00	0.00	7,600.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,700.00	0.00	0.00	7,700.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,800.00	0.00	0.00	7,800.00	0.00	0.00	0.00	0.00	0.00	0.00	
7,900.00	0.00	0.00	7,900.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,000.00	0.00	0.00	8,000.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,100.00	0.00	0.00	8,100.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,200.00	0.00	0.00	8,200.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,300.00	0.00	0.00	8,300.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,400.00	0.00	0.00	8,400.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,500.00	0.00	0.00	8,500.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,600.00	0.00	0.00	8,600.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,700.00	0.00	0.00	8,700.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,800.00	0.00	0.00	8,800.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,900.00	0.00	0.00	8,900.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,933.90	0.00	0.00	8,933.90	0.00	0.00	0.00	0.00	0.00	0.00	



SCDMC-1H
Eddy County, New Mexico
Northing: 529917.60
Easting: 539873.10
Design #1



To convert a Magnetic Direction to a Grid Direction, Add 7.51°
To convert a True Direction to a Grid Direction, Subtract 0.07°

Azimuths to Grid North
True North: -0.07°
Magnetic North: 7.51°
Magnetic Field
Strength: 48430.3nT
Dip Angle: 60.23°
Date: 1/15/2014
Model: IGRF2010

SECTION DETAILS:

MD	Inc	Azi	TVD	+N/-S	+E/-W	Dleg	TFace	V Sect	Target
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	
8068.70	0.00	0.00	8068.70	0.00	0.00	0.00	0.00	0.00	
9193.70	90.00	270.31	8784.90	3.90	-716.19	8.00	270.31	716.20	
13087.27	90.00	270.31	8784.90	25.10	-4609.70	0.00	0.00	4609.77	SCDMC 1H BHL

WELL DETAILS: SCDMC-1H

Ground Level: 3161.90

+N/-S	+E/-W	Northing	Easting	Latitude	Longitude
0.00	0.00	529917.60	539873.10	32.457	-104.204

DESIGN TARGET DETAILS:

Name	TVD	+N/-S	+E/-W	Northing	Easting
SCDMC 1H PP	8236.78	-0.30	-20.00	529917.30	539853.10
SCDMC 1H BHL	8784.90	25.10	-4609.70	529942.70	535263.40

PROJECT DETAILS:


Eddy County, New Mexico
Geodetic System: US State Plane 1927
Datum: NAD 1927 (NADCON CONUS)
Ellipsoid: Clarke 1866
Zone: New Mexico East 3001

System Datum: Mean Sea Level


SITE DETAILS: Simpson-CDM Com 1H

Site Centre Northing: 529917.60
Easting: 539873.10

Positional Uncertainty: 0.00
Convergence: 0.07
Local North: Grid



KB @ 3185.90usft
Gr @ 3161.90





Scientific Drilling

Planning Report



Database:	CompassC	Local Co-ordinate Reference:	Well: SCDMC-1H
Company:	OXY	TVD Reference:	KB @ 3185.90usft
Project:	Eddy County, New Mexico	MD Reference:	KB @ 3185.90usft
Site:	Simpson-CDM Com-1H	North Reference:	Grid
Well:	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Original Wellbore		
Design:	Design #1		

Project:	Eddy County, New Mexico, New Mexico		
Map System:	US State Plane 1927 (Exact solution)	System Datum:	Mean Sea Level
Geo Datum:	NAD 1927 (NADCON CONUS)		
Map Zone:	New Mexico East 3001		


Site:	Simpson-CDM/Com-1H		
Site Position:		Northing:	529,917.60 usft
From:	Map	Easting:	539,873.10 usft
Position Uncertainty:	0.00 usft	Slot Radius:	13-3/16 "
		Latitude:	32.457
		Longitude:	-104.204
		Grid Convergence:	0.07 °

Well:	SCDMC-1H		
Well Position	+N/-S	0.00 usft	Northing:
	+E/-W	0.00 usft	Easting:
Position Uncertainty	0.00 usft	Wellhead Elevation:	0.00 usft
		Latitude:	32.457
		Longitude:	-104.204
		Ground Level:	3,161.90 usft

Wellbore:	Original Wellbore		
Magnetics	Model Name	Sample Date	Declination
			(°)
	IGRF2010	1/15/2014	7.58
			Dip Angle
			(°)
			60.23
			Field Strength
			(nT)
			48,430

Design:	Design #1		
Audit Notes:			
Version:	Phase:	PROTOTYPE	Tie On Depth:
			0.00
Vertical Section:	Depth From (TVD)	+N/-S	+E/-W
	(usft)	(usft)	(usft)
	0.00	0.00	0.00
			Direction
			(°)
			270.31

Plan Sections										
Measured	Inclination	Azimuth	Vertical	+N/-S	+E/-W	Dogleg	Build	Turn	TFO	Target
Depth	(°)	(°)	Depth	(usft)	(usft)	Rate	Rate	Rate	(°)	
(usft)			(usft)			(°/100usft)	(°/100usft)	(°/100usft)		
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	
8,068.70	0.00	0.00	8,068.70	0.00	0.00	0.00	0.00	0.00	0.00	
9,193.70	90.00	270.31	8,784.90	3.90	-716.19	8.00	8.00	0.00	270.31	
13,087.27	90.00	270.31	8,784.90	25.10	-4,609.70	0.00	0.00	0.00	0.00	SCDMC 1H BHL



Database:	CompassC	Local Co-ordinate Reference:	Well SCDMC-1H
Company:	OXY	TVD Reference:	KB @ 3185.90usft
Project:	Eddy County, New Mexico	MD Reference:	KB @ 3185.90usft
Site:	Simpson-CDM Com. 1H	North Reference:	Grid
Well:	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Original Wellbore		
Design:	Design #1		

Planned Survey

Measured Depth (usft)	Inclination (°)	Azimuth (°)	Vertical Depth (usft)	+N/-S (usft)	+E/-W (usft)	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
100.00	0.00	0.00	100.00	0.00	0.00	0.00	0.00	0.00	0.00
200.00	0.00	0.00	200.00	0.00	0.00	0.00	0.00	0.00	0.00
300.00	0.00	0.00	300.00	0.00	0.00	0.00	0.00	0.00	0.00
400.00	0.00	0.00	400.00	0.00	0.00	0.00	0.00	0.00	0.00
500.00	0.00	0.00	500.00	0.00	0.00	0.00	0.00	0.00	0.00
600.00	0.00	0.00	600.00	0.00	0.00	0.00	0.00	0.00	0.00
700.00	0.00	0.00	700.00	0.00	0.00	0.00	0.00	0.00	0.00
800.00	0.00	0.00	800.00	0.00	0.00	0.00	0.00	0.00	0.00
900.00	0.00	0.00	900.00	0.00	0.00	0.00	0.00	0.00	0.00
1,000.00	0.00	0.00	1,000.00	0.00	0.00	0.00	0.00	0.00	0.00
1,100.00	0.00	0.00	1,100.00	0.00	0.00	0.00	0.00	0.00	0.00
1,200.00	0.00	0.00	1,200.00	0.00	0.00	0.00	0.00	0.00	0.00
1,300.00	0.00	0.00	1,300.00	0.00	0.00	0.00	0.00	0.00	0.00
1,400.00	0.00	0.00	1,400.00	0.00	0.00	0.00	0.00	0.00	0.00
1,500.00	0.00	0.00	1,500.00	0.00	0.00	0.00	0.00	0.00	0.00
1,600.00	0.00	0.00	1,600.00	0.00	0.00	0.00	0.00	0.00	0.00
1,700.00	0.00	0.00	1,700.00	0.00	0.00	0.00	0.00	0.00	0.00
1,800.00	0.00	0.00	1,800.00	0.00	0.00	0.00	0.00	0.00	0.00
1,900.00	0.00	0.00	1,900.00	0.00	0.00	0.00	0.00	0.00	0.00
2,000.00	0.00	0.00	2,000.00	0.00	0.00	0.00	0.00	0.00	0.00
2,100.00	0.00	0.00	2,100.00	0.00	0.00	0.00	0.00	0.00	0.00
2,200.00	0.00	0.00	2,200.00	0.00	0.00	0.00	0.00	0.00	0.00
2,300.00	0.00	0.00	2,300.00	0.00	0.00	0.00	0.00	0.00	0.00
2,400.00	0.00	0.00	2,400.00	0.00	0.00	0.00	0.00	0.00	0.00
2,500.00	0.00	0.00	2,500.00	0.00	0.00	0.00	0.00	0.00	0.00
2,600.00	0.00	0.00	2,600.00	0.00	0.00	0.00	0.00	0.00	0.00
2,700.00	0.00	0.00	2,700.00	0.00	0.00	0.00	0.00	0.00	0.00
2,800.00	0.00	0.00	2,800.00	0.00	0.00	0.00	0.00	0.00	0.00
2,900.00	0.00	0.00	2,900.00	0.00	0.00	0.00	0.00	0.00	0.00
3,000.00	0.00	0.00	3,000.00	0.00	0.00	0.00	0.00	0.00	0.00
3,100.00	0.00	0.00	3,100.00	0.00	0.00	0.00	0.00	0.00	0.00
3,200.00	0.00	0.00	3,200.00	0.00	0.00	0.00	0.00	0.00	0.00
3,300.00	0.00	0.00	3,300.00	0.00	0.00	0.00	0.00	0.00	0.00
3,400.00	0.00	0.00	3,400.00	0.00	0.00	0.00	0.00	0.00	0.00
3,500.00	0.00	0.00	3,500.00	0.00	0.00	0.00	0.00	0.00	0.00
3,600.00	0.00	0.00	3,600.00	0.00	0.00	0.00	0.00	0.00	0.00
3,700.00	0.00	0.00	3,700.00	0.00	0.00	0.00	0.00	0.00	0.00
3,800.00	0.00	0.00	3,800.00	0.00	0.00	0.00	0.00	0.00	0.00
3,900.00	0.00	0.00	3,900.00	0.00	0.00	0.00	0.00	0.00	0.00
4,000.00	0.00	0.00	4,000.00	0.00	0.00	0.00	0.00	0.00	0.00
4,100.00	0.00	0.00	4,100.00	0.00	0.00	0.00	0.00	0.00	0.00
4,200.00	0.00	0.00	4,200.00	0.00	0.00	0.00	0.00	0.00	0.00
4,300.00	0.00	0.00	4,300.00	0.00	0.00	0.00	0.00	0.00	0.00
4,400.00	0.00	0.00	4,400.00	0.00	0.00	0.00	0.00	0.00	0.00
4,500.00	0.00	0.00	4,500.00	0.00	0.00	0.00	0.00	0.00	0.00
4,600.00	0.00	0.00	4,600.00	0.00	0.00	0.00	0.00	0.00	0.00
4,700.00	0.00	0.00	4,700.00	0.00	0.00	0.00	0.00	0.00	0.00
4,800.00	0.00	0.00	4,800.00	0.00	0.00	0.00	0.00	0.00	0.00
4,900.00	0.00	0.00	4,900.00	0.00	0.00	0.00	0.00	0.00	0.00
5,000.00	0.00	0.00	5,000.00	0.00	0.00	0.00	0.00	0.00	0.00
5,100.00	0.00	0.00	5,100.00	0.00	0.00	0.00	0.00	0.00	0.00
5,200.00	0.00	0.00	5,200.00	0.00	0.00	0.00	0.00	0.00	0.00
5,300.00	0.00	0.00	5,300.00	0.00	0.00	0.00	0.00	0.00	0.00



Scientific Drilling
Planning Report




Database	CompassC	Local Co-ordinate Reference:	Well SCDMC-1H
Company	OXY	TVD Reference:	KB @ 3185.90usft
Project	Eddy County, New Mexico	MD Reference:	KB @ 3185.90usft
Site	Simpson-CDM Com 1H	North Reference:	Grid
Well	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore	Original Wellbore		
Design	Design #1		

Planned Survey									
Measured Depth (usft)	Inclination (°)	Azimuth (°)	Vertical Depth (usft)	+N/-S (usft)	+E/-W (usft)	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)
5,400.00	0.00	0.00	5,400.00	0.00	0.00	0.00	0.00	0.00	0.00
5,500.00	0.00	0.00	5,500.00	0.00	0.00	0.00	0.00	0.00	0.00
5,600.00	0.00	0.00	5,600.00	0.00	0.00	0.00	0.00	0.00	0.00
5,700.00	0.00	0.00	5,700.00	0.00	0.00	0.00	0.00	0.00	0.00
5,800.00	0.00	0.00	5,800.00	0.00	0.00	0.00	0.00	0.00	0.00
5,900.00	0.00	0.00	5,900.00	0.00	0.00	0.00	0.00	0.00	0.00
6,000.00	0.00	0.00	6,000.00	0.00	0.00	0.00	0.00	0.00	0.00
6,100.00	0.00	0.00	6,100.00	0.00	0.00	0.00	0.00	0.00	0.00
6,200.00	0.00	0.00	6,200.00	0.00	0.00	0.00	0.00	0.00	0.00
6,300.00	0.00	0.00	6,300.00	0.00	0.00	0.00	0.00	0.00	0.00
6,400.00	0.00	0.00	6,400.00	0.00	0.00	0.00	0.00	0.00	0.00
6,500.00	0.00	0.00	6,500.00	0.00	0.00	0.00	0.00	0.00	0.00
6,600.00	0.00	0.00	6,600.00	0.00	0.00	0.00	0.00	0.00	0.00
6,700.00	0.00	0.00	6,700.00	0.00	0.00	0.00	0.00	0.00	0.00
6,800.00	0.00	0.00	6,800.00	0.00	0.00	0.00	0.00	0.00	0.00
6,900.00	0.00	0.00	6,900.00	0.00	0.00	0.00	0.00	0.00	0.00
7,000.00	0.00	0.00	7,000.00	0.00	0.00	0.00	0.00	0.00	0.00
7,100.00	0.00	0.00	7,100.00	0.00	0.00	0.00	0.00	0.00	0.00
7,200.00	0.00	0.00	7,200.00	0.00	0.00	0.00	0.00	0.00	0.00
7,300.00	0.00	0.00	7,300.00	0.00	0.00	0.00	0.00	0.00	0.00
7,400.00	0.00	0.00	7,400.00	0.00	0.00	0.00	0.00	0.00	0.00
7,500.00	0.00	0.00	7,500.00	0.00	0.00	0.00	0.00	0.00	0.00
7,600.00	0.00	0.00	7,600.00	0.00	0.00	0.00	0.00	0.00	0.00
7,700.00	0.00	0.00	7,700.00	0.00	0.00	0.00	0.00	0.00	0.00
7,800.00	0.00	0.00	7,800.00	0.00	0.00	0.00	0.00	0.00	0.00
7,900.00	0.00	0.00	7,900.00	0.00	0.00	0.00	0.00	0.00	0.00
8,000.00	0.00	0.00	8,000.00	0.00	0.00	0.00	0.00	0.00	0.00
8,068.70	0.00	0.00	8,068.70	0.00	0.00	0.00	0.00	0.00	0.00
8,100.00	2.50	270.31	8,099.99	0.00	-0.68	0.68	8.00	8.00	0.00
8,150.00	6.50	270.31	8,149.83	0.03	-4.61	4.61	8.00	8.00	0.00
8,200.00	10.50	270.31	8,199.27	0.07	-12.00	12.00	8.00	8.00	0.00
8,250.00	14.50	270.31	8,248.07	0.12	-22.82	22.82	8.00	8.00	0.00
8,300.00	18.50	270.31	8,296.00	0.20	-37.02	37.03	8.00	8.00	0.00
8,350.00	22.50	270.31	8,342.82	0.30	-54.53	54.54	8.00	8.00	0.00
8,400.00	26.50	270.31	8,388.31	0.41	-75.27	75.27	8.00	8.00	0.00
8,450.00	30.50	270.31	8,432.24	0.54	-99.12	99.12	8.00	8.00	0.00
8,500.00	34.50	270.31	8,474.40	0.69	-125.99	125.99	8.00	8.00	0.00
8,550.00	38.50	270.31	8,514.58	0.85	-155.72	155.72	8.00	8.00	0.00
8,600.00	42.50	270.31	8,552.59	1.02	-188.19	188.19	8.00	8.00	0.00
8,650.00	46.50	270.31	8,588.25	1.22	-223.23	223.23	8.00	8.00	0.00
8,700.00	50.50	270.31	8,621.37	1.42	-260.67	260.68	8.00	8.00	0.00
8,750.00	54.50	270.31	8,651.80	1.64	-300.33	300.34	8.00	8.00	0.00
8,800.00	58.50	270.31	8,679.39	1.86	-342.02	342.03	8.00	8.00	0.00
8,850.00	62.50	270.31	8,704.00	2.10	-385.53	385.54	8.00	8.00	0.00
8,900.00	66.50	270.31	8,725.52	2.34	-430.65	430.66	8.00	8.00	0.00
8,950.00	70.50	270.31	8,743.84	2.60	-477.16	477.17	8.00	8.00	0.00
9,000.00	74.50	270.31	8,758.87	2.86	-524.84	524.85	8.00	8.00	0.00
9,050.00	78.50	270.31	8,770.53	3.12	-573.45	573.46	8.00	8.00	0.00
9,100.00	82.50	270.31	8,778.78	3.39	-622.75	622.76	8.00	8.00	0.00
9,150.00	86.50	270.31	8,783.57	3.66	-672.51	672.52	8.00	8.00	0.00
9,193.70	90.00	270.31	8,784.90	3.90	-716.19	716.20	8.00	8.00	0.00
9,200.00	90.00	270.31	8,784.90	3.93	-722.48	722.49	0.00	0.00	0.00
9,300.00	90.00	270.31	8,784.90	4.48	-822.48	822.49	0.00	0.00	0.00
9,400.00	90.00	270.31	8,784.90	5.02	-922.48	922.49	0.00	0.00	0.00



Scientific Drilling

Planning Report



Database:	CompassC	Local Co-ordinate Reference:	Well: SCDMC-1H
Company:	OXY	TVD Reference:	KB @ 3185.90usft
Project:	Eddy County, New Mexico	MD Reference:	KB @ 3185.90usft
Site:	Simpson-CDM.Com 1H	North Reference:	Grid
Well:	SCDMC-1H	Survey Calculation Method:	Minimum Curvature
Wellbore:	Original Wellbore		
Design:	Design #1		

Planned Survey										
Measured Depth (usft)	Inclination (°)	Azimuth (°)	Vertical Depth (usft)	+N/-S (usft)	+E/-W (usft)	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	Turn Rate (°/100usft)	
9,500.00	90.00	270.31	8,784.90	5.57	-1,022.48	1,022.49	0.00	0.00	0.00	
9,600.00	90.00	270.31	8,784.90	6.11	-1,122.48	1,122.49	0.00	0.00	0.00	
9,700.00	90.00	270.31	8,784.90	6.66	-1,222.48	1,222.49	0.00	0.00	0.00	
9,800.00	90.00	270.31	8,784.90	7.20	-1,322.47	1,322.49	0.00	0.00	0.00	
9,900.00	90.00	270.31	8,784.90	7.75	-1,422.47	1,422.49	0.00	0.00	0.00	
10,000.00	90.00	270.31	8,784.90	8.29	-1,522.47	1,522.49	0.00	0.00	0.00	
10,100.00	90.00	270.31	8,784.90	8.83	-1,622.47	1,622.49	0.00	0.00	0.00	
10,200.00	90.00	270.31	8,784.90	9.38	-1,722.47	1,722.49	0.00	0.00	0.00	
10,300.00	90.00	270.31	8,784.90	9.92	-1,822.47	1,822.49	0.00	0.00	0.00	
10,400.00	90.00	270.31	8,784.90	10.47	-1,922.47	1,922.49	0.00	0.00	0.00	
10,500.00	90.00	270.31	8,784.90	11.01	-2,022.46	2,022.49	0.00	0.00	0.00	
10,600.00	90.00	270.31	8,784.90	11.56	-2,122.46	2,122.49	0.00	0.00	0.00	
10,700.00	90.00	270.31	8,784.90	12.10	-2,222.46	2,222.49	0.00	0.00	0.00	
10,800.00	90.00	270.31	8,784.90	12.65	-2,322.46	2,322.49	0.00	0.00	0.00	
10,900.00	90.00	270.31	8,784.90	13.19	-2,422.46	2,422.49	0.00	0.00	0.00	
11,000.00	90.00	270.31	8,784.90	13.73	-2,522.46	2,522.49	0.00	0.00	0.00	
11,100.00	90.00	270.31	8,784.90	14.28	-2,622.46	2,622.49	0.00	0.00	0.00	
11,200.00	90.00	270.31	8,784.90	14.82	-2,722.45	2,722.49	0.00	0.00	0.00	
11,300.00	90.00	270.31	8,784.90	15.37	-2,822.45	2,822.49	0.00	0.00	0.00	
11,400.00	90.00	270.31	8,784.90	15.91	-2,922.45	2,922.49	0.00	0.00	0.00	
11,500.00	90.00	270.31	8,784.90	16.46	-3,022.45	3,022.49	0.00	0.00	0.00	
11,600.00	90.00	270.31	8,784.90	17.00	-3,122.45	3,122.49	0.00	0.00	0.00	
11,700.00	90.00	270.31	8,784.90	17.55	-3,222.45	3,222.49	0.00	0.00	0.00	
11,800.00	90.00	270.31	8,784.90	18.09	-3,322.45	3,322.49	0.00	0.00	0.00	
11,900.00	90.00	270.31	8,784.90	18.64	-3,422.44	3,422.49	0.00	0.00	0.00	
12,000.00	90.00	270.31	8,784.90	19.18	-3,522.44	3,522.49	0.00	0.00	0.00	
12,100.00	90.00	270.31	8,784.90	19.72	-3,622.44	3,622.49	0.00	0.00	0.00	
12,200.00	90.00	270.31	8,784.90	20.27	-3,722.44	3,722.49	0.00	0.00	0.00	
12,300.00	90.00	270.31	8,784.90	20.81	-3,822.44	3,822.49	0.00	0.00	0.00	
12,400.00	90.00	270.31	8,784.90	21.36	-3,922.44	3,922.49	0.00	0.00	0.00	
12,500.00	90.00	270.31	8,784.90	21.90	-4,022.43	4,022.49	0.00	0.00	0.00	
12,600.00	90.00	270.31	8,784.90	22.45	-4,122.43	4,122.49	0.00	0.00	0.00	
12,700.00	90.00	270.31	8,784.90	22.99	-4,222.43	4,222.49	0.00	0.00	0.00	
12,800.00	90.00	270.31	8,784.90	23.54	-4,322.43	4,322.49	0.00	0.00	0.00	
12,900.00	90.00	270.31	8,784.90	24.08	-4,422.43	4,422.49	0.00	0.00	0.00	
13,000.00	90.00	270.31	8,784.90	24.62	-4,522.43	4,522.49	0.00	0.00	0.00	
13,087.27	90.00	270.31	8,784.90	25.10	-4,609.70	4,609.77	0.00	0.00	0.00	

Design Targets										
Target Name	hit/miss target	Dip Angle (°)	Dip Dir. (°)	TVD (usft)	+N/-S (usft)	+E/-W (usft)	Northing (usft)	Easting (usft)	Latitude	Longitude
SCDMC 1H PP		0.00	0.00	8,236.78	-0.30	-20.00	529,917.30	539,853.10	32.457	-104.204
- plan misses target center by 0.41usft at 8238.36usft MD (8236.78 TVD, 0.11 N, -20.00 E)										
- Point										
SCDMC 1H BHL		0.00	0.00	8,784.90	25.10	-4,609.70	529,942.70	535,263.40	32.457	-104.219
- plan hits target center										
- Rectangle (sides W0.00 H3,893.57 D40.00)										

Stewart, David

To: Dennis Hughes
Subject: RE: SIMPSON-CDM COM WATER WELLS

From: Dennis Hughes [<mailto:dwhughes@horizonsurvey.com>]
Sent: Monday, January 27, 2014 10:27 AM
To: Weaver, Calvin C.(Dusty); Stewart, David
Cc: dwhughes
Subject: SIMPSON-CDM COM WATER WELLS

WATER WELL C-01644 (APPROX. 668' FNL X 664' FWL SECTION) IS 314' EAST OF THE EOT AND 268' SOUTH OF THE HORIZONTAL WELL BORE FOR THIS WELL.

WATER WELL C-01649 (APPROX. 1000' FNL X 333' FWL SECTION) IS 17' WEST AND 600' SOUTH OF THE EOT FOR THIS WELL.

THESE ARE THE ONLY WELLS CLOSE TO THIS WELLBORE.

DUSTY, HERE ARE THE WATER WELL COORDINATES IN NM-E NAD27 FEET.

DENNIS W. HUGHES
713.805.1757 CELL
281.855.6200 OFFICE
HORIZON SURVEY, INC.
16840 CLAY RD SUITE 111
HOUSTON, TEXAS 77084

From: Weaver, Calvin C.(Dusty)
Sent: Saturday, January 25, 2014 3:29 PM
To: Stewart, David
Subject: RE: SIMPSON-CDM COM #1H (EXP) Needs NM Fee APD Submission

David,

This well is outside the city limits and we did not find any water wells within 300'.....

Calvin C. (Dusty) Weaver
Cell.: 806-893-3067
Office: 432-685-5723

From: Stewart, David
Sent: Thursday, January 23, 2014 2:27 PM
To: Weaver, Calvin C.(Dusty); Wilson, Jim B (RWI Construction Inc); Dyer, Whitney L
Cc: Duplantis, Michael J; Wolf, Jason D; Khalilov, Anar; Millan, Sebastian; Steel, Brittany A; Havins, Donna; Hodge, Mark
Subject: RE: SIMPSON-CDM COM #1H (EXP) Needs NM Fee APD Submission

Dusty/Jim, need to know if this well is located in the Carlsbad city limits? If so have they been notified? Any water wells with 300'? If so how many?

Thanks, David S.
Wk - 432-685-5717

simpsoncdm_com_waterwells

HORIZON SURVEY, INC.
16840 CLAY RD SUITE 111
HOUSTON, TEXAS 77084
281-855-6200

Monday, January 27, 2014 10:14:42 AM

PROJECT: s2012\Documents\2013 shared\TERRAMODEL PRO\2009
PRO\NM445000POTASH.pro

--				
Point Coordinates Listing				
Point	North	East	Elev	Name

1171	527681.498692	537575.449143	*	c00096
1172	526061.594826	537906.596272	*	c00222
1173	527372.714814	536575.887938	*	c00552
1174	527361.316227	535250.021964	*	c00606
1175	526700.915545	535902.219725	*	c00634
1176	526068.890350	539888.767375	*	c00652
1177	526057.491071	538562.903691	*	c00673
1178	527368.610698	537232.195876	*	c00688
1179	528020.133218	535900.637585	*	c00725
1180	528024.237512	535244.329182	*	c00741
1181	525393.077054	537232.949444	*	c00749
1182	526061.594826	537906.596272	*	c00767
1183	527681.498692	537575.449143	*	c00779, c00781, c00888
1184	526049.373252	537237.059735	*	c00943
1185	525397.180625	536576.641667	*	c001038
1186	528353.594660	535577.840964	*	c001047
1187	526705.019475	535245.911430	*	c001068
1188	528024.237512	535244.329182	*	c001069
1189	529009.047719	536241.562510	*	c001087
1191	525397.180625	536576.641667	*	c01096
1192	525397.180625	536576.641667	*	c01101
1193	527034.376804	535579.422952	*	c01155
1194	528680.534269	535248.440123	*	c01174
1195	528024.237512	535244.329182	*	c01248
1196	528680.534269	535248.440123	*	c01299
1197	527045.775569	536905.288665	*	c01321
1198	529343.455566	535242.747751	*	c01553
1199	529672.812532	535576.259793	*	c01644
1200	529343.455566	535242.747751	*	c01649
1201	525746.055410	539561.860715	*	c01650
1202	528365.013212	536900.425366	*	c01653
1203	528353.594660	535577.840964	*	c01662
1204	527681.498692	537575.449143	*	c01709
1205	527045.775569	536905.288665	*	c01755
1206	525734.655948	538235.996883	*	c01947
1207	527045.775569	536905.288665	*	c02045
1208	526042.077682	535254.886164	*	c02471
1209	526705.019475	535245.911430	*	c02530
1210	526068.890350	539888.767375	*	c02645
1211	526068.890350	539888.767375	*	c02837
1212	526350.000487	536392.272264	*	c03171
1213	522259.407685	536140.221599	*	c03335
1214	527144.712500	536827.148316	*	c03614 pod1



New Mexico Office of the State Engineer

Water Column/Average Depth to Water



























(A CLW##### in the
POD suffix indicates the
POD has been replaced
& no longer serves a
water right file.)

(R=POD has
been replaced,
O=orphaned,
C=the file is
closed)

(quarters are 1=NW 2=NE 3=SW 4=SE)

(quarters are smallest to largest) (NAD83 UTM in meters)

(In feet)

POD														
Sub-		Q Q Q										Depth Depth Water		
POD Number	Code basin	County	64	16	4	Sec	Tws	Rng	X	Y	Well	Water	Column	
C 00096		ED				29	21S	27E	574063	3590675*		91		
C 00222		ED	1	3	4	29	21S	27E	574167	3590182*		297		
C 00552	C	ED	1	2	3	29	21S	27E	573759	3590579		240	24	216
C 00606	C	ED	1	1	3	29	21S	27E	573355	3590573*		252	8	244
C 00634	C	ED	4	1	3	29	21S	27E	573555	3590373*		122	17	105
C 00652		ED	2	4	4	29	21S	27E	574771	3590188*		458		
C 00673	C	ED	2	3	4	29	21S	27E	574367	3590182*		309	30	279
C 00688	C	ED	2	2	3	29	21S	27E	573959	3590579*		90	31	59
C 00725	C	ED	4	3	1	29	21S	27E	573552	3590775*		222	22	200
C 00741	C	ED	3	3	1	29	21S	27E	573352	3590775*				
C 00749	C	ED	4	4	3	29	21S	27E	573963	3589977*				
C 00767		ED	1	3	4	29	21S	27E	574167	3590182*		150	26	124
C 00779	C	ED				29	21S	27E	574063	3590675*		247	18	229
C 00781	C	ED				29	21S	27E	574063	3590675*		302	29	273
C 00888	C	ED				29	21S	27E	574063	3590675*		270	12	258
C 00943	C	ED	2	4	3	29	21S	27E	573963	3590177*		280	27	253
C 01038	C	ED	3	4	3	29	21S	27E	573763	3589977*		293	14	279
C 01047		ED		3	1	29	21S	27E	573453	3590876*		288	256	32
C 01068	C	ED	3	1	3	29	21S	27E	573355	3590373*		350	20	330
C 01069	C	ED	3	3	1	29	21S	27E	573352	3590775*		355	20	335
C 01087	C	ED			1	29	21S	27E	573654	3591077*		310	16	294
C 01096	C	ED	3	4	3	29	21S	27E	573763	3589977*		306	17	289
C 01101	C	ED	3	4	3	29	21S	27E	573763	3589977*		315	17	298
C 01155	C	ED		1	3	29	21S	27E	573456	3590474*		290	22	268
C 01174	C	ED	1	3	1	29	21S	27E	573352	3590975*		280	27	253
C 01248	C	ED	3	3	1	29	21S	27E	573352	3590775*		240	19	221

*UTM location was derived from PLSS - see Help




















(A CLW##### in the
POD suffix indicates the
POD has been replaced
& no longer serves a
water right file.)

(R=POD has
been replaced,
O=orphaned,
C=the file is
closed)

(quarters are 1=NW 2=NE 3=SW 4=SE)

(quarters are smallest to largest) (NAD83 UTM in meters)

(In feet)

POD Number	POD		Q Q Q							X	Y	Depth Well	Depth Water	Water Column
	Sub-Code	basin	County	64	16	4	Sec	Tws	Rng					
C 01299	C	ED	1	3	1	29	21S	27E	573352	3590975*		284	23	261
C 01321	C	LE	2	3	29	21S	27E	573860	3590480*		270	60	210	
C 01553	C	ED	3	1	1	29	21S	27E	573349	3591177*		84		
C 01644	C	ED	1	1	29	21S	27E	573450	3591278*		66	35	31	
C 01649	C	ED	3	1	1	29	21S	27E	573349	3591177*		88	25	63
C 01650	C	ED	4	4	29	21S	27E	574672	3590089*		45			
C 01653	C	ED	4	1	29	21S	27E	573856	3590882*		60	20	40	
C 01662	C	ED	3	1	29	21S	27E	573453	3590876*		40			
C 01709	C	ED				29	21S	27E	574063	3590675*		42	15	27
C 01755	C	ED	2	3	29	21S	27E	573860	3590480*		320	17	303	
C 01947	C	ED	3	4	29	21S	27E	574268	3590083*		43	18	25	
C 02045	C	ED	2	3	29	21S	27E	573860	3590480*		80	29	51	
C 02471	C	ED	1	3	3	29	21S	27E	573359	3590171*		120	50	70
C 02530	C	ED	3	1	3	29	21S	27E	573355	3590373*		30	17	13
C 02645	C	ED	2	4	4	29	21S	27E	574771	3590188*		195	45	150
C 02837	C	ED	2	4	4	29	21S	27E	574771	3590188*		179	155	24
C 03171	C	ED	3	2	3	29	21S	27E	573705	3590267		100	31	69
C 03335	C	ED	4	1	3	29	21S	27E	573636	3589020		225	31	194
C 03614 POD1	C	ED	1	2	3	29	21S	27E	573836	3590510		228	30	198

Average Depth to Water: **34 feet**

Minimum Depth: **8 feet**

Maximum Depth: **256 feet**

Record Count: 45

PLSS Search:

Section(s): 29

Township: 21S

Range: 27E

*UTM location was derived from PLSS - see Help

The data is furnished by the NMOSE/ISC and is accepted by the recipient with the expressed understanding that the OSE/ISC make no warranties, expressed or implied, concerning the accuracy, completeness, reliability, usability, or suitability for any particular purpose of the data.



Permian Drilling Hydrogen Sulfide Drilling Operations Plan New Mexico

Scope

This contingency plan establishes guidelines for the public, all company employees, and contract employees who's work activities may involve exposure to hydrogen sulfide (H₂S) gas.

While drilling this well, it is possible to encounter H₂S bearing formations. At all times, the first barrier to control H₂S emissions will be the drilling fluid, which will have a density high enough to control influx.

Objective

1. Provide an immediate and predetermined response plan to any condition when H₂S is detected. All H₂S detections in excess of 10 parts per million (ppm) concentration are considered an Emergency.
2. Prevent any and all accidents, and prevent the uncontrolled release of hydrogen sulfide into the atmosphere.
3. Provide proper evacuation procedures to cope with emergencies.
4. Provide immediate and adequate medical attention should an injury occur.

Discussion

Implementation:	This plan with all details is to be fully implemented before drilling to <u>commence</u> .
Emergency response Procedure:	This section outlines the conditions and denotes steps to be taken in the event of an emergency.
Emergency equipment Procedure:	This section outlines the safety and emergency equipment that will be required for the drilling of this well.
Training provisions:	This section outlines the training provisions that must be adhered to prior to drilling.
Drilling emergency call lists:	Included are the telephone numbers of all persons to be contacted should an emergency exist.
Briefing:	This section deals with the briefing of all people involved in the drilling operation.
Public safety:	Public safety personnel will be made aware of any potential evacuation and any additional support needed.
Check lists:	Status check lists and procedural check lists have been included to insure adherence to the plan.
General information:	A general information section has been included to supply support information.

Hydrogen Sulfide Training

All personnel, whether regularly assigned, contracted, or employed on an unscheduled basis, will receive training from a qualified instructor in the following areas prior to commencing drilling operations on the well:

1. The hazards and characteristics of H₂S.
2. Proper use and maintenance of personal protective equipment and life support systems.
3. H₂S detection.
4. Proper use of H₂S detectors, alarms, warning systems, briefing areas, evacuation procedures and prevailing winds.
5. Proper techniques for first aid and rescue procedures.
6. Physical effects of hydrogen sulfide on the human body.
7. Toxicity of hydrogen sulfide and sulfur dioxide.
8. Use of SCBA and supplied air equipment.
9. First aid and artificial respiration.
10. Emergency rescue.

In addition, supervisory personnel will be trained in the following areas:

1. The effects of H₂S on metal components. If high tensile strength tubular is to be used, personnel will be trained in their special maintenance requirements.
2. Corrective action and shut-in procedures when drilling a well, blowout prevention and well control procedures.
3. The contents and requirements of the H₂S Drilling Operations Plan.

H₂S training refresher must have been taken within one year prior to drilling the well. Specifics on the well to be drilled will be discussed during the pre-spud meeting. H₂S and well control (choke) drills will be performed while drilling the well, at least on a weekly basis. This plan shall be available in the well site. All personnel will be required to carry the documentation proving that the H₂S training has been taken.

Service company and visiting personnel

- A. Each service company that will be on this well will be notified if the zone contains H₂S.
- B. Each service company must provide for the training and equipment of their employees before they arrive at the well site.
- C. Each service company will be expected to attend a well site briefing

Emergency Equipment Requirements

1. Well control equipment

The well shall have hydraulic BOP equipment for the anticipated pressures. Equipment is to be tested on installation and follow Oxy Well Control standard, as well as BLM Onshore Order #2.

Special control equipment:

- A. Hydraulic BOP equipment with remote control on ground. Remotely operated choke.
- B. Rotating head
- C. Gas buster equipment shall be installed before drilling out of surface pipe.

2. Protective equipment for personnel

- A. Four (4) 30-minute positive pressure air packs (2 at each briefing area) on location.
- B. Adequate fire extinguishers shall be located at strategic locations.
- C. Radio / cell telephone communication will be available at the rig.
 - Rig floor and trailers.
 - Vehicle.

3. Hydrogen sulfide sensors and alarms

- A. H₂S sensor with alarms will be located on the rig floor, at the bell nipple, and at the flow line. These monitors will be set to alarm at 10 ppm with strobe light, and audible alarm.
- B. Hand operated detectors with tubes.
- C. H₂S monitor tester (to be provided by contract Safety Company.)
- D. There shall be one combustible gas detector on location at all times.

4. Visual Warning Systems

- A. One sign located at each location entrance with the following language:

**Caution – potential poison gas
Hydrogen sulfide
No admittance without authorization**

Wind sock – wind streamers:

- A. One 36" (in length) wind sock located at protection center, at height visible from rig floor.
- B. One 36" (in length) wind sock located at height visible from pit areas.

Condition flags

- A. One each condition flag to be displayed to denote conditions.

green – normal conditions

yellow – potential danger

red – danger, H₂S present

- B. Condition flag shall be posted at each location sign entrance.

5. Mud Program

The mud program is designed to minimize the risk of having H₂S and other formation fluids at surface. Proper mud weight and safe drilling practices will be applied. H₂S scavengers will be used to minimize the hazards while drilling. Below is a summary of the drilling program.

Mud inspection devices:

Garrett gas train or hatch tester for inspection of sulfide concentration in mud system.

6. Metallurgy

- A. Drill string, casing, tubing, wellhead, blowout preventers, drilling spools or adapters, kill lines, choke manifold, lines and valves shall be suitable for the H₂S service.
- B. All the elastomers, packing, seals and ring gaskets shall be suitable for H₂S service.

7. Well Testing

No drill stem test will be performed on this well.

8. Evacuation plan

Evacuation routes should be established prior to well spud for each well and discussed with all rig personnel.

9. Designated area

- A. Parking and visitor area: all vehicles are to be parked at a predetermined safe distance from the wellhead.
- B. There will be a designated smoking area.
- C. Two briefing areas on either side of the location at the maximum allowable distance from the well bore so they offset prevailing winds perpendicularly, or at a 45-degree angle if wind direction tends to shift in the area.

Emergency procedures

- A. In the event of any evidence of H₂S level above 10 ppm, take the following steps:
 - 1. The Driller will pick up off bottom, shut down the pumps, slow down the pipe rotation.
 - 2. Secure and don escape breathing equipment, report to the upwind designated safe briefing / muster area.
 - 3. All personnel on location will be accounted for and emergency search should begin for any missing, the Buddy System will be implemented.
 - 4. Order non-essential personnel to leave the well site, order all essential personnel out of the danger zone and upwind to the nearest designated safe briefing / muster area.
 - 5. Entrance to the location will be secured to a higher level than our usual "Meet and Greet" requirement, and the proper condition flag will be displayed at the entrance to the location.
 - 6. Take steps to determine if the H₂S level can be corrected or suppressed and, if so, proceed as required.
- B. If uncontrollable conditions occur:
 - 1. Take steps to protect and/or remove any public in the down-wind area from the rig – partial evacuation and isolation. Notify necessary public safety personnel and appropriate regulatory entities (i.e. BLM) of the situation.

2. Remove all personnel to the nearest upwind designated safe briefing / muster area or off location.
3. Notify public safety personnel of safe briefing / muster area.
4. An assigned crew member will blockade the entrance to the location. No unauthorized personnel will be allowed entry to the location.
5. Proceed with best plan (at the time) to regain control of the well. Maintain tight security and safety procedures.

C. Responsibility:

1. Designated personnel.
 - a. Shall be responsible for the total implementation of this plan.
 - b. Shall be in complete command during any emergency.
 - c. Shall designate a back-up.

- | | |
|---------------------|--|
| All personnel: | <ol style="list-style-type: none"> 1. On alarm, don escape unit and report to the nearest upwind designated safe briefing / muster area upw 2. Check status of personnel (buddy system). 3. Secure breathing equipment. 4. Await orders from supervisor. |
| Drill site manager: | <ol style="list-style-type: none"> 1. Don escape unit if necessary and report to nearest upwind designated safe briefing / muster area. 2. Coordinate preparations of individuals to return to point of release with tool pusher and driller (using the buddy system). 3. Determine H2S concentrations. 4. Assess situation and take control measures. |
| Tool pusher: | <ol style="list-style-type: none"> 1. Don escape unit Report to up nearest upwind designated safe briefing / muster area. 2. Coordinate preparation of individuals to return to point of release with tool pusher drill site manager (using the buddy system). 3. Determine H2S concentration. 4. Assess situation and take control measures. |
| Driller: | <ol style="list-style-type: none"> 1. Don escape unit, shut down pumps, continue |

- rotating DP.
- 2. Check monitor for point of release.
- 3. Report to nearest upwind designated safe briefing / muster area.
- 4. Check status of personnel (in an attempt to rescue, use the buddy system).
- 5. Assigns least essential person to notify Drill Site Manager and tool pusher by quickest means in case of their absence.
- 6. Assumes the responsibilities of the Drill Site Manager and tool pusher until they arrive should they be absent.

Derrick man
Floor man #1
Floor man #2

- 1. Will remain in briefing / muster area until instructed by supervisor.

Mud engineer:

- 1. Report to nearest upwind designated safe briefing / muster area.
- 2. When instructed, begin check of mud for ph and H2S level. (Garett gas train.)

Safety personnel:

- 1. Mask up and check status of all personnel and secure operations as instructed by drill site manager.

Taking a kick

When taking a kick during an H2S emergency, all personnel will follow standard Well control procedures after reporting to briefing area and masking up.

Open-hole logging

All unnecessary personnel off floor. Drill Site Manager and safety personnel should monitor condition, advise status and determine need for use of air equipment.

Running casing or plugging

Following the same “tripping” procedure as above. Drill Site Manager and safety personnel should determine if all personnel have access to protective equipment.

Ignition procedures

The decision to ignite the well is the responsibility of the operator (Oxy Drilling Management). The decision should be made only as a last resort and in a situation where it is clear that:

1. Human life and property are endangered.
2. There is no hope controlling the blowout under the prevailing conditions at the well.

Instructions for igniting the well

1. Two people are required for the actual igniting operation. They must wear self-contained breathing units and have a safety rope attached. One man (tool pusher or safety engineer) will check the atmosphere for explosive gases with the gas monitor. The other man is responsible for igniting the well.
2. Primary method to ignite: 25 mm flare gun with range of approximately 500 feet.
3. Ignite upwind and do not approach any closer than is warranted.
4. Select the ignition site best for protection, and which offers an easy escape route.
5. Before firing, check for presence of combustible gas.
6. After lighting, continue emergency action and procedure as before.
7. All unassigned personnel will remain in briefing area until instructed by supervisor or directed by the Drill Site Manager.

Remember: After well is ignited, burning hydrogen sulfide will convert to sulfur dioxide, which is also highly toxic. **Do not assume the area is safe after the well is ignited.**

Status check list

Note: All items on this list must be completed before drilling to production casing point.

1. H2S sign at location entrance.
2. Two (2) wind socks located as required.
3. Four (4) 30-minute positive pressure air packs (2 at each Briefing area) on location for all rig personnel and mud loggers.
4. Air packs inspected and ready for use.
5. Cascade system and hose line hook-up as needed.
6. Cascade system for refilling air bottles as needed.
7. Condition flag on location and ready for use.
8. H2S detection system hooked up and tested.
9. H2S alarm system hooked up and tested.
10. Hand operated H2S detector with tubes on location.
11. 1 – 100' length of nylon rope on location.
12. All rig crew and supervisors trained as required.
13. All outside service contractors advised of potential H2S hazard on well.
14. No smoking sign posted and a designated smoking area identified.
15. Calibration of all H2S equipment shall be noted on the IADC report.

Checked by: _____ Date: _____

Procedural check list during H2S events

Perform each tour:

1. Check fire extinguishers to see that they have the proper charge.
2. Check breathing equipment to ensure that it is in proper working order.
3. Make sure all the H2S detection system is operative.

Perform each week:

1. Check each piece of breathing equipment to make sure that demand or forced air regulator is working. This requires that the bottle be opened and the mask assembly be put on tight enough so that when you inhale, you receive air or feel air flow.
2. BOP skills (well control drills).
3. Check supply pressure on BOP accumulator stand by source.
4. Check breathing equipment mask assembly to see that straps are loosened and turned back, ready to put on.
5. Check pressure on breathing equipment air bottles to make sure they are charged to full volume. (Air quality checked for proper air grade "D" before bringing to location)
6. Confirm pressure on all supply air bottles.
7. Perform breathing equipment drills with on-site personnel.
8. Check the following supplies for availability.
 - A. Emergency telephone list.
 - B. Hand operated H2S detectors and tubes.

General evacuation plan

1. When the company approved supervisor (Drill Site Manager, consultant, rig pusher, or driller) determines the H₂S gas cannot be limited to the well location and the public will be involved, he will activate the evacuation plan.
2. Drill Site Manager or designee will notify local government agency that a hazardous condition exists and evacuation needs to be implemented.
3. Company or contractor safety personnel that have been trained in the use of H₂S detection equipment and self-contained breathing equipment will monitor H₂S concentrations, wind directions, and area of exposure. They will delineate the outer perimeter of the hazardous gas area. Extension to the evacuation area will be determined from information gathered.
4. Law enforcement personnel (state police, police dept., fire dept., and sheriff's dept.) Will be called to aid in setting up and maintaining road blocks. Also, they will aid in evacuation of the public if necessary.
5. After the discharge of gas has been controlled, company safety personnel will determine when the area is safe for re-entry.

Important: Law enforcement personnel will not be asked to come into a contaminated area. Their assistance will be limited to uncontaminated areas. Constant radio contact will be maintained with them.

Emergency actions

Well blowout – if emergency

1. Evacuate all personnel to “Safe Briefing / Muster Areas” or off location if needed.
2. If sour gas – evacuate rig personnel.
3. If sour gas – evacuate public within 3000 ft radius of exposure.
4. Don SCBA and shut well in if possible using the buddy system.
5. Notify Drilling Superintendent and call 911 for emergency help (fire dept and ambulance) if needed.
6. Implement the Blowout Contingency Plan, and Drilling Emergency Action Plan.
6. Give first aid as needed.

Person down location/facility

1. If immediately possible, contact 911. Give location and wait for confirmation.
2. Don SCBA and perform rescue operation using buddy system.

Toxic effects of hydrogen sulfide

Hydrogen sulfide is extremely toxic. The acceptable ceiling concentration for eight-hour exposure is 10 ppm, which is .001% by volume. Hydrogen sulfide is heavier than air (specific gravity – 1.192) and colorless. It forms an explosive mixture with air between 4.3 and 46.0 percent by volume. Hydrogen sulfide is almost as toxic as hydrogen cyanide and is between five and six times more toxic than carbon monoxide. Toxicity data for hydrogen sulfide and various other gases are compared in table i. Physical effects at various hydrogen sulfide exposure levels are shown in table ii.

Table i
Toxicity of various gases

Common name	Chemical formula	Specific gravity (sc=1)	Threshold limit (1)	Hazardous limit (2)	Lethal concentration (3)
Hydrogen Cyanide	Hcn	0.94	10 ppm	150 ppm/hr	300 ppm
Hydrogen Sulfide	H2S	1.18	10 ppm	250 ppm/hr	600 ppm
Sulfur Dioxide	So2	2.21	5 ppm	-	1000 ppm
Chlorine	Cl2	2.45	1 ppm	4 ppm/hr	1000 ppm
Carbon Monoxide	Co	0.97	50 ppm	400 ppm/hr	1000 ppm
Carbon Dioxide	Co2	1.52	5000 ppm	5%	10%
Methane	Ch4	0.55	90,000 ppm	Combustible above 5% in air	

- 1) threshold limit – concentration at which it is believed that all workers may be repeatedly exposed day after day without adverse effects.
- 2) hazardous limit – concentration that will cause death with short-term exposure.
- 3) lethal concentration – concentration that will cause death with short-term exposure.

Toxic effects of hydrogen sulfide

Table ii
Physical effects of hydrogen sulfide

<u>Percent (%)</u>	<u>Ppm</u>	<u>Concentration</u> Grains 100 std. Ft3*	<u>Physical effects</u>
0.001	<10	00.65	Obvious and unpleasant odor.

0.002	10	01.30	Safe for 8 hours of exposure.
0.010	100	06.48	Kill smell in 3 – 15 minutes. May sting eyes and throat.
0.020	200	12.96	Kills smell shortly; stings eyes and throat.
0.050	500	32.96	Dizziness; breathing ceases in a few minutes; needs prompt artificial respiration.
0.070	700	45.36	Unconscious quickly; death will result if not rescued promptly.
0.100	1000	64.30	Unconscious at once; followed by death within minutes.

*at 15.00 psia and 60'f.

Use of self-contained breathing equipment (SCBA)

1. Written procedures shall be prepared covering safe use of SCBA's in dangerous atmosphere, which might be encountered in normal operations or in emergencies. Personnel shall be familiar with these procedures and the available SCBA.
2. SCBA's shall be inspected frequently at random to insure that they are properly used, cleaned, and maintained.
3. Anyone who may use the SCBA's shall be trained in how to insure proper face-piece to face seal. They shall wear SCBA's in normal air and then wear them in a test atmosphere. (note: such items as facial hair {beard or sideburns} and eyeglasses will not allow proper seal.) Anyone that may be reasonably expected to wear SCBA's should have these items removed before entering a toxic atmosphere. A special mask must be obtained for anyone who must wear eyeglasses or contact lenses.
4. Maintenance and care of SCBA's:
 - a. A program for maintenance and care of SCBA's shall include the following:
 1. Inspection for defects, including leak checks.
 2. Cleaning and disinfecting.
 3. Repair.
 4. Storage.
 - b. Inspection, self-contained breathing apparatus for emergency use shall be inspected monthly.
 1. Fully charged cylinders.
 2. Regulator and warning device operation.
 3. Condition of face piece and connections.
 4. Rubber parts shall be maintained to keep them pliable and prevent deterioration.
 - c. Routinely used SCBA's shall be collected, cleaned and disinfected as frequently as necessary to insure proper protection is provided.
5. Persons assigned tasks that requires use of self-contained breathing equipment shall be certified physically fit (medically cleared) for breathing equipment usage at least annually.
6. SCBA's should be worn when:
 - A. Any employee works near the top or on top of any tank unless test reveals less than 10 ppm of H₂S.

- B. When breaking out any line where H₂S can reasonably be expected.
- C. When sampling air in areas to determine if toxic concentrations of H₂S exists.
- D. When working in areas where over 10 ppm H₂S has been detected.
- E. At any time there is a doubt as to the H₂S level in the area to be entered.

Rescue
First aid for H₂S poisoning

Do not panic!

Remain calm – think!

1. Don SCBA breathing equipment.
2. Remove victim(s) utilizing buddy system to fresh air as quickly as possible. (go up-wind from source or at right angle to the wind. Not down wind.)
3. Briefly apply chest pressure – arm lift method of artificial respiration to clean the victim's lungs and to avoid inhaling any toxic gas directly from the victim's lungs.
4. Provide for prompt transportation to the hospital, and continue giving artificial respiration if needed.
5. Hospital(s) or medical facilities need to be informed, before-hand, of the possibility of H₂S gas poisoning – no matter how remote the possibility is.
6. Notify emergency room personnel that the victim(s) has been exposed to H₂S gas.

Besides basic first aid, everyone on location should have a good working knowledge of artificial respiration.

Revised CM 6/27/2012