	•		OCD Artesi	а			
Form 3160-5 (August 2007) B SUNDRY Do not use th abandoned we	ELLS -enter an		FORM APPROVED OMB NO. 1004-0135 Expires: July 31, 2010 5. Lease Serial No. NMNM043625 6. If Indian, Allottee or Tribe Name				
SUBMIT IN TRIPLICATE - Other instructions on reverse side.					7. If Unit or CA/Agre	cement, Name and/or No.	
1. Type of Well					8. Well Name and No. SAGUARO AGS FEDERAL 3		
Oil Well Gas Well Other     Contact: TINA HUERTA     YATES PETROLEUM CORPORATIONE-Mail: tinah@yatespetroleum.com					9. API Well No. 30-015-20396		
3a. Address 105 SOUTH FOURTH STREE ARTESIA, NM 88210	3b. Phone No. (include area code) Ph: 575-748-4168 Fx: 575-748-4585			10. Field and Pool, or Exploratory SOUTH DAGGER DRAW UP			
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Sec 26 T20S R24E SENW 1980FNL 1980FWL					11. County or Parish, and State EDDY COUNTY, NM		
12. CHECK APPI	ROPRIATE BOX(ES) TO	INDICATI	NATURE OF	NOTICE, RE	EPORT, OR OTHE	R DATA	
TYPE OF SUBMISSION	TYPE OF ACTION						
If the proposal is to deepen direction Attach the Bond under which the wor following completion of the involved	onally or recomplete horizontally, give su work will be performed or provide the Bo ved operations. If the operation results in		pen       Production (Start/Resume)         ture Treat       Reclamation         Construction       Recomplete         and Abandon       Temporarily Abandon         Back       Water Disposal         ng estimated starting date of any proposed work and approlocations and measured and true vertical depths of all pertining file with BL/MBIA. Required subsequent reports shall be ecompletion or recompletion in a new interval, a Form 31 requirements, including reclamation, have been completed.		nent markers and zones. filed within 30 days 0-4 shall be filed once		
determined that the site is ready for fr Yates Petroleum Corporation 1. NU BOP. RU all safety eq casing is cemented to surface 2. Set a 7 inch CIBP at 7558 3. Engineer Calc TOC 5534 ft are going to perf at each plug drilled by Conoco). 4. Perf 4 shots at 5465 ft. Pre 45 sx Class C cement plug ins pressure, spot a 170 ft plug ins necessary. This will place a p 5. Perf 4 shots at 5000 ft. Pre	nal inspection.) plans to plug and abandor upment as needed. No cr <b>Not Cenated</b> t and cap it with 25 sx Cla , no logs or records of a C to ensure that cement is p pessure up on casing to 500 ide and outside casing from side the casing from 5295 lug across Wolfcamp top.	this well as asing recove to Sur- ss H cemen BL could be resent behir psi. If we c m 5295 ft - ft - 5465 ft.	follows: ry will be attemp for c c found, so from f d the casing (we can pump into pe 5465 ft. If the ca WOC and tag; re	here on out w here on out w ell originally erfs spot a sing holds eset if	ction <b>Reclamat</b> /e SEE ATTAC CONDITION	TON PROCEDURE	
14. I hereby certify that the foregoing is	true and correct. Electronic Submission #2 For YATES PETRO						
Name(Printed/Typed) TINA HUERTA			Title REG REPORTING SUPERVISOR				
· Signature (Electronic S	ubmission)		Date 03/18/2	015		· · ·	
	THIS SPACE FO	R FEDERA	L OR STATE	OFFICE US	E	· · · · · · · · · · · · · · · · · · ·	
Approved By frames onditions of approval, if any, are attached rule that the applicant holds legal or equiptich, would envite the applicant to condu	. Approval of this notice does n itable title to those rights in the s			SPET 160	-	5-5-15 Date	
ith 18 U.S.C. Section 1001 and Title 43 1 States any false, fictitious or fraudulent s	J.S.C. Section 1212, make it a c	rime for any pe pany matter wi	rson knowingly and		e to any department or a	agency of the United	
** OPERAT	OB-SUBMITTED ** OP	FRATOR-				**	

18.0

DIVITIED

### Additional data for EC transaction #295454 that would not fit on the form

#### 32. Additional remarks, continued


a 45 sx Class C cement plug inside and outside casing from 4830 ft - 5000 ft. If the casing holds pressure, spot a 170 ft plug inside and outside casing from 4830 ft - 5000 ft. WOC and tag; reset


pressure, spot a 170 ft plug inside and outside casing from 4830 ft - 5000 ft. WOC and tag; reset if necessary. This will place a plug across Abo top.
6. Perf 4 shots at 3570 ft. Pressure up on the casing to 500 psi. If we can pump into perfs spot a 45 sx Class C cement plug inside and outside casing from 3400 ft - 3570 ft. If the casing holds pressure, spot a 170 ft plug inside casing from 3400 ft - 3570 ft. WOC and tag; reset if necessary. This will be a spacer plug to stay within the 2000 ft limit for non-cemented casing.
7. Perf 4 shots at 2140 ft. Pressure up on casing to 500 psi. If we can pump into perfs spot a 45 sx Class C cement plug inside and outside casing from 1970 ft - 2140 ft. If the casing holds pressure, spot a 170 ft plug inside the casing from 1970 ft - 2140 ft. WOC and tag; reset if pressure, spot a 170 ft plug inside the casing from 1970 ft - 2140 ft. WOC and tag; reset if pressure, spot a 170 ft plug inside the casing from 1970 ft - 2140 ft. WOC and tag; reset if pressure, spot a 170 ft plug inside the casing from 1970 ft - 2140 ft. WOC and tag; reset if pressure is a 170 ft plug inside the casing from 1970 ft - 2140 ft. WOC and tag; reset if pressure.

B. Perf 4 shots at 1027 ft. Pressure up on casing from 857 ft - 1027 ft. WOC and tag; reset if necessary. This will place a plug across Glorieta top.
B. Perf 4 shots at 1027 ft. Pressure up on casing to 500 psi. If we can pump into perfs spot a 45 sx Class C cement plug inside and outside casing from 857 ft - 1027 ft. If the casing holds pressure, spot a 170 ft plug inside the casing from 857 ft - 1027 ft. WOC and tag; reset if necessary. This will place a plug across surface casing shoe.
Perf 4 shots at 170 ft. Pressure up on casing to 500 psi. If we can pump into perfs spot a 45 we can pump into perfs performed account plus and autopart plus performed account plus account

sx Class C cement plug inside and outside casing from surface to 170 ft. If the casing holds pressure, spot a 170 ft plug inside the casing from 0 - 170 ft. WOC and tag; reset if necessary. This will place a plug at surface.

10. Remove all surface equipment and weld dry hole marker per regulations. Wellbore schematics attached





## BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

## Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>minety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90<sup>th</sup> day provide this office, prior to the 90<sup>th</sup> day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. <u>Notification</u>: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.

3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.

5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10<sup>th</sup> day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. <u>Show date well was plugged.</u>

8. <u>Trash</u>: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

J. Arnos 3/6/11



# United States Department of the Interior

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

#### Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

#### Jim Amos Supervisory Petroleum Engineering Tech 575-234-5909, 575-361-2648 (Cell)

Solomon Hughes Natural Resource Specialist 575-234-5951

Jeffery Robertson Natural Resource Specialist 575-234-2230

Duncan Whitlock Environmental Protection Specialist 575-234-5926

Linda Denniston Environmental Protection Specialist 575-234-5974

Douglas Hoag Civil Engineering Tech 575-234-5979 Cody Layton Supervisory Multi Resources 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612