

Submit 1 Copy To Appropriate District Office
 District I - (575) 393-6161
 1075 N. French Dr., Hobbs, NM 88240
 District II - (575) 748-1283
 811 S. First St., Artesia, NM 88210
 District III - (505) 334-6178
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV - (505) 476-3460
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
 Energy, Minerals and Natural Resources
NM OIL CONSERVATION
 ARTESIA DISTRICT
OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505
RECEIVED

Form C-103
 Revised July 18, 2013

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other		WELL API NO. 30-015-25630 5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/> 6. State Oil & Gas Lease No.
2. Name of Operator Yates Petroleum Corporation		7. Lease Name or Unit Agreement Name Molly QD Com 8. Well Number 1
3. Address of Operator 105 South Fourth Street, Artesia, NM 88210		9. OGRID Number 025575 10. Pool name or Wildcat North Seven Rivers; Wolfcamp
4. Well Location Unit Letter <u>P</u> : <u>660</u> feet from the <u>South</u> line and <u>660</u> feet from the <u>East</u> line Section <u>13</u> Township <u>19S</u> Range <u>24E</u> NMPM <u>Eddy</u> County		
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3601'GR		

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Yates Petroleum Corporation plans to plug and abandon this well as follows:

- MIRU all safety equipment as needed. POOH with production equipment.
 - Spot a 25 sx Class "H" cement plug from 6944'-7144' across stage tool. - *WOC & TAG*
 - Set a 5-1/2" CIBP at 6010' and cap it with 25 sx Class "C" cement. - *WOC & TAG*
 - Load hole with plugging mud then spot a 25 sx Class "C" cement plug from 5203'-5403' across Wolfcamp top.
 - Perforate at 4110', then spot a 60 sx cement plug inside and outside the 5-1/2" casing. Displace the cement to 3910'. This will place a plug from 3910'-4110' across Abo top. WOC and tag, reset if necessary.
 - Perforate at 1922', then spot a 60 sx cement plug inside and outside the 5-1/2" casing. Displace the cement to 1722'. This will place a plug from 1722'-1922' across Glorieta top. WOC and tag, reset if necessary.
 - Perforate at 1150', then spot a 60 sx cement plug inside and outside the 5-1/2" casing. Displace the cement to 950'. This will place a plug from 950'-1150' across casing shoe. WOC and tag, reset if necessary.
 - Perforate at 445', then spot a 110 sx cement plug inside and outside the 5-1/2" casing. Do not displace the cement, this will place a plug from surface to 445' forming the shoe plug and surface plug. WOC and tag, reset if necessary.
 - Cut off wellhead, install dry hole marker and clean location.
- Wellbore schematics attached

Spud Date: Rig Release Date:

WELL MUST BE PLUGGED BY 10/4/2017

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Reporting Supervisor DATE September 29, 2016

Type or print name Tina Huerta E-mail address: tinah@yatespetroleum.com PHONE: 575-748-4168

For State Use Only

APPROVED BY: [Signature] TITLE COMPLIANCE OFFICER DATE 10/4/2016

Conditions of Approval (if any): **SEE ATTACHED COA-5**

Approved for plugging of well bore only.
 Authority under bond is retained pending receipt
 of the (Subsequent Report of Well Plugging)
 which may be found at OGD Web Page under
 Form: www.cmr.state.nm.us/oed.

WELL NAME: Molly QD Com #1 FIELD: Dagger Draw Upper Penn N.

LOCATION: 660' FSL & 660' FEL of Section 13-19S-24E Eddy Co., NM

GL: 3,601' GR ZERO: KB:'

SPUD DATE: 6/26/86 COMPLETION DATE: 9-23/86

COMMENTS: API No.: 30-015-25630


CASING PROGRAM

13-3/8" 59.45# J55		395'
8-5/8" 24# 32#		1100'
5-1/2" 17# N80	580'	
5-1/2" 17# J55	1,958'	
5-1/2" 15.5# J55	5,102'	
5-1/2" 17# J55	801'	
5-1/2" 17# N80	783'	9,212'

Before

TOPS


SA	470'
Glorieta	1,872'
Abo	4,060'
WC Lm	5,353'
Cisco	6,330'
Canyon Lm	7,545'
Strawn	8,141'
Atoka	8,596'
Miss Chester	9,132'
Canyon Dolo	7,702'
Strawn Mkr	8,458'
Morrow CI	8,894'
Chester	9,132'



Not to Scale
9/1/16
JMH

WELL NAME: Molly QD Com #1 **FIELD:** Dagger Draw Upper Penn N.
LOCATION: 660' FSL & 660' FEL of Section 13-19S-24E Eddy Co., NM
GL: 3,601' GR **ZERO:** **KB:** **CASING PROGRAM**
SPUD DATE: 6/26/86 **COMPLETION DATE:** 9-23/86
COMMENTS: API No.: 30-015-25630

13-3/8" 59.45# J55		395'
8-5/8" 24# 32#		1100'
5-1/2" 17# N80	580'	
5-1/2" 17# J55	1,958'	
5-1/2" 15.5# J55	5,102'	
5-1/2" 17# J55	801'	
5-1/2" 17# N80	783'	9,212'



After

TOPS

SA	470'
Glorieta	1,872'
Abo	4,060'
WC Lm	5,353'
Cisco	6,330'
Canyon Lm	7,545'
Strawn	8,141'
Atoka	8,596'
Miss Chester	9,132'
Canyon Dolo	7,702'
Strawn Mkr	8,458'
Morrow CI	8,894'
Chester	9,132'

Not to Scale
 9/1/16
 JMH

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
7. Produced water **will not** be used during any part of the plugging operation.
8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
10. **Class 'C' cement will be used above 7500 feet.**
11. **Class 'H' cement will be used below 7500 feet.**
12. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
13. **All Casing Shoes Will Be Perforated and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**
14. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
15. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

16. **When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set**
17. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
18. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
19. Any Production Formations will be isolated with cement plugs: Some of these are:
 - A) **Strawn, Fusselman, Devonian, Marrow, Atoka, Wolfcamp, Bone springs, Delaware, Abo, Glorieta, Any Salt Section, (Potash), Grayburg, Queen, Yates, Tubb, 7-Rivers**
 - B) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
20. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name
2. Lease and Well Number
3. API Number
4. Unit Letter
5. Quarter Section (feet from the North, South, East or West)
6. Section, Township and Range
7. Plugging Date
8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)