Swomit 1 Copy Office	To Appropriate District	Sta	State of New Mexico		Form C-103					
<u>District I</u> – (575) 393-6161		Energy, Mi	Energy, Minerals and Natural Resources		Revised July 18, 2013 WELL API NO.					
1625 N. French District II ~ (57)	Dr., Hobbs, NM 88240 5) 748-1283	OIL CONSERVATION DIVISION			30-015-29360					
811 S. First St.,	Artesia, NM 88210				5. Indicate Type of Lease					
<u>District III</u> – (50 1000 Rio Brazo	s Rd., Aztec, NM 87410		South St. Fran		STATE	☐ FEE ☒				
	strict IV = (505) 476-3460 Santa Fe, NM 8/505 20 S. St. Francis Dr., Santa Fe, NM					Gas Lease No.				
	SUNDRY NO		7. Lease Name	or Unit Agreement Name						
DIFFERENT R	THIS FORM FOR PRO ESERVOIR. USE "API	Bradshaw								
PROPOSALS.) 1. Type of V	Vell: Oil Well 🛛	8. Well Number								
2. Name of	Operator				9. OGRID Nun	003 nber				
	Smith & Marrs I	nc.			20989					
3. Address of		te. 33 Lubbock, TX	79424		10. Pool name or Wildcat Penasco Draw; Upper Penn					
4. Well Loc	<u> </u>				<u> </u>					
Uni	t LetterN	:660fe	eet from the	South line and	1980feet fr	om theWestline				
Sect	tion 4	Township 19		e 25 E	NMPM	County Eddy				
		11. Elevation (Si	how whether DR 3543 '	RKB, RT, GR, etc.,)					
				<u></u>						
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data										
	NOTICE OF	INTENTION TO		SUR	SEQUENT R	EDUBT UE:				
PERFORM F	REMEDIAL WORK	K 🗆	ALTERING CASING							
TEMPORAR	ILY ABANDON	CHANGE PLAN		COMMENCE DRI	LLING OPNS.	P AND A				
		MULTIPLE CON	IPL 🗌	CASING/CEMEN	T JOB 🗌					
OTHER:				OTHER:						
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date										
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.										
1. MIR	U. ND WH, NU BO	OP. POOH w/ Prod Ec	quip		NM OIL	CONSERVATION ESIA DISTRICT				
2. RIH	WL – Set 7" CIBP	@ 7,715'		51 5 C 1 51	A	N 2-9 2017				
4 0 .	25 1010	c hole w/ MLF. Spot 2 -4,500' - 5050'-	MARAL CANAL	AC. A. AAMCMA	Y .					
5. Spot	25sx cmt @ 3,000'	-2900'. WOCT	38851- 3785	(COUGAS-SA	NA ANDRES)	RECEIVED :				
6. Spot	25sx cmt @,2,000°	-1,900, 26561-2	550, 3644	-COVERS-OUE	test	ECETATE :				
8. Spot	100sx cmt @ 600'	-1,150 . WOC-1ag	-ADDA PU	uc@ 24301- to	23301 - Couti	IS BASE OF SHIFT				
		t and Cap - Install dry	hole marker			hore only.				
					_	ingoi well be pending under				
					and for plus	and is retained Web Page united to the Page united				
	3/15	/97			4 23 Ophicy under	aund a OCD us/ocd.				
Spud Date:	3/13		Rig Release Da	ite:	of City may her	sing of well bore only. Sing of well bore onl				
WELL	MUST BE	- PLUPBED	B4 7		Forms, Www	ind is Report Web Pass Juent Report Report Web Pass Juent Report Report Web Pass Juent Report Report Report Web Pass Juent Report Re				
		on above is true and c								
•		2	•	, ,						
SIGNATURE		\times	TITLE	Agent	DA	TE 6/28/17				
				*5****						
Type or print		Bryant	E-mail address:		PHe	ONE:				
APPROVED BY: Joseph 1 Byw TITLE COMPLIANCE OFFICER DATE 7/3/2017										
APPROVED		1 Byw	_title_ <i>Com</i>	PLIANCE O	rfiler d	ATE 7/3/2017				
Conditions of Approval (if any): A SEE ATTACHED COA-S										

Operator Name:	Smith + Marys Inc						
Lease Name:	Bradshaw # 803						
API #:	30-015-29360						
95/8 @ 1200' TOC ZIVC							

TD: 8014'

Operator Name: 5	th & Ma	irs Inc.		
Lease Name: Br	adshaw	*3		
Spot 600-0 m/ 100 sks mt			147	hole ciric
PEAF + SQ - WOL & TAR Spat 1250 - USD w 255ks mt - WOLKA 2650 1 - 2550 1 - (COURS YATES) Spat 2000 1900 w 255ks mt	1	9 120 TOC_CI	rc) 2 U 2 D 1
400 74 1/LUB (3674 - 3300 (+ ARAYBURE)	95 /\ \	TO TO	00 APLUB C 2380'-(Lovers	BASE OF SAL
Spot 3000-2900 w/255ks cost	Tagy	7}	,	
5050'- 4950'- (COVER & LORIETY) Spot 4600- 4600 4. 1255Ks and		フ(7 (
Schappe 2715-7615-125 sks out 100 100			#26	83
L		TOC_Cire		8 34 6000-DU
	TD:			4000- DV

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 15. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.

- 16. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 17. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 18. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - 1) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 19. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)