Submit 1 Copy To Appropriate District Office State of	New Mexico	Form C-103
District I Energy, Minerals	and Natural Resources	October 13, 2009
1625 N. French Dr., Hobbs, NM 88240 District II		WELL API NO. 30-005-63679
	ATION DIVISION	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410 1220 SOUTH	St. Francis Dr.	STATE STATE
District IV Santa Fe, NM 87505	, NM 87505	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS		V-09896
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		7. Lease Name or Unit Agreement Name
PROPOSALS.)		Barracuda ABV State 8. Well Number
1. Type of Well: Oil Well 🔲 Gas Well 🖂 Other		1
2. Name of Operator		9. OGRID Number
Armstrong Energy Corporation		001092
3. Address of Operator P.O. Box 1973, Roswell, NM 88202-1973		10. Pool name or Wildcat
4. Well Location		Foor Ranch; San Andres (Gas)
Unit Letter <u>H</u> : <u>1680</u> feet from the <u>North</u> line and <u>800</u> feet from the <u>East</u> line		
Section 5 Township 10S Range 27E NMPM Chaves County		
11. Elevation (Show whether DR, RKB, RT, GR, etc.)		
3934' GR		
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:		
		<u> </u>
		—
OTHER: OTHER:		
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.		
	•	
1. Set CIBP @ 1950', load hole and test to 500 psi, held	าห	NM OIL CONCERNMENT
<ol> <li>Set CIBP @ 1950 , load note and lest to 500 psi, neid</li> <li>Circ hole with mud.</li> </ol>	JIX.	NM OIL CONSERVATION ARTESIA DISTRICT
3. Spot 25 sx on CIBP. WOC, tag @ 1739'.		
3. Spot 25 sx on CIBP. WOC, tag @ 1739 <sup>2</sup> . 4. Perf 1384 <sup>2</sup> , could not pump into perfs.		JAN U 4 ZU18
5. Spot 25 sx @ 1434', WOC, tag @ 1224'.		
6. Perf 480', establish circulation up 8-5/8" annulus to Surface.		
· •	in raco.	RECEIVED
7. Cement w/ 75 sx and circulate, WOC and tag.		RECEIVED
8. Cut off well head 3' below ground.		RECEIVED
		RECEIVED
8. Cut off well head 3' below ground.		RECEIVED
8. Cut off well head 3' below ground.		KECEIVED
<ol> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> </ol>	tion.	RECEIVED
8. Cut off well head 3' below ground.		RECEIVED
<ol> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> <li>Spud Date:</li> </ol>	tion. Rig Release Date:	
<ol> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> </ol>	tion. Rig Release Date:	
<ul> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> <li>Spud Date:</li> <li>I hereby certify that the information above is true and complete</li> </ul>	tion. Rig Release Date:	
<ol> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> <li>Spud Date:</li></ol>	tion.          Rig Release Date:         to the best of my knowledge         Coperations Manager	ge and belief.
<ul> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> <li>Spud Date:</li> <li>I hereby certify that the information above is true and complete</li> </ul>	tion.          Rig Release Date:         to the best of my knowledge         Coperations Manager	ge and belief.
<ol> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> <li>Spud Date:</li> <li>I hereby certify that the information above is true and complete</li> <li>SIGNATURETITLE</li> <li>Type or print name Kyle S. Alpers E-mail addres</li> <li>For State Use Only</li> </ol>	tion.   Rig Release Date:   to the best of my knowledge   Operations Manager   s:   kalpers@aecnm.	ge and belief.
<ol> <li>8. Cut off well head 3' below ground.</li> <li>9. Install Dry Hole Marker, cut of anchors and clean loca</li> <li>Spud Date:</li></ol>	tion.   Rig Release Date:   to the best of my knowledge   Operations Manager   s:   kalpers@aecnm.	ge and belief.