
Submit 1 Copy To Appropriate District Office	State of Nev	v Mexico		Form C-103
<u>District I</u> – (575) 393-6161	Energy, Minerals and	Natural Resources	WELL ADINO	Revised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283			WELL API NO. 30-015-23177	
811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION		5. Indicate Type of Lease	
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.		STATE 🛛	FEE 🗌
<u>District IV</u> - (505) 476-3460	Santa Fe, NM 87505		6. State Oil & Gas Lea	se No.
1220 S. St. Francis Dr., Santa Fe, NM 87505			{	
	ICES AND REPORTS ON W	ELLS	7. Lease Name or Unit	Agreement Name
(DO NOT USE THIS FORM FOR PROPO)	
DIFFERENT RESERVOIR. USE "APPLI PROPOSALS.)	CATION FOR PERMIT" (FORM C-)	or) FOR SUCH	Continenta	I A State
1. Type of Well: Oil Well	Gas Well Other		8. Well Number	•
2. Name of Operator			9. OGRID Number	
E	OG M Resources Inc.		1544	
3. Address of Operator			10. Pool name or Wildcat Turkey Track 7 Rvrs Qn GB SA	
	Fourth St, Artesia, NM 8821	J 	Turkey Track / R	vrs Qn GB SA
4. Well Location	10 Cost form the Cost	Line and 000	fort from the Fort	12
Unit Letter I : 23			feet from the East	
Section 10	Township 19S 11. Elevation (Show whether	Range 29E	NMPM County	Eddy
	· ·	3376' GL	,	5
· ·				
12. Check A	Appropriate Box to Indica	te Nature of Notice,	Report or Other Data	i
			•	
	NTENTION TO:	1	SEQUENT REPOR	
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	PLUG AND ABANDON ⊠ CHANGE PLANS □	REMEDIAL WOR COMMENCE DRI	·	ERING CASING 🗍
PULL OR ALTER CASING	MULTIPLE COMPL	CASING/CEMENT	_ :	
DOWNHOLE COMMINGLE	MOETH LE COMI L	O/ (OII VO/OEIVIEI V	1 00B	
CLOSED-LOOP SYSTEM				
OTHER:		OTHER:		
13. Describe proposed or comp				
proposed completion or rec	ork). SEE RULE 19.15.7.14 N	-	npletions: Attach wellbo	re diagram of
Not for Newson a	24 hrs before men	Lu	NM OIL	CONSERVATION
I. MIRU. ND WH, NO BOP			ARTE	SIA DISTRICT
	Oumpbail 3 sxs cmt 2,179' – 2,		_ FE	B 26 200
3. Set 4½" CIBP @ 1,592'. C	fire well w/ MLF, cap w/ 45 sx	s @ 1,592′-983′. WOC	Tag	, — — — — — — — — — — — — — — — — — — —
4. P&S 100 sxs @ 372'-3'.5. Verify cmt @ surface. Top	off if necessary, RDMO. Cut	z off WH & anchors & inst	tall DH marker.	ECEIVED
,	•			Dun for
		T SAIT 320 B SWIT 1060	· COA #14	
		BSNIFIODO		
A closed loop system will	be used for all fluids from th	is wellbore and dispose	d of required by OCD R	ule 19.15.17
Spud Date:	Rig Relea	se Date:		
		L		
* See Attach.	el CDA's	must be	placed by	2-28-19
I hereby certify that the information	above is true and complete to	the best of my knowledge	e and belief.	
/70	7			
SIGNATURE	TIT 1	LEAgent	DAT	E2/23/18
SIGNATORE	() ····			<u> </u>
Type or print nameGreg	Bryant E-mail addr	ess:	PHONE:	
For State Use Only	•			
	•			
APPROVED BY:	200_TITLES	^		

 LEASE NAME
 Continental A State

 WELL #
 8


 API #
 30-015-23177

 COUNTY
 Eddy, NM



TD @ 3,200'

LEASE NAME	Continental A State	
WELL#	8	
API#	30-015-23177	
COUNTY	Eddy, NM	



TD @ 3,200'

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)