Submit ! Copy To	Appropriate District	State of New Mexico		Form C-103			
District I – (575) 3 1625 N. French D.	393-6161 r., Hobbs, NM 88240	Energy, Minerals and Natural Resources		WELL API NO	Revised Aug	gust 1, 2011	
<u>District II</u> – (575)	748-1283	OIL CONSERVATION DIVISION		30-015-22104	'		
811 S. First St., A. <u>District III</u> – (505)		1220 South St. Francis Dr.		5. Indicate Typ		<b>-</b>	
	Rd., Aztec, NM 87410	Santa Fe,			6. State Oil & 0		$\boxtimes$
1220 S. St. Franci	s Dr., Santa Fe, NM				o. State Off & C	Jas Lease No.	
87505	SUNDRY NO	TICES AND REPORTS ON	WELLS		7 Lease Name	or Unit Agreemer	nt Name
	HIS FORM FOR PROP	OSALS TO DRILL OR TO DEEP	EN OR PLU		7. Bease Hame	or ome rigidenie	iit i vaiiic
PROPOSALS.)	SERVOIR. USE "APPI	LICATION FOR PERMIT" (FORM	C-101) FO	OR SUCH	Old Indian Drav		
1. Type of We		Gas Well Other N	OIL C	<b>ONSERVATIO</b>			ı
2. Name of Op			ARTE	SIA DISTRICT	9. OGRID Nun	ıber	
Chevron U  3. Address of			SEP	1 7 2018	4323 10. Pool name	or Wildcat	
	ville Blvd., Midlar	id, TX 79706	JLI	1 / 2010	Indian Draw		
4. Well Locat	ion		RF	CEIVED			
Unit I	Letter J: 1659 feet	from the SOUTH line and 22	257 feet f	rom the EAST line			
Section	on 07 Township 2	22S Range 28E, NMPM, C		<del></del>			
		11. Elevation (Show whe	ther DR,	RKB, RT, GR, etc.,	)		
		3087' GL				,	
	12. Check	Appropriate Box to Ind	licate Na	ature of Notice,	Report or Othe	r Data	
	NOTICE OF I	NTENTION TO:		SUB	SEQUENT R	EPORT OF:	
PERFORM RE	MEDIAL WORK		$\boxtimes$	REMEDIAL WOR	к 🗆	ALTERING CA	SING
TEMPORARIL	_			COMMENCE DRI		P AND A	
PULL OR ALT				CASING/CEMEN	T JOB 📙		
OTHER:	SOMMINGEE [	J		OTHER:			
		pleted operations. (Clearly					
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. 8 5/8" 24# @ 400": TOC @ surface; 5 1/2" 14# @ 3450": TOC @ surface							
Chevron USA INC respectfully requests to abandon this well as follows:							
1 тост	OC @ 2110' am 4	on of CIDD @ 2001?		No	otify OCD 24	hrs . prior to	
_	•	op of CIBP @ 2891'.		. 44	any work	done.	If mmagazina
		500 psi for 10 minutes. If	-	test was success.	rui, spot oo oois	9.5 ppg MLL.	ii pressure
test was unsuccessful, spot MLF after first cement plug.  3. Spot 25 sx CL C cement f/ 3119' t/ 2891' (Upgrade plug). If pressure test in Step 2 was unsuccessful, WOC, tag,							
spot 25 sx CL C cement if 3119° t/ 2891° (Opgrade plug). If pressure test in Step 2 was unsuccessful, woc, tag, spot 60 bbls 9.5 ppg MLF. If pressure test in Step to was successful, the step 2 was unsuccessful, woc, tag, spot 60 bbls 9.5 ppg MLF.							
4. Spot 25 sx CL C cement f/ 2440' t/ 2212' (Bell Canyon, Lamar, B. Salt)							
5. Spot 50 sx CL C cement f/ 450' t/ surface (Shoe, T. Salt, Fresh Water) Perf + Attempt % Sq 2							
6. Verify cement to surface. Cut all casings & anchors & remove 3' below grade. Weld on dry hole marker. Clean							
location.							
7. All ce	ment plugs class	"C" with closed loop syste	em.				
I hereby certify that the information above is true and complete to the best of my knowledge and belief.							
							_
KSee	111/Ached	COA' 9/17/2018	n	1-st be Pl	ussed by	ワーノフーバ	7
1	X Nick Gla						
•	Nick Glann		•				
	P&A Engineer/Pro	_					
SIGNATURE	Signed by: Nick G	ann	E-mail	address: <u>nglann@c</u>	hevron.com PHC	NE: <u>432-687-778</u>	36 (office)
For State Use C	<u>Only</u>	n		, A			
APPROVED B	Y: <i>411</i>	TITLE	5/	AH My-		ATE 9-17	-18

Conditions of Approval (if any):

# Old Indian Draw Unit 24 Current Wellbore Diagram

Created: Updated: Updated: Lease: Field: Surf. Loc.: Bot. Loc.:	East Lovi	By: R. By: By: an Draw Unit ng - Delaware L & 2,257' FE	J DeBruir	<u>-</u> - - -	Well #: API Surface Unit Ltr.: Bottom Hole Unit Ltr.: COST CTR	TSHP/Rng: J TSHP/Rng:	St. Lse: 30-015-22104 22S / Section: Section: UCRE60100	7 7
County: Status:	Eddy TA'd	St.: Oil Well	NM	<u> </u>	CHEVNO:		EP7540	
Surface Cass Size: Wt., Grd.: Depth: Sxs Cmt: Circulate: TOC: Hole Size:	8-5/8" 24#, K-55 400' 300 Yes, 52 sxs Surface 12-1/4"	TD, ft				-	GL: Ini. Spud: _ Ini. Comp.:	3,086.6' 06/10/77 06/22/77
Form	ation Name	Top		į				
T Salt		99						
B Salt		2,349	İ					
Lamar LS Bell Canyor		2,349 2,390	<b> </b>					
Cherry Can		3,249	l l	1				
	This wellbore diagram i the most recent info regarding wellbore conf equipment that could be Midland Office well files / online databases as of date above.	rmation iguration & found in the & computer						
Production C Size: Wt., Grd.: Depth: Sxs Cmt: Circulate: TOC: Hole Size:	5-1/2" 14#, K-55 3,450' 585 Yes, 30 sxs Surface 7-7/8"							•

PBTD: 3,414' TD: 3,450'

#### Old Indian Draw Unit 24 **Proposed Wellbore Diagram**

Created: _	01/28/18	By:	RJ DeBruin		
Updated:		By:			
Updated: _		By:			
Lease:	Öld İnd	ian Draw U	nit		
Field:	East Loving - Delaware				
Surf. Loc.:	1,659' FSL & 2,257' FEL				
Bot. Loc.:					
County:	Eddy	St.:	NM		
Status:	TA'd Oil Well				

Well #:	24	St. Lse:	Private
API		30-015-22104	
Surface	TSHP/Rng:	225/	28E
Unit Ltr.:	J	Section:	7
Bottom Hole	TSHP/Rng:		
Unit Ltr.:		Section:	
COST CTR		UCRE60100	
CHEVNO:		EP7540	

Surface Casing

Size: 8-5/8" Wt., Grd.: 24#. K-55 Depth: 400' Sxs Cmt: 300

Circulate: TOC: Hole Size:

Yes, 52 sxs Surface 12-1/4"

GL:	3,086.6
Ini. Spud:	06/10/77
Ini. Comp.:	06/22/77

TD, ft **Formation Name** Top T Saft 99 B Salt 2,349 Lamar LS 2,349 Bell Canyon 2,390 Cherry Canyon 3,249 Spot 50 sx CL C cmt f/ 450' t/ surface (Shoe, T. Salt, Fresh Water)

Spot 25 sx CL C cmt f/ 2440' t/ 2212' (Bell Cyn, Lamar, B. Salt)

Production Casing

Size: 5-1/2" Wt., Grd.: 14#, K-55 Depth: 3,450' Sxs Cmt: 585 Circulate: Yes, 30 sxs TOC: Surface Hole Size:

PBTD: 3,414' TD: 3,450'

Spot 25 sx CL C cmt f/ 3119' t/ 2891' (Upgrade Cement)

TOC @ ~3,119' (~29' of cmt) 5-1/2" CIBP @ 3,148' (12/19/08)

> Perfs: 3,248' - 3,268' (4 SPF) Perfs: 3,298' - 3,328' (2 SPF) Delaware

NOTE: According to TA C-103, only 29' of cmt (3 sxs using yield of 1.32) was put on top of CIBP.

## **CONDITIONS FOR PLUGGING AND ABANDONMENT**

### District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

### **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)