

Submit 1 Copy To Appropriate District Office

District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-32450	
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name Bones BAD	
8. Well Number 1	
9. OGRID Number 7377	
10. Pool name or Wildcat Dayton; Wolfcamp	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3447' GR	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
EOG Resources, Inc.

3. Address of Operator
104 South Fourth Street, Artesia, NM 88210

4. Well Location
Unit Letter C : 660 feet from the North line and 1980 feet from the West line
Section 31 Township 18S Range 26E NMPM Eddy County

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Notify OCD 24 hrs. prior to
any work done.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- MIRU all safety equipment as needed. POOH with production equipment. 6052'
- Set a CIBP at 6052'. Spot a 64 sx Class "H" cement plug from 6102'-5494'. WOC and tag. This will plug Wolfcamp and Abo.
- Spot a 25 sx Class "C" cement plug from 4480'-4242'. WOC and tag. This will plug Abo.
- Spot a 31 sx Class "C" cement plug from 3570'-3279'. WOC and tag. This will plug Lower Yeso and Tubb.
- Spot a 46 sx Class "C" cement plug from 2435'-2001'. WOC and tag. This will plug Upper Yeso and Glorieta.
- Perforate at 1267'. Attempt to establish circulation. Spot a 25 sx Class "C" cement plug from 1267'-1029'. WOC and tag. This will plug 8-5/8" casing shoe. 860-622
- Spot a 25 sx Class "C" cement plug from 768'-530'. WOC and tag. This will plug San Andres.
- Spot a 10 sx Class "C" cement plug from 95' up to surface. This will plug top. Port @ 570 + Attempt to 562
- Cut off wellhead and weld on dry hole marker. Clean location as per regulated.

RECEIVED

Wellbore schematics attached

JUN 10 2019

Spud Date:

Rig Release Date:

DISTRICT II-ARTESIA O.C.D.

* See Attached COAs

Must be Plugged by 6/12/20

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE June 6, 2019

Type or print name Tina Huerta E-mail address: tina_huerta@egoresources.com PHONE: 575-748-4168

For State Use Only

APPROVED BY: [Signature] TITLE Staff Mgr DATE 6/12/19
Conditions of Approval (if any):

Current

Figure 1 consists of two schematic diagrams, A and B, illustrating the experimental apparatus. Diagram A is a top-down view of a rectangular arena. It features a central rectangular platform. A starting box, labeled 'B', is located on the left side of the arena. The arena is divided into four quadrants by a central vertical line and a horizontal line passing through the platform. The quadrants are labeled with letters: 'A' in the top-left, 'B' in the top-right, 'C' in the bottom-left, and 'D' in the bottom-right. Diagram B is a side-view schematic showing the arena's height and the platform's position. It shows a rectangular arena with a central platform. The arena is divided into four quadrants, labeled 'A', 'B', 'C', and 'D'. The platform is located in the center of the arena. The arena is divided into four quadrants by a central vertical line and a horizontal line passing through the platform. The quadrants are labeled with letters: 'A' in the top-left, 'B' in the top-right, 'C' in the bottom-left, and 'D' in the bottom-right.

1409 - 1467

PBTD:	1,540	MD
TD:	1,550	MD

CASING DETAIL									
#	HOLE SIZE	SIZE	WGHT	GRADE	Top	BTM	Sx Cmt	Circ/TOC	TOC Method
		20			0	503	300		
A	9 1/2	13 3/8	48		0	1,111	550		
B	6 1/4	8 5/8	24		0	521			
C	6.25	5 1/2	17		521	1540	150		
C	6.25	5 1/2	17		521	1540	150		

[illegible][illegible][illegible]

Prepared by: MJM

Date: 5-Jun-2019

BONES BAD #001

Current

CASING DETAIL

#	HOLE SIZE	SIZE	WGHT	GRADE	Top	BTM	Sx Cmt	Circ/TOC	TOC Method
		20			0	40			
A	9 1/2	13 3/8	48		0	520	600	Circ	
B	6 1/4	8 5/8	24		0	1217	1050	Circ	
C	6.25	5 1/2	17 / 15.5		0	9350	2050	Circ	

FORMATION TOPS

	FORMATION	TOP							
	SAN ANDRES	718							
	Glorieta	2189							
	Upper Yeso	2385							
	Tubb	3467							
	Lower Yeso	3520							
	Abo	4430							
	Atoka	5682							
	Wolfcamp	5740							
	Canyon	7663							
	Stawn	8285							
	Morrow	8966							
	Chester	9260							

Plugs

1	Set CIBP at 6052. Spot a 64 SX (608 ft) CLS H cement plug 5494 ft - 6102 ft. WOC & Tag Plug. This will plug the Wolfcamp & Atoka.
2	Spot a 25 SX (238 ft) CLS C cement plug 4242 ft - 4480 ft. WOC & Tag Plug. This will plug the Abo.
3	Spot a 31 SX (296 ft) CLS C cement plug 3279 ft - 3570 ft. WOC & Tag Plug. This will plug the Lower yeso & Tubb.
4	Spot a 46 SX (434 ft) CLS C cement plug 2001ft - 2435 ft. WOC & Tag Plug. This will plug the Upper Yeso & Glorieta
5	Perforate at 1267 ft. Attempt to establish Circulation. Spot a 25 SX (238 ft) CLS C cement plug 1029 ft - 1267 ft. WOC & Tag Plug. This will plug the 8.625 inch casing shoe.
6	Spot a 25 SX (238 ft) CLS C cement plug 530 ft - 768 ft. WOC & Tag Plug. This will plug the San Anders.
7	Spot a 10 SX (95 ft) CLS C cement plug 0 ft - 95 ft. WOC & Tag Plug. This will plug the Top.

Prepared by: MJM

Date: 5-Jun-2019

COMMENTS

Plug #7

Plug #6

Plug #5

Plug #4


Plug #3

Plug #2

Plug #1

Perfs 6102 - 8022

Perfs 8844 - 9010



PBTD: 8,970 MD
TD: 9,350 MD

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)