

District I - (575) 393-6161  
1625 N. French Dr., Hobbs, NM 88240  
District II - (575) 748-1283  
811 S. First St., Artesia, NM 88210  
District III - (505) 334-6178  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV - (505) 476-3460  
1220 S. St. Francis Dr., Santa Fe, NM 87505

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-005-63316
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. L-6811
7. Lease Name or Unit Agreement Name Horizon AWH State
8. Well Number 1
9. OGRID Number 7377
10. Pool name or Wildcat Pecos Slope; Abo
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3768' GR

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator  
EOG Resources, Inc.

3. Address of Operator  
104 South Fourth Street, Artesia, NM 88210

4. Well Location  
Unit Letter A : 1200 feet from the North line and 660 feet from the East line  
Section 16 Township 9S Range 26E NMPM Chaves County

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

<p><b>NOTICE OF INTENTION TO:</b></p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPL <input type="checkbox"/></p> <p>DOWNHOLE COMMINGLE <input type="checkbox"/></p> <p>CLOSED-LOOP SYSTEM <input type="checkbox"/></p> <p>OTHER: <input type="checkbox"/></p>	<p><b>SUBSEQUENT REPORT OF:</b></p> <p>REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/></p> <p>COMMENCE DRILLING OPNS. <input type="checkbox"/> P AND A <input type="checkbox"/></p> <p>CASING/CEMENT JOB <input type="checkbox"/></p> <p>OTHER: <input type="checkbox"/></p>
--	--

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

**Notify OCD 24 hrs. prior to any work done.**

- MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
- Set a CIBP at 5322' with 356' Class "C" cement on top. Covers perfs and top of Wolfcamp. WOC and tag.
- Tag TOC at 4966'. Set a CIBP at 4370' with 35' Class "C" cement on top. Covers top of Abo. WOC and tag. *25 sx Cnt*
- Tag TOC at 4335'. Perforate at 3653'. Attempt to establish circulation or spot a 35 sx in/out cement plug from 3653'-3523'. Covers top of the Tubb. WOC and tag.
- Perforate at 2090'. Attempt to establish circulation or spot a 32 sx in/out cement plug from 2090'-1970'. Covers top of Glorieta. WOC and tag.
- Perforate at 1194'. Attempt to establish circulation or spot a 31 sx in/out cement plug from 1194'-896'. Covers the top of the San Andres and the 8-5/8" casing shoe. WOC and tag.
- Tag TOC. Perforate at 100'. Spot a 25 sx in/out cement plug from 100' up to surface. Backfill and 1" as needed on surface plug.
- Cut off wellhead and weld on dry hole marker. Clean location as per regulated.

Wellbore schematics attached

\*\*\* SEE ATTACHED COA'S \*\*\*

**NM OIL CONSERVATION**  
ARTESIA DISTRICT

Spud Date:

Rig

MUST BE PLUGGED BY 11/5/20

OCT 31 2019

RECEIVED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE October 31, 2019

Type or print name Tina Huerta E-mail address: tina\_huerta@eogresources.com PHONE: 575-748-4168

For State Use Only

APPROVED BY: [Signature] TITLE Staff Mgr. DATE 11/5/19

Conditions of Approval (if any):

[illegible]

# Horizon AWH State #1

Sec-TWN-RNG: Sec. 16 - 9S-26E  
 FOOTAGES: 1200' FNL & 660' FEL  
 CURRENT

API: 30-005-63316  
 GL: 3768'  
 KB:

## CASING DETAIL

#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cmt	Circ/TOC	TOC Method
A	12 1/4	8 5/8	24	J-55	0	1144'	600	Circ	
B	7 7/8	5 1/2	15.5	J-55	0	6,380	500	3960	CBL

## FORMATION TOPS

	Formation	Top							
	San Anders	946							
	Glorieta	2030							
	Tubb	3588							
	Abo	4327							
	Wolfcamp	5016							
	Cisco	5597							
	Penn Clastics	5715							
	Mississippian	5875							
	Ordovician	5932							
	Granite Wash	6203							

## Plugs

1	CIBP @ 5322' with 356' class C cmt. Covering perms and top of Wolfcamp. WOC & Tag								
2	CIBP @ 4370' with 36' class C cmt covering top of Abo. WOC & Tag.	25	5x						
3	Perfs @ 3653'. In/Out class C plug from 3653' - 3523' (35 sxs) covering the top of the Tubb. WOC & Tag.								
4	Perfs @ 2090'. Spot in/out class C plug from 2090' - 1970' (32 sxs) covering the top of the Glorieta. WOC & Tag.								
5	Perfs @ 1194'. Spot in/out class C plug from 1194' - 896' (31 sxs) covering 8-5/8" csg shoe and top of San Andres. WOC & Tag.								
6	Perfs @ 100'. Spot in/out class C plug from 100' to surface (25 sxs). Tis will be the surface plug.								

PBTD: 5,310 MD

TD: 6,380 MD

## CONDITIONS FOR PLUGGING AND ABANDONMENT

### District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

#### **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

**1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS**

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)