

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

OCD-ARTESIA

FORM APPROVED  
OM B No. 1004-0137  
Expires: March 31, 2007

## SUNDRY NOTICES AND REPORTS ON WELLS

**Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.**

**SUBMIT IN TRIPLICATE- Other instructions on reverse side.**1. Type of Well  
☐ Oil Well ☐ Gas Well ☒ Other2. Name of Operator **Marbob Energy Corporation**3a. Address  
**PO Box 227, Artesia, NM 88211-0227**3b. Phone No. (include area code)  
**505-748-3303**

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

**1980 FSL 1980 FEL, Sec. 11-T17S-R29E, Unit J**

5. Lease Serial No.

**NMLC058362**

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

**NMNM111789X**

8. Well Name and No.

**Dodd Federal Unit #11**

9. API Well No.

**30-015-02948**

10. Field and Pool, or Exploratory Area

**Grbg Jackson SR Q Grbg SA**

11. County or Parish, State

**Eddy Co., NM**

## 12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

## TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

## TYPE OF ACTION

- |   |  |  |   |
|---|--|--|---|
| <input type="checkbox"/> Acidize              | <input type="checkbox"/> Deepen                      | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Alter Casing         | <input type="checkbox"/> Fracture Treat              | <input type="checkbox"/> Reclamation               | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Casing Repair        | <input type="checkbox"/> New Construction            | <input type="checkbox"/> Recomplete                | <input type="checkbox"/> Other          |
| <input type="checkbox"/> Change Plans         | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon       |   |
| <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back                   | <input type="checkbox"/> Water Disposal            |   |

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

**Plug and abandon as follows:****Notify BLM 24 hours before starting plugging operation.**

1. POOH w/ pkr & tbq.
2. Shoot 4 sqz holes @ 900' (50' below base salt @ 850').
3. Set CIBP on tbq @ 2300'. Spot 10 sx Class "C" neat cmt on top of CIBP. Pull up to 2100' & circ well bore full of 9 ppg brine mixed w/ 25 sx per 100 bbs of salt gel (appx 35 bbls csg volume).
4. Pull tbq to 750'. Pump 45 sx Class "C" + 2% CaCl<sub>2</sub> to the end of the tbq (placing cmt inside & outside the csg). TOOH w/ tbq, load csg. WOC a couple of hours & tag cmt w/ tbq.
5. Shoot 4 sqz holes @ 510' (50' below 8 5/8" shoe @ 460'). Pump 40 sx Class "C" + 2% CaCl<sub>2</sub> down 7" csg & up 8 5/8" x 7" annulus to fill the well from 510' to 410' w/ cmt. WOC a couple of hours, then tag plug.
6. Shoot 4 deep penetrating sqz holes @ 100' (above calculated TOC behind 8 5/8"). Pump 60 sx Class "C" + 2% CaCl<sub>2</sub> down 7" csg & up 8 5/8" x 7" annulus & outside 8 5/8" to fill well from 100' to surface w/ cmt.
7. Cut wellhead & csg off 3' below ground level & remove. Weld plate onto 8 5/8" stub. Weld 4" dry hole marker onto plate such that 4' of it is above ground level.
8. Cut off anchors & reclaim location per BLM specs.

**SEE ATTACHED FOR  
CONDITIONS OF APPROVAL**

14. I hereby certify that the foregoing is true and correct  
Name (Printed/Typed)

**Diana J. Briggs**Title **Production Analyst**

Signature

Date

**06/13/2006****Accepted for record  
NMOCB****THIS SPACE FOR FEDERAL OR STATE OFFICE USE**

Approved by

**(ORIG. SGD.) ALEXIS C. SWOBODA****PETROLEUM ENGINEER**

Date

**JUN 19 2006**

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)