Submit 3 Copies To Appropriate District Office State of New Mexico	Form C-103
District 1 Energy, Minerals and Natural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 88240	WELL API NO.
District II 1301 W. Grand Association VIM 88210 OIL CONSERVATION DIVISION	30-015-01299
District III OIL CONSERVATION DIVISION District III 1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Dio Droggo Dd - Agroca 104 4 97410	STATE STATE FEE
District IV Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe. NM	E-9510
87505	7 Lagga Nama on Unit Agreement Nama
CONNOT USE THIS ECOM ECO DEPONDALS TO DRILL OF TO DEEDEN OPINIGERACY TO A	7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	EAST DED LAVE IDDT
SUNDRY NOTICES AND REPORTS ON WELLS  (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEDEN ORRILUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)  1. Type of Well: Oil Well	EAST RED LAKE UNIT
PROPOSALS.)  1. Type of Well: Oil Well  Gas Well Other  2. Name of Operator Lothian Oil  3. Address of Operator	8. Well Number 2X
2. Name of Operator RECENTESIA OT	9. OGRID Number 36990
Lothian Oil 200 - And 201	
3. Address of Operator	10. Pool name or Wildcat
200 N. LORAINE, STE. 400, MIDLAND, TX 79701	Red Lake; QN-GB-East 51340
200 N. LORAINE, STE. 400, MIDLAND, TX 79701  4. Well Location	
H. WEII ECCURION	C 4 C 41 NUEGTE V.
Unit Letter: F2,310'_feet from theNORTH line and1,650'_	
Section 1 Township 17-S Range 28-E NMP!	
11. Elevation (Show whether DR, RKB, RT, GR, e	tc.)
3,608' GL	
Pit or Below-grade Tank Application or Closure	
Pit type Depth to Groundwater Distance from nearest fresh water well	Distance from nearest surface water
Pit Liner Thickness: mil Below-Grade Tank: Volume bbls;	Construction Material
12. Check Appropriate Box to Indicate Nature of Notic	e, Report or Other Data
NATIAE AE MITENTIAN TA	DAEAUENT DEDART AE
	BSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL W	DRK ALTERING CASING
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WORK ☐ COMMENCE [	DRK ☐ ALTERING CASING ☐ PRILLING OPNS.☐ P AND A ☐
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL W	DRK ☐ ALTERING CASING ☐ PRILLING OPNS.☐ P AND A ☐
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE IS CASING/CEMI	DRK ☐ ALTERING CASING ☐ PRILLING OPNS.☐ P AND A ☐
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE IS CASING/CEMIS	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF CASING/CEMING MULTIPLE COMPL CASING/CEMING	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE IN CASING/CEMING MULTIPLE COMPL CASING/CEMING	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF CASING/CEMING MULTIPLE COMPL CASING/CEMING	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEMING OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE TEMPORARILY ABANDON CHANGE PLANS COMMENCE TO CASING/CEMING MULTIPLE COMPL CASING/CEMING	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf.	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON COMMENCE OF TEMP	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON COMMENCE OF TEMP	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  CHANGE PLANS COMMENCE OF PULL OR ALTER CASING  MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid.	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON COMMENCE OF TEMP	ORK ALTERING CASING PRILLING OPNS. PAND A SINT JOB PAND A SINT JOB
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  CHANGE PLANS COMMENCE OF PULL OR ALTER CASING  MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid.	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON COMMENCE OF TEMP	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  ALTER CASING  MULTIPLE COMPL  CASING/CEMING  PULL OR ALTER CASING  MULTIPLE COMPL  CASING/CEMING  THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.  I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit	ORK
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON CHANGE PLANS COMMENCE OF TEMPORARILY ABANDON COMMENCE OF TEMP	ORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE FOR PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.  I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines, a general permite SIGNATURE:  SIGNATURE: Asserting And Abandon TITLE: Petroleum Engineer	DRK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  CHANGE PLANS COMMENCE OF PULL OR ALTER CASING  MULTIPLE COMPL CASING/CEMING THER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of Cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.  I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit SIGNATURE:  State Lies Only.  TITLE: Petroleum Engineer  Type or print name Jesse K. Lawson E-mail address: jklawson@lothian.us	DRK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  MULTIPLE COMPL COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEMINOTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of the cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.  I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit structure.  SIGNATURE: State K. Sawson TITLE: Petroleum Engineer  Type or print name Jesse K. Lawson E-mail address: jklawson@lothian.up.  For State Use Only  CASING/CEMIN COMMENCE DATE OF CASING/CEMIN CASIN	ALTERING CASING PRILLING OPNS. PAND A
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  MULTIPLE COMPL COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEMINOTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of the cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.  I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit structure.  SIGNATURE: State K. Sawson TITLE: Petroleum Engineer  Type or print name Jesse K. Lawson E-mail address: jklawson@lothian.up.  For State Use Only  CASING/CEMIN COMMENCE DATE OF CASING/CEMIN CASIN	ALTERING CASING PRILLING OPNS. PAND A
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK TEMPORARILY ABANDON  MULTIPLE COMPL COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEMINOTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent details, of starting any proposed work). SEE RULE 1103. For Multiple Completions: or recompletion.  1) Gauge ring run. 2) Set CIBP within 100' of top perf. 3) Pressure up casing to 500#, hold for 30 min. Document with pressure of the cannot have more than 10% loss of pressure in 30 min. 5) Displace with packer fluid. 6) Notify OCD 24 to 48 hours prior to test.  I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit structure.  SIGNATURE: State K. Sawson TITLE: Petroleum Engineer  Type or print name Jesse K. Lawson E-mail address: jklawson@lothian.up.  For State Use Only  CASING/CEMIN COMMENCE DATE OF CASING/CEMIN CASIN	ALTERING CASING ARILLING OPNS. PAND A
PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE TEMPORARILY ABANDON CHANGE PLANS COMMENCE TO CASING/CEMING MULTIPLE COMPL CASING/CEMING	ALTERING CASING PRILLING OPNS. PAND A