

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised June 10, 2003

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. <b>30-015-00176</b>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name <b>Atoka San Andres Unit</b>
8. Well Number <b>113</b>
9. OGRID Number <b>6137</b>
10. Pool name or Wildcat <b>Atoka San Andres</b>

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other— <u>Water Injection Well</u>	
2. Name of Operator Devon Energy Production Company, LP	
3. Address of Operator 20 North Broadway, Suite 1500, Oklahoma City, Oklahoma 73102	
4. Well Location Unit Letter <u>J</u> : 1645' feet from the <u>South</u> line and <u>2310'</u> feet from the <u>East</u> line Section <u>11</u> Township <u>18S</u> Range <u>26E</u> Eddy County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3316' GL; 3322' KB	

DEC 26 2007  
CD-ARTESIA

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
<b>NOTICE OF INTENTION TO:</b> PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPLETION <input type="checkbox"/> OTHER: <input type="checkbox"/>	<b>SUBSEQUENT REPORT OF:</b> REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. MIRU PA rig on 12/2/07. POOH w/ 2-3/8" IPC tubing. Dump bail 35' cement on top of existing CIBP at 1,576'.
2. Circulate wellbore with 9.5 ppg salt gel mud.
3. Spot 25 Sx cement in 5-1/2" casing plug at 1,275'. Tagged TOC @ 1,046'. (8-5/8" casing shoe at 1,225')
4. Spot 60' surface plug.
5. Cut wellhead off 3' below ground level, set P&A marker, clean location.
6. Wellbore plugged & abandoned - 12/20/07.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Ronnie Slack TITLE: Engineering Technician DATE 12/20/07

Type or print name Ronnie Slack E-mail address: Ronnie.Slack@dvn.com Telephone No. 405-552-4615

(This space for State use)

APPROVED BY Phil Hankin TITLE Comptroller DATE 1/2/2008  
Conditions of approval, if any:

Approved for plugging of well bore only.  
Liability under bond is retained pending  
receipt of C-103 (Subsequent Report of Well  
Plugging) which may be found at OCD Web  
Page under forms. [www.emnrd.state.us/ocd](http://www.emnrd.state.us/ocd)

**DEVON ENERGY PRODUCTION COMPANY LP**

Well Name: ATOKA SAN ANDRES UNIT #113		Field: ATOKA SAN ANDRES	
Location: 1645' FSL & 2310' FEL; SEC 11-T18S-R26E		County: EDDY	State: NM
Elevation: 3316' GL; 3322' KB		Spud Date: 8/17/56	Compl Date: 9/3/56
API#: 30-015-00176	Prepared by: Ronnie Slack	Date: 12/20/07	Rev:

**PLUGGED & ABANDONED**  
12/20/07

**Plug & Abandonment**

1. Spot 60' surface plug.
2. Cut wellhead off, set dry hole marker, clean location.
3. Wellbore plugged - 12/20/07

9.5# mud

**Plug & Abandonment**

1. Spot 25 Sx cement at 1,275'.
2. Tagged TOC @ 1,046'.

11" Hole  
8-5/8", 29#, @ 1,225'  
Cmt'd w/700 Sx. TOC at surface

9.5# mud

**Plug & Abandonment**

1. Dump 35' cement on existing CIBP at 1,576'.
2. Circulate wellbore w/9.5# salt gel mud

CIBP @ 1,576' (3/18/82)

**SAN ANDRES**  
1,654' - 1,672 (4 spf)

1,788' PBD

7-7/8" Hole  
5-1/2", 15#, @ 1,797'  
Cmt'd w/350 Sx. TOC at surface

1,797' TD