

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

APR 29 2008

OCD-ARTESIA



FORM APPROVED
OMB No. 1004-0135
Expires January 31, 2004

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or re enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1 Type of Well



Oil Well



Gas Well



Other

2 Name of Operator

Yates Drilling Company

3a Address

105 S. 4th Str., Artesia, NM 88210

3b. Phone No. (include area code)

505-748-8663

4 Location of Well (Footage, Sec., T., R., M., OR Survey Description)

2310' FSL & 2310' FWL Section 30-25S-30E

5 Lease Serial No

NMNM-14785

6 If Indian, Allottee or Tribe Name

7 If Unit or CA/Agreement, Name and/or No

8. Well Name and No

Bennett Federal #2

9 API Well No

30-015-32189

10 Field and Pool, or Exploratory Area

Bone Spring

11 County or Parish, State

Eddy County NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION



Notice of Intent



Subsequent Report



Final Abandonment Notice

TYPE OF ACTION



Acidize



Deepen



Production (Start/Resume)



Water Shut-Off



Alter Casing



Fracture Treat



Reclamation



Well Integrity



Casing Repair



New Construction



Recomplete



Other



Change Plans



Plug and Abandon



Temporarily Abandon



Convert to Injection



Plug Back



Water Disposal

13 Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof)

If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.

See attachment.

*Modification
30 day ext. 5/20/08
J. Amos*

ACCEPTED FOR RECORD

APR 30 2008

APPROVED

JAN 20 2008

JAMES A. AMOS
SUPERVISOR-EPS

14 I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Karen J. Leishman

Gerry Guye, Deputy Field Inspector
NMOC-District II ARTESIA
Title Operations Tech

Title

Date

1/14/2008

Signature

Karen J. Leishman

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

Date

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

CONDITIONS OF APPROVAL
NMNM14785; Bennett Federal #2
2310' FSL & 2310' FWL, Sec. 30, T25S-R30E
Eddy County, New Mexico

Plugging procedure:

Attached: NMOCD Guidelines
BLM Permanent Abandonment Conditions of Approval

Proposed procedure:

1. Move in and rig up pulling unit
2. POH with rods and pump
3. ND wellhead and NU 3,000 #BOP
4. RIH with tubing open ended and tag CIBP @ 9,200' and circulate 10# mud to surface.
5. Spot 50' class "H" cement plug on top of the CIBP. **The CIBP can be capped with 35 feet of cement if bailer is used. Otherwise, it must be a minimum of 25 sacks (NMOCD Guidelines).**
6. POH and spot 100' cement across the top of the Bone Springs (7530'). **All cement plugs, except the surface plug, shall have sufficient slurry volume to fill 100 feet of hole, plus an additional 10 percent of slurry for each 1,000 feet of depth (7445' - 7615').**
7. POH with tubing open ended to 5,950 and spot a 100' cement plug across the DV tool. **Should be 150' plug (5875 - 6025')**
8. POH with tubing and RU wireline. Free point 5 1/2" casing and cut at 4,000' +/- Pull casing and LD.
9. RIN and spot tubing at 4,050'. Circulate 10# mud and spot 100' plug **(50' in/out). WOC and tag plug.**
10. RIH and spot tubing at 3,480', **and spot plug across the 8-5/8" casing shoe (3430') and the base of the salt (3265'), from 3480' - 3215'. WOC and tag plug.**
11. POH and spot 100' cement plug across the surface casing shoe. **Spot tubing at 784' (50' below the top of salt), and set cement plug to extend 50' into the 11 3/4" surface casing (510' - 784'). WOC and tag plug.**
12. POH and pump cement from 100' to surface.
13. ~~Erect dry hole marker and cut off anchors.~~

If you have any questions, contact Jim Amos at 505-234-5909.

*See attached modifications!
of 4/25/08.*

J. Amos

Yates Drilling Company
NMNM14785; Bennett Federal 2
2310' FSL & 2310' FWL
Section 30, T.25 S., R.30 E.
Eddy County, New Mexico
3

RE: Modified P&A Procedure

Steps 1-7	Remains the same as previous COA's
Steps 8-9	Omitted
Step 10	Perforate 5-1/2" casing @ 3480', squeeze with adequate cement to fill from 3480'-3215' (covers top of salt and 8-5/8" casing shoe). WOC and tag no lower than 3215'.
Step 11	Perforate 5-1/2" casing @ 784', circulate cement to surface in/out.

James A. Amos
505-234-5909

