•	1. ž	÷Ĵ									
District I State o					f Nev	v Mexico				For	rm C-102
•	rench Dr.	, Hobbs, NM 88240	Energy, Miner	als & No	itural	Resource	s Departme	nt	Revise	d October	r 12, 2005
District II	rand Ave	nue, Artesio, NM 882	57 -			ON DIVISIO	•	Submit	to Approp	oriate Dis	trict Office
District III		100, 720000, 140 002									- 4 Copies
1000 Rio I	Brazos Re	d., Aztec, NM 87410	12	20 South	h St.	Francis [)r.				- 3 Copies
District IV				Santa F	e, NI	M 87505					e copico
1220 S. S	t. Francis	: Dr., Santa Fe, NM	87505		•				🗋 AN	AENDED F	REPORT
			WELL LOCAT	ION AND	ACRE	AGE DEDI	CATION PLAT				
[Number	Pool C			• •		Pool Name			
30-0	15-	37280	17.	970		Dog (lanton; 1	Nolfcamp			
Property Code P			roperty Name				We	ell Number			
37830 LUCKY WOL			LF 31 FED. COM				1H				
OGRID No. O			Operator Name					E	Elevation		
7377 EOG RES		SOURCES, INC.				3	519.6'				
·····				Sur	face	Location					
UL or lot no.	. Section	Township	Range		Lot Idn	Feet from the	North/South line	Feet from the	East/Wes	it line	County
A	31	16 SOUTH	28 EAST, N.	М. Р. М.		330'	NORTH	330'	EA	AST	EDDY
• <u> </u>			Bottom H	lole Loco	ition	lf Differen	t From Sur	face			
UL or lot no.	. Section	Township	Range		Lot Idn	Feet from the	North/South line	Feet from the	East/Wes	st line	County
D	31	16 SOUTH	28 EAST, N.	М. Р. М.		660'	NORTH	330'	WE	EST	EDDY
Dedicated	d Acres	Joint or Infill	Consolidation Code	Order No.		• • • • • • • • •	• • • • • • • • • • • • • • • • • • • •				
11.0			i								

÷

.

No allowable will be assigned to this completion until all interests have been consolidated or a non-standard unit has been approved by the division.

	LG4437 120	a a 330'	Nm 12110	OPERATOR CERTIFICATION
8	GRID AZ = 265°31' PRODUCING AREA PROJECT AREA		SURFACE LOCATION NEW MEXICO EAST NAD 1927 Y=685484.7 X=538736.6 LAT:: N 32.88441485 LONG:: W 104.2071482	I hereby certify that the information contained herein is true and complete to the best of my knowledge and belief, and that this organization either owns a working interest or unleased mineral interest in the land including the proposed bottom hole location or has a right to drill this well at this location pursuant to a contract with an owner of such a mineral or working interest, or to a voluntary pooling agreement or a compulsory pooling order heretofore entered by the division. Jun J. Mun <u>815/2009</u> Signature Date Donny G. Glanton
	 			Printed Name SURVEYOR CERTIFICATION I hereby certify that the well location shown on this plat was plotted from field notes of octal Algress made by me of Neter my supervision and that the same is true but correct to the best of my belief. July 17, 2009 Date of Survey Signature and Seal of Professional Survey Survey Signature and Seal of Professional Survey Signature and Seal of Survey Signature and Seal of Signature and Seal of Professional Survey Sur
				WO# 090717WL-a (Rev. A) (KA)

LOCATION VERIFICATION MAP



SCALE: 1'' = 2000'

CONTOUR INTERVAL: 10'

SEC. <u>31</u> TWP. <u>16-S</u> RGE. <u>28-E</u> SURVEY <u>N.M.P.M.</u> COUNTY <u>EDDY</u> DESCRIPTION <u>330'</u> FNL <u>& 330'</u> FEL ELEVATION <u>3519.6'</u> OPERATOR <u>EOG</u> RESOURCES, INC. LEASE <u>LUCKY WOLF 31</u> FED. COM <u>#1H</u> U.S.G.S. TOPOGRAPHIC MAP <u>DIAMOND MOUND, N.M.</u>



Exh.b.f2

۲

s 🐥

_ i



DIRECTIONSBEGINNING IN ARTESIA AT THE INTERSECTION OF U.S. HWY. #285 AND U.S. HWY. #82, GO EAST ON U.S. HWY. #82 FOR APPX. 9.5 MILES, TURN NORTH ON EDDY COUNTY ROAD #202 (SOUTHERN UNION ROAD) FOR 2.8 MILES, TURN NORTHEAST ON EDDY COUNTY ROAD #202 FOR 1.3 MILES, TURN NORTHWEST FOR 0.1 MILES, TURN NORTH ON LEASE ROAD FOR 1.8 MILES, TURN EAST ON TRAIL ROAD FOR 0.7 MILES, TURN NORTH FOR 0.1 MILES TO LOCATION.

** "Wells-Fed. US I COG OEG
94851 300^{60} 90027 9
pevon Ener 2 Graph Fed U3 627 72 Vortes Pat. 4H Vortes Pat.
(Collins
US. 4 Hontgemery 201 1 Vites Colline per 303672 10250 Section 31, T/65 - R 28E, N. M. R.M. a) 12 3 4 Hontgemery 201 14 36380 14
Ware Chi Oper Chase Uli (1250 21 2018) 5 1 2018 5 1 2018 0 23 1 2018 0 23 1 2018 0 23 1 2018 0 23 1 2018 0 23 1 2018 0 2018 1 20 340 0 23 1 2018 1 20
$ \begin{array}{c c} & & & & \\ \hline & & & \\$
$\begin{array}{c c} F_{100} & F_{100}$
US Stote US Logo CG CG C C C C C C C C C C C C C C C C
Il Blanco (Chose Oil COG OKS Murchison, COG OKS 16,1,2001,54956 X 54954 8 1 2015 120 59 50 A J 120 59 50 A J 120 59 50 A J 120 50 1 15 10 10 10 10 10 10 10 10 10 10 10 10 10
Hitchcock - 1 1000 OF 10 10012
US_ State U.S. (LAUNT ALL Chapstone LAUNT ALL Constant LAUNT ALL CONTRACTOR C
Murshall Without Fed. 3 Marshall Without Fed. 3 Marsha
Yates Pet, etal 32
1) Storage 1 Long 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
I BAF US US. 1 Stote Conservation 0559522 0 3074 (13978 313919 21997) 2 COS 055 0 102897 ★ Stote US. 1 Stote Conservation 103961 213974 (13978 313919 219972 13974 (13978 313919 21974) 2 COS 05 0 102897
weichetel fer det Francis (107) 0559522 1 011997 1 (Votes Fet, stal) Genoco HOP * Sol Uneven - + + + +
1 JincAng-Sh. Yu Big Troman Line Servers) Lass \$ (D Laufer) Statest John Criservi Anno Servers John
Jyorest - Wonny - Rep the state of the state
Image: Internet intern
Image: State of the state
Pure Bell Austing Instruction Hardson Berl Fault Barton Instruction Hardson Berl Fault Hardson Berl Faul
1 0123 072375 10210 000 100 1000 1000 1000 1000 1000
Nuchson Dig Instant Dig Instant Dig Instant Dig Dig Dig <thdig< th=""> <thdig< th=""> Dig Dig</thdig<></thdig<>
or 3133 3100 Colletti, wassed Colle
Workson Overhand
99028 Ume Rock Sergar Grief (1990) (1
99028 12007 1000 1000 1000 1000 1000 1000 1000
Also
SDA Res SDA
Anne and a state of the state o





SAID STRIP OF LAND BEING 3533.3 FEET OR 214.14 RODS IN LENGTH, CONTAINING 1.622 ACRES MORE OR LESS AND BEING ALLOCATED BY FORTIES AS FOLLOWS.

NE/4 NW/4 - 101.67 RODS OR 0.770 ACRES OF EXISTING ROAD NE/4 NW/4 - 30.24 RODS OR 0.229 ACRES OF NEW ROAD NW/4 NE/4 - 82.23 RODS OR 0.623 ACRES OF NEW ROAD

LEGEND

● - DENOTES FOUND MONUMENT AS NOTED

SURVEYORS CERTIFICATE	1000' 0	1000' 2000' FEET
I, TERRY J. ASEL, NEW MEXICO PROFESSIONAL SURVEYOR NO. 15079, DO HEREBY CERTIFY THAT I CONDUCTED AND AM RESPONSIBLE FOR THIS SURVEY, THAT THIS SURVEY	SCALE: 1"	
TRUE AND CORRECT TO THE BEST OF MY KNOWLEDGRAND BELIEF, AND MEETS THE "MINIMIUM STANDARDS" OF MET SURVEYING IN NEW MEXICO" AS ADOPTED BY THE NEW MET	EOG RESOU	URCES, INC.
MEXICO STATE BOARD OF REGISTRATION FOR PROFESSIONAL ENGINEERS AND SURVEYORS Serve Juse 6///2009 Torry J. Asel N.M. R.P.S. No. 15079 Asel Surveying	SURVEY FOR A I CROSSING STATE OF I SECTION 31, TOWNSHIP 16 N.M.P.M., EDDY CO	NEW MEXICO LAND IN 5 SOUTH, RANGE 28 EAST,
	Survey Date: 05/28/09	Sheet 3 of 4 Sheets
P.O. BOX 393 - 310 W. TAYLOR	W.O. Number: 090528RD	Drawn By: KA
HOBBS, NEW MEXICO - 575-393-9146	Date: 05/30/09	090528RD.DWG Scale:1"=1000'



Permit Information:

Well Name: Lucky Wolf 31 Fed Com #1H

Location:

۲,

· · · _ .

•

SL	330' FNL & 330' FEL, Section 31, T-16-S, R-28-E, Eddy Co., N.M.
BHL	660' FNL & 330' FWL, Section 31, T-16-S, R-28-E, Eddy Co., N.M.

Casing Program:

Casing	Setting Depth	Hole Size	Casing Size	Casing Weight	Casing Grade	Desired TOC
Surface	500'	17-1/2"	13-3/8"	48#	KJ-55	Surface
Intermediate	5,800'	8-3/4"	7"	26#	HCP-110	Surface
Production	10,909'	6-1/8"	4-1/2"	11.6#	HCP-110	5,300'
			· · · · · · · · · · · · · · · · · · ·	•		5600'

Cement Program:

Depth	No.	Slurries:
•	Sacks	
500'	600	Class C Cement + 0.005 lbs/sack Static Free + 2% CaCl ₂ + 0.25 lbs/sack
		Cello Flake + 0.005 gps FP-6L (14.8 ppg / 1.35 yld / 6.35 gps fresh water)
5,800'	850	Lead: Class 'C' + 2.00% SMS + 1.50% R-3 + 0.25 lb/sk Cello Flake + 0.005
		lb/sk Static Free (12.7 ppg / 2.01 yld / 11.2 gps fresh water)
	300	Tail: Class 'C' + 1.00% CaCl ₂ + 0.25 lb/sk Cello Flake + 0.005 lb/sk Static
		Free (14.8 ppg / 1.33 yld / 6.32 gps fresh water)
10,909'		Packer Isolation

Note – actual cement volumes are subject to change based on results of hole calipers (fluid and/or wireline).

Mud Program:

Depth (MD)	Туре	Weight (ppg)	Viscosity	Water Loss
0 - 500'	Fresh - Gel	8.4-9.2	28-34	N/c
500' - 1800'	Fresh Water	8.4	28-34	N/c
1800' - 5,800'	Cut Brine	9.0-9.3	28-34	N/c
5,800' - 6,800'	Cut Brine (Pilot Hole)	9.0-9.3	28-34	N/c
KOP – 10,909'	Cut Brine/ Polymer	9.0-9.3	40-45	10-25
	(Lateral)			

1. GEOLOGIC NAME OF SURFACE FORMATION: Permian

.

1.1

_1

2. ESTIMATED TOPS OF IMPORTANT GEOLOGICAL MARKERS:

Queen	950'
San Andres	1,750'
Glorieta	3,250'
Tubb	4,500'
Abo Shale	5,220'
Wolfcamp	6,405'
Target Landing Point	6,435'
Pilot Hole TD	6,800'

3. ESTIMATED DEPTHS OF ANTICIPATED FRESH WATER, OIL OR GAS:

0-150'	Fresh Water
950'	Oil
1,750'	Oil
3,250'	Oil
4,500'	Oil
5,220'	Oil
6,405'	Oil
	950' 1,750' 3,250' 4,500' 5,220'

No other Formations are expected to give up oil, gas or fresh water in measurable quantities. Surface fresh water sands will be protected by setting 13.375" casing at 500' and circulating cement back to surface.

4. CASING PROGRAM - NEW See COM

Hole		Csg				DF	DF	DF
Size	Interval	OD	Weight	Grade	Conn	Collapse	Burst	Tension
17.5"	0 - 500'	13.375"	48#	K.855	STC	3.09	1.43	1.60
8.75"	500'-5800'	7"	26#	HCP110	LTC	2.78	1.25	1.60
6.125"	5600' – TD	4.5"	11.6#	HCP110	BTC	2.63	1.25	1.60

Cementing Program: 2. COA

1

τ 1

Э

13.375" Surface Casing:	$600\ sx$ - Class C Cement + 0.005 lbs/sack Static Free + 2% CaCl_2 + 0.25 lbs/sack Cello Flake + 0.005 gps FP-6L (14.8 ppg / 1.35 yld / 6.35 gps fresh water)
7" Intermediate Casing:	Cement to surface, Lead: 850 sx Class 'C' + 2.00% SMS + 1.50% R-3 + 0.25 lb/sk Cello Flake + 0.005 lb/sk Static Free (12.7 ppg / 2.01 yld / 11.2 gps fresh water)
	Tail: 300 sx Class 'C' + 1.00% $CaCl_2$ + 0.25 lb/sk Cello Flake + 0.005 lb/sk Static Free (14.8 ppg / 1.33 yld / 6.32 gps fresh water)
4.5" Production Casing:	Packer Isolation

5. MINIMUM SPECIFICATIONS FOR PRESSURE CONTROL: (SEE EXHIBIT #1)

The blowout preventer equipment (BOP) shown in Exhibit #1 will consist of a double ram-type (5000 psi WP) preventer and an annular preventer (5000-psi WP). Units will be hydraulically operated and the ram-type will be equipped with blind rams on bottom and drill pipe rams on top. All BOP's and accessory equipment will be tested in accordance with Onshore Oil & Gas order No. 2. for a 2M system prior to drilling out of the surface casing shoe and while drilling the intermediate section. Before drilling out of the intermediate casing, the ram- type BOP and accessory equipment will be tested to 5000/ 250 psig and the annular preventer to 2500/ 250 psig.

Pipe rams will be operationally checked each 24-hour period. Blind rams will be operationally checked on each trip out of the hole. These checks will be noted on the daily tour sheets.

Hydraulically operated choke will not be installed prior to the setting and cementing of the intermediate casing string, but will be installed prior to drilling out of the intermediate casing shoe.

1 t

,)

6. TYPES AND CHARACTERISTICS OF THE PROPOSED MUD SYSTEM:

The well will be drilled to TD with a combination of brine, cut brine, and polymer mud system. The applicable depths and properties of this system are as follows:

Depth (MD)	Туре	Weight (ppg)	Viscosity_	Water Loss
0-500'	Fresh - Gel	8.4-9.2	28-34	N/c
500' - 1800'	Fresh Water	8.4	28-34	N/c
1800' - 5,800'	Cut Brine	9.0-9.3	28-34	N/c
5,800' - 6,800'	Cut Brine (Pilot Hole)	9.0-9.3	28-34	N/c
KOP – 10,909'	Cut Brine/ Polymer	9.0-9.3	40-45	10-25
	(Lateral)			

Sufficient mud materials to maintain mud properties and meet minimum lost circulation and weight increase requirements will be kept at the wellsite at all times.

7. AUXILIARY WELL CONTROL AND MONITORING EQUIPMENT:

(A) A kelly cock will be kept in the drill string at all times.

(B) A full opening drill pipe-stabbing valve (inside BOP) with proper drill pipe connections will be on the rig floor at all times.

8. LOGGING, TESTING AND CORING PROGRAM: See COA

Open-hole logging is anticipated in the 8-3/4" hole section. The logging suites for this hole section are listed below:

NGT-CNL-LDT w/ Pe	From TD to previous casing shoe. At casing pull GR – Neutron to surface.
HR Laterolog Array	From TD to previous casing shoe.
FMI	Possible in the production hole

9. ABNORMAL CONDITIONS, PRESSURES, TEMPERATURES AND POTENTIAL HAZARDS:

The estimated bottom hole temperature (BHT) at TD is 140 degrees F with an estimated maximum bottom-hole pressure (BHP) at TD of 2810 psig. No hydrogen sulfide or other hazardous gases or fluids have been encountered, reported or are known to exist at this depth in this area. No major loss circulation zones have been reported in offsetting wells.

ı.

1.1

4

10. ANTICIPATED STARTING DATE AND DURATION OF OPERATIONS:

The drilling operation should be finished in approximately one month. If the well is productive, an additional 30-60 days will be required for completion and testing before a decision is made to install permanent facilities.



Seogresources

EOG Resources, Inc.

Eddy County Lucky Wolf 31 Fed Com #1H OH

Plan: Plan #1

Pathfinder X & Y Planning Report

06 August, 2009









Project: Eddy Cc Site: Lucky W Well: #1H Wellbore: OH Design: Plan #1	olf 31 Fed Com		Local Co-ordinate TVD Reference: MD Reference: North Reference: Survey Calculatio Database:	WELL @ 3538.60ft (N WELL @ 3538.60ft (N Grid	AcVay #4 19' KB Correction) AcVay #4 19' KB Correction)
Project	Eddy County	- Annual Information Contraction Contraction Contraction Contraction Contraction Contraction Contraction Contra - Annual Information Contraction Contraction Contraction Contraction Contraction Contraction Contraction Contra	and the second	eroneous a l'arterne concernances en est	
Geo Datum: NAD	tate Plane 1927 (Exact solution) 1927 (NADCON CONUS) Mexico East 3001		System Datum:	Mean Sea Level	
Site	Lucky Wolf 31 Fed Com	an a	and a start and and a second second second second and a second second second second second second second second	anna an ann an an ann an ann an ann an a	annathar and the the the state of a second of a second of the second of the second of the second of the second
Site Position: From: M Position Uncertainty:	1ap 0 00 ft	Northing: Easting: Slot Radius:	685,484.700 ft 538,736 600 ft "	Latitude: Longitude: Grid Convergence:	32° 53' 3.893 N 104° 12' 25.734 W 0.07 °
Well	#1H				
Well Position +N/- +E/-\ Position Uncertainty		Northing: Easting: Wellhead Elevation:	685,484.700 ft 538,736 600 ft ft	Latitude: Longitude: Ground Level:	32° 53' 3.893 N 104° 12' 25.734 W 3.519.60 ft
• Wellbore	OH				
Magnetics V	lodel Name Sample Date IGRF200510 08/06/200	(0)	Dip Angle Field Stro (f) 60 75		
Design	Plan #1				
Audit Notes: Version:	Phase:	PLAN Tie On Dep	oth: 0.00		
Vertical Section:	Depth From (TVD) (ft) 0 00	+N/-S +E/-W (ft) (ft) 0.00 0.00	Direction () 265.52		
Sŭrvey Tool Program From (ft)		Tool Name	Description		
0.00 10,	909.29 Plan #1 (OH)	MWD	MWD - Standard		

08/06/2009 3 10 52PM

COMPASS 2003.16 Build 42

Seogresources

Pathfinder X & Y Planning Report



Project: Ed Site: Lu Well: #1 Wellbore: Of Design: 1						ocal Co-ordinate. VD Reference: ID Reference: Jorth Reference: Survey Calculation Jatabase.	WI WI Gr Method:	ELL @ 3538.60		
Planned Survey			الم الم الم الم				2. • • • • · · · · · · · · · · · · · · ·		- 100 - 100	
MD		Azi	TVD	TVDSS)Leg	Northing	Easting
0.00	0.00	(°). 0.00	0.00	(ft) -3,538.60	0 00	(ft) 0.00	(ft) 0.00	100ft) 0.00	685,484 70	(ft) 538,736.60
100.00	0.00	0.00	100.00	-3,438.60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
200 00	0.00	0.00	200.00	-3,338 60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
300.00	0.00	0.00	300.00	-3,238 60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
400.00	0.00	0.00	400 00	-3,138 60	0 00	0.00	0.00	0.00	685,484 70	538,736.60
500.00	0 00	0 00	500.00	-3,038.60	0.00	0.00	0 00	0.00	685,484 70	538,736.60
600.00	0.00	0 00	600 00	-2,938 60	0.00	0.00	0.00	0.00	685,484.70	538,736 60
700 00	0.00	0.00	700.00	-2,838.60	0 00	0.00	0.00	0.00	685,484.70	538,736 60
800.00	0 00	0 00	800 00	-2,738.60	0.00	0 00	0 00	0.00	685,484 70	538,736.60
900.00	0.00	0 00	900 00	-2,638.60	0.00	0.00	0 00	0.00	685,484 70	538,736 60
1,000.00	0.00	0.00	1,000.00	-2,538.60	0 00	0.00	0 00	0 00	685,484.70	538,736 60
1,100.00	0.00	0.00	1,100.00	-2,438 60	0.00	0 00	0.00	0.00	685,484.70	538,736.60
1,200.00	0.00	0.00	1,200.00	-2,338.60	0.00	0.00	0 00	0 00	685,484.70	538,736.60
1,300 00	0.00	0.00	1,300.00	-2,238.60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
1,400.00	0.00	0.00	1,400 00	-2,138.60	0.00	0.00	0.00	0.00	685,484.70	538,736 60
1,500.00	0.00	0.00	1,500.00	-2,038.60	0.00	0.00	0 00	0.00	685,484.70	538,736.60
1,600 00	0.00	0 00	1,600.00	-1,938.60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
1,700.00	0 00	0.00	1,700 00	-1,838.60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
1,800.00	0.00	0.00	1,800.00	-1,738 60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
1,900.00	0.00	0 00	1,900 00	-1,638.60	0.00	0.00	0.00	0.00	685,484.70	538,736 60
2,000.00	0 00	0.00	2,000 00	-1,538 60	0.00	0 00	0 00	0.00	685,484.70	538,736.60
2,100 00	0.00	0.00	2,100.00	-1,438 60	0 00	0.00	0.00	0.00	685,484.70	538,736.60
2,200.00	0.00	0.00	2,200 00	-1,338.60	0 00	0 00	0.00	0.00	685,484 70	538,736.60
2,300 00	0 00	0 00	2,300.00	-1,238 60	0 00	0.00	0.00	0.00	685,484.70	538,736.60
2,400.00	0 00	0.00	2,400 00	-1,138.60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
2,500.00	0.00	0.00	2,500 00	-1,038.60	0 00	0.00	0.00	0.00	685,484.70	538,736.60
2,600.00	0.00	0.00	2,600 00	-938.60	0.00	0 00	0.00	0.00	685,484.70	538,736 60

08/06/2009 3.10[.]52PM

COMPASS 2003.16 Build 42





Project: Eddy C	Nolf 31 Fed Com					ocăl Co-ordinate IVD Reference: VD Reference: North Reference: Survey Calculatior Database:	WI WI Gr Method: Mi	ELL @ 3538.60		
Planned Survey						and a state of the	and the second			
MD (ft)		Azi	TVD (ft)		N/S (ft)) 2 100ft)	Northing (ft)	Easting (ft),
2,700.00	م <u>ت المحملة مت</u> مثلية الطالاتين. 0.00	0.00	2,700 00	-838 60	0.00	0.00	0.00	ند المراب المرابع من ا 0.00	685,484 70	538,736.60
2,800.00	0.00	0.00	2,800.00	-738.60	0 00	0.00	0.00	0.00	685,484.70	538,736.60
2,900.00	0 00	0.00	2,900.00	-638 60	0.00	0 00	0.00	0 00	685,484.70	538,736.60
3,000.00	0.00	0.00	3,000.00	-538.60	0.00	0.00	0.00	0.00	685,484.70	538,736 60
3,100.00	0 00	0 00	3,100 00	-438 60	0.00	0.00	0.00	0.00	685,484.70	538,736.60
3,200.00	0.00	0.00	3,200.00	-338.60	0.00	0 00	0.00	0 00	685,484.70	538,736.60
3,300.00	0.00	0 00	3,300.00	-238.60	0.00	0.00	0.00	0.00	685,484.70	538,736 60
3,400.00	0.00	0.00	3,400.00	-138.60	0.00	0 00	0.00	0 00	685,484.70	538,736.60
3,500.00	0.00	0.00	3,500.00	-38.60	0.00	0.00	0 00	0.00	685,484.70	538,736.60
3,600.00	0.00	0 00	3,600 00	61.40	0.00	0 00	0 00	0.00	685,484.70	538,736.60
3,700.00	0 00	0.00	3,700.00	161.40	0.00	0.00	0.00	0.00	685,484.70	538,736.60
3,800.00	0.00	0 00	3,800.00	261.40	0.00	0.00	0.00	0.00	685,484 70	538,736.60
3,900 00	0.00	0.00	3,900 00	361 40	0.00	0 00	0 00	0 00	685,484.70	538,736.60
4,000.00	0.00	0 00	4,000.00	461 40	0.00	0.00	0.00	0.00	685,484.70	538,736.60
4,100 00	0.00	0.00	4,100.00	561 40	0.00	0 00	0 00	0.00	685,484 70	538,736.60
4,200.00	0.00	0.00	4,200 00	661.40	0.00	0.00	0.00	0.00	685,484.70	538,736.60
4,300 00	0.00	0 00	4,300.00	761.40	0.00	0.00	0.00	0 00	685,484.70	538,736.60
4,400.00	0.00	0.00	4,400.00	861.40	0.00	0.00	0 00	0.00	685,484 70	538,736 60
4,500 00	0.00	0.00	4,500.00	961.40	0.00	0 00	0.00	0 00	685,484.70	538,736.60
4,600.00	0 00	0.00	4,600.00	1,061.40	0 00	0.00	0.00	0.00	685,484.70	538,736.60
4,700.00	0.00	0.00	4,700 00	1,161.40	0.00	0.00	0.00	0.00	685,484.70	538,736.60
4,800.00	0.00	0 00	4,800 00	1,261.40	0 00	0 00	0.00	0.00	685,484 70	538,736 60
4,900.00	0 00	0.00	4,900 00	1,361.40	0.00	0 00	0.00	0.00	685,484.70	538,736.60
5,000.00	0 00	0 00	5,000.00	1,461 40	0.00	0 00	0 00	0.00	685,484.70	538,736.60
5,100.00	0 00	0 00	5,100.00	1,561.40	0.00	0.00	0.00	0.00	685,484.70	538,736.60
5,200.00	0.00	0.00	5,200.00	1,661.40	0 00	0 00	0.00	0 00	685,484.70	538,736 60
5,300.00	0.00	0.00	5,300.00	1,761.40	0.00	0.00	0.00	0.00	685,484.70	538,736.60



Pathfinder Energy Services

Pathfinder X & Y Planning Report



Project: Eddy C	Wolf 31 Fed Com					Local Co-ordinate TVD Reference: MD Reference: North Reference: Survey Calculatio Database:	W W G Method: M			
Planned Survey								i wa nakao kaza		The second s
MD (ft)	(n)	Azi (°)	ĨīVD (ft)	TVDSS (ftt)	N/S (ft)	E/W (ft)		DLeg /100ft)	Northing (ft)	Easting (ft)
5,400.00	0 00	0.00	5,400 00	1,861.40	0.00	0 00	0.00	0.00	685,484.70	538,736.60
5,500 00	0 00	0 00	5,500.00	1,961.40	0.00	0.00	0.00	0.00	685,484.70	538,736.60
5,600.00	0.00	0.00	5,600 00	2,061.40	0.00	0.00	0 00	0.00	685,484.70	538,736.60
5,700.00	0.00	0 00	5,700.00	2,161.40	0.00	0.00	0.00	0.00	685,484 70	538,736.60
5,800 00	0.00	0.00	5,800.00	2,261 40	0.00	0 00	0.00	0 00	685,484.70	538,736.60
5,900 00	0.00	0.00	5,900.00	2,361 40	0.00	0.00	0 00	0.00	685,484.70	538,736.60
5,957.50	0.00	0.00	5,957.50	2,418.90	0.00	0 00	0.00	0 00	685,484.70	538,736.60
KOP-5957.50'MI	D,0.00°INC,0.00°A	ZI,5957.50'TVD								
5,975.00	2.10	265.52	5,975.00	2,436 40	-0 03	-0.32	0 32	12.00	685,484.67	538,736.28
6,000 00	5 10	265.52	5,999.94	2,461 34	-0.15	-1 88	1.89	12.00	685,484.55	538,734.72
6,025 00	8.10	265.52	6,024.78	2,486.18	-0 37	-4.75	4.76	12 00	685,484.33	538,731.85
6,050.00	11.10	265.52	6,049.42	2,510.82	-0.70	-8.90	8.93	12.00	685,484.00	538,727.70
6,075.00	14.10	265.52	6,073 82	2,535.22	-1.12	-14.34	14.38	12 00	685,483.58	538,722.26
6,100.00	17.10	265.52	6,097.89	2,559.29	-1.65	-21.04	21.11	12 00	685,483.05	538,715.56
6,125.00	20.10	265.52	6,121.59	2,582 99	-2.27	-28.99	29.08	12.00	685,482.43	538,707.61
6,150.00	23.10	265.52	6,144 83	2,606 23	-2.99	-38.16	38.28	12.00	685,481.71	538,698.44
6,175.00	26.10	265 52	6,167.56	2,628.96	-3.80	-48.54	48.68	12.00	685,480.90	538,688 06
6,200.00	29.10	265 52	6,189.71	2,651.11	-4.71	-60 08	60 27	12.00	685,479.99	538,676.52
6,225.00	32.10	265 52	6,211.23	2,672 63	-5 70	-72.77	72.99	12.00	685,479.00	538,663 83
6,250.00	35.10	265 52	6,232 05	2,693.45	-6.78	-86 56	86 82	12.00	685,477 92	538,650.04
6,275.00	38.10	265.52	6,252 12	2,713.52	-7.95	-101 41	101 72	12.00	685,476.75	538,635.19
6,300.00	41.10	265 52	6,271 38	2,732 78	-9 19	-117.30	117.66	12 00	685,475 51	538,619.30
6,325.00	44.10	265 52	6,289 78	2,751.18	-10.51	-134 16	134 58	12.00	685,474.19	538,602 44
6,350.00	47.10	265.52	6,307.27	2,768 67	-11.91	-151.97	152.43	12 00	685,472.79	538,584.63
6,375.00	50.10	265.52	6,323 80	2,785.20	-13.37	-170 66	171.18	12.00	685,471.33	538,565.94
6,400.00	53.10	265 52	6,339.33	2,800.73	-14.90	-190.19	190.77	12.00	685,469 80	538,546.41
6,425 00	56.10	265.52	6,353.81	2,815.21	-16.49	-210 50	211.15	12.00	685,468 21	538,526.10

08/06/2009 3:10·52PM

COMPASS 2003.16 Build 42





Project: Eddy	Resources, Inc. County Wolf 31 Fed Com					Local Co-ordina TVD Reference MD Reference North Reference	N . N)ft (McVay #4 19' ł)ft (McVay #4 19' ł	
Wellbore: Design:	#1		الله الله المحمد المراجع المراجع المحمد ا المحمد المحمد المحمد المحمد المحمد			Survey Calculat		inimum Curvatu idland Database		i. E
Carl Carl Carl						Database:				
Planned Survey			ار اور اور اور اور اور اور اور اور اور ا	مىرىيى بىرىيى بىرىي بىرىيى بىرىيى			· · · · · · · · · · · · · · · · · · ·		10	
MD (ft)	inc ()	Azi	TVD (ft)	TVDSS (ft)	N/S	19 1 J L L 19 1		DLeg /100ft)	Northing (ft)	Easting (ft)
6,450.00	59.10	265.52	6,367.21	2,828 61	-18 14	-231.54	232.25	12.00	685,466 56	538,505.06
6,475.00	62.10	265.52	6,379.48	2,840.88	-19 84	-253.25	254.03	12.00	685,464.86	538,483.35
6,500.00	65.10	265.52	6,390 60	2,852.00	-21.59	-275.57	276.42	12.00	685,463 11	538,461.03
6,525 00	68 09	265 52	6,400.53	2,861.93	-23 38	-298 44	299.36	12.00	685,461.32	538,438.16
6,537.39	69 58	265.52	6,405.00	2,866.40	-24.29	-309.97	310.92	12.00	685,460.41	538,426.63
Top of Wolfcar	np - 6537.39'MD,69	9.58°INC,265.52°	AZ1,6405.00'TVD							
6,550.00	71.09	265.52	6,409.24	2,870.64	-25.21	-321 80	322,79	12 00	685,459 49	538,414.80
6,575.00	74.09	265 52	6,416.72	2,878 12	-27.08	-345.58	346.64	12.00	685,457.62	538,391.02
.6,600.00	77.09	265.52	6,422 94	2,884.34	-28 97	-369.72	370 85	12.00	685,455.73	538,366.88
6,625 00	80.09	265.52	6,427.88	2,889.28	-30.88	-394.15	395.36	12.00	685,453.82	538,342.45
6,650.00	83.09	265.52	6,431.54	2,892.94	-32.81	-418.80	420.08	12.00	685,451.89	538,317.80
6,675.00	86 09	265.52	6,433.89	2,895 29	-34.76	-443 61	444.97	12 00	685,449 94	538,292 99
6,700 00	89.09	265.52	6,434.94	2,896.34	-36 71	-468.51	469.95	12.00	685,447 99	538,268.09
6,707.56	90.00	265.52	6,435 00	2,896.40	-37.30	-476.04	477 50	12 00	685,447.40	538,260.56
EOC-6707.56'N	ID,90.00°INC,265.5	2°AZI,6435.00'T\	D,12.00°DLS, 47	7.50'VS, -37.30'N, -	476.05'E					
6,800 00	90.00	265 52	6,435.00	2,896.40	-44 52	-568.20	569 94	0.00	685,440 18	538,168.40
6,900.00	90.00	265 52	6,435 00	2,896.40	-52.33	-667.90	669.94	0.00	685,432.37	538,068.70
7,000 00	90.00	265.52	6,435.00	2,896 40	-60.14	-767 59	769.94	0.00	685,424.56	537,969.01
7,100.00	90.00	265.52	6,435 00	2,896 40	-67.95	-867.29	869.94	0.00	685,416.75	537,869.31
7,200.00	90.00	265.52	6,435.00	2,896 40	-75.76	-966.98	969.94	0.00	685,408.94	537,769.62
7,300 00	90.00	265.52	6,435.00	2,896.40	-83.57	-1,066.68	1,069.94	0.00	685,401.13	537,669.92
7,400.00	90 00	265.52	6,435.00	2,896.40	-91 39	-1,166.37	1,169 94	0.00	685,393.31	537,570.23
7,500.00	90.00	265.52	6,435 00	2,896 40	-99.20	-1,266.06	1,269.94	0.00	685,385 50	537,470.54
7,600 00	90.00	265 52	6,435.00	2,896 40	-107.01	-1,365 76	1,369.94	0.00	685,377 69	537,370.84
7,700 00	90.00	265.52	6,435.00	2,896 40	-114.82	-1,465.45	1,469 94	0.00	685,369.88	537,271.15
7,800 00	90.00	265 52	6,435.00	2,896 40	-122.63	-1,565 15	1,569.94	0.00	685,362.07	537,171.45
7,900.00	90 00	265.52	6,435.00	2,896.40	-130.44	-1,664.84	1,669 94	0.00	685,354.26	537,071.76





Project: Site: Well: Wellbore: C	OG Resources, Inc. ddy County ucky Wolf 31 Fed Com 1H DH Van #1	1997 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1997 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 -				Local Co-ordina TVD-Reference: MD Reference North Reference Survey Calculat Database	w w ion (Method:	ELL @ 3538.60		1-
Planned Survey										
MD (ft)		Azi (°)	TVD (ft)	TVDSS (ft)	(n)/S	E/W (ft)		DLeg /100ft)	Northing ≉ (ft)	Easting (ft)
8,000.00	90.00	265.52	6,435 00	2,896.40	-138.25	-1,764.54	1,769.94	0.00	685,346.45	536,972.06
8,100.00	90.00	265.52	6,435.00	2,896 40	-146 06	-1,864 23	1,869.94	0.00	685,338.64	536,872.37
8,200.00	90.00	265.52	6,435.00	2,896.40	-153.87	-1,963.93	1,969.94	0 00	685,330.83	536,772.67
8,300 00	90.00	265 52	6,435 00	2,896.40	-161.69	-2,063.62	2,069 94	0.00	685,323.01	536,672.98
8,400.00	90.00	265 52	6,435.00	2,896 40	-169 50	-2,163.31	2,169.94	0.00	685,315 20	536,573.29
8,500.00	90.00	265.52	6,435 00	2,896.40	-177.31	-2,263.01	2,269 94	0 00	685,307.39	536,473.59
8,600.00	90 00	265.52	6,435.00	2,896.40	-185.12	-2,362.70	2,369.94	0 00	685,299.58	536,373.90
8,700.00	90.00	265.52	6,435.00	2,896 40	-192.93	-2,462.40	2,469.94	0.00	685,291.77	536,274.20
8,800.00	90.00	265.52	6,435.00	2,896.40	-200.74	-2,562 09	2,569 94	0.00	685,283.96	536,174.51
8,900.00	90.00	265.52	6,435 00	2,896.40	-208.55	-2,661.79	2,669.94	0.00	685,276.15	536,074.81
9,000.00	90 00	265.52	6,435.00	2,896.40	-216 36	-2,761.48	2,769.94	0.00	685,268 34	535,975.12
9,100 00	90.00	265.52	6,435.00	2,896 40	-224.17	-2,861.18	2,869.94	0.00	685,260.53	535,875 42
9,200.00	90.00	265.52	6,435.00	2,896.40	-231 99	-2,960 87	2,969 94	0.00	685,252.71	535,775.73
9,300 00	90.00	265.52	6,435.00	2,896.40	-239.80	-3,060.57	3,069.94	0.00	685,244 90	535,676.03
9,400 00	90.00	265.52	6,435.00	2,896 40	-247.61	-3,160.26	3,169.94	0 00	685,237.09	535,576.34
9,500.00	90.00	265.52	6,435.00	2,896 40	-255.42	-3,259 95	3,269.94	0 00	685,229.28	535,476.65
9,600.00	90 00	265.52	6,435.00	2,896.40	-263.23	-3,359.65	3,369.94	0 00	685,221.47	535,376.95
9,700.00	90.00	265.52	6,435.00	2,896.40	-271 04	-3,459 34	3,469 94	0.00	685,213.66	535,277.26
9,800 00	90.00	265.52	6,435.00	2,896.40	-278.85	-3,559.04	3,569.94	0.00	685,205.85	535,177.56
9,900.00	90.00	265.52	6,435.00	2,896 40	-286.66	-3,658.73	3,669.94	0 00	685,198.04	535,077 87
10,000.00	90 00	265.52	6,435 00	2,896.40	-294.47	-3,758 43	3,769.94	0.00	685,190.23	534,978.17
10,100.00	90 00	265.52	6,435.00	2,896 40	-302.29	-3,858.12	3,869.94	0.00	685,182.41	534,878.48
10,200.00	90.00	265 52	6,435.00	2,896 40	-310.10	-3,957.82	3,969.94	0 00	685,174.60	534,778.78
10,300.00	90.00	265.52	6,435 00	2,896.40	-317.91	-4,057.51	4,069 94	0.00	685,166.79	534,679.09
10,400 00	90.00	265 52	6,435 00	2,896.40	-325.72	-4,157.20	4,169.94	0 00	685,158 98	534,579.40
10,500 00	90.00	265 52	6,435.00	2,896.40	-333.53	-4,256 90	4,269 94	0.00	685,151.17	534,479.70
10,600 00	90.00	265.52	6,435 00	2,896.40	-341.34	-4,356.59	4,369.94	0 00	685,143 36	534,380.01

COMPASS 2003.16 Build 42





Project: Eddy Co	sources, Inc. unty lolf 31 Fed Com					Local Co-ordinat TVD Reference: MD Reference: North Reference Survey Calculatio Database:	W W Gr Dn.Method:	ELL @ 3538 60		
Planned Survey.										and a second star at
MD (ft)	Inc (°)	Azi'	TVD (ft)	rvDSS (ft)	N/S (ft)	ĒŴ (ft)	V: Sec		Northing (ft)	Easting (ft)
10,700.00	90.00	265.52	6,435.00	2,896.40	-349.15	-4,456.29	4,469.94	0.00	685,135.55	534,280.31
10,800 00	90.00	265 52	6,435.00	2,896.40	-356 96	-4,555 98	4,569.94	0.00	685,127.74	534,180.62
10,909.29	90.00	265.52	6,435.00	2,896.40	-365.50	-4,664.94	4,679.23	0.00	685,119.20	534,071 66
Färgets Farget Name Hil/Miss target Shape	Dip Angle.	Dip Dir:	ŢŲĎ (ft)	+N/-S (ft)	+E/-W	Northing (ft)	Eastinĝ	Latitu	ide.	gitude
PBHL(LW31#1H) - plan misses by 4.46 - Point	0.00 ft at 10909.29ft ME	0 00 0 (6435.00 TVD, -:	6,435.00 365.50 N, -4664.9	-365 50 4 E)	-4,669 40	685,119 200	534,067.2	00 32° 53'	0.328 N 104° 13	3' 20.497 W
Plan Annotations	Sinta Indenia.	X.Z	ant and a second a second	a', and the second at	C.C. Color Lood	, elurer and area at modernstates	- more and a strain the stars.	and the second		
Méasured Depth (ft)	Vertical. Depth		rdinåtes +E/∙W (ft)	Comment						
5,957.50		0.00	0.00		/D,0.00°INC,0.00°					
6,537.39		-24.29	-309.97	•	•	9.58°INC,265.52°AZ				
6,707.56	,	-37 30	-476.04			.52°AZI,6435.00'TVI	D,12.00°DLS, 477			
10,909.29	6,435.00	-365.50	-4,664.94	TD at 10909.29	J					
				Approved By:				Dato:		

Approved By:

Date:





ATTACHMENT TO EXHIBIT #1

- 1. Wear ring to be properly installed in head.
- 2. Blow out preventer and all fittings must be in good condition, 5000 psi W.P. minimum. Exhibit #1.
- 3. All fittings to be flanged

4

1.

.

- 4. Safety valve must be available on rig floor at all times with proper connections, valve to be full bore 5000 psi W.P. minimum.
- 5. All choke and fill lines to be securely anchored especially ends of choke lines.
- 6. Equipment through which bit must pass shall be at least as large as the diameter of the casing being drilled through.
- 7. Kelly cock on kelly.
- 8. Extension wrenches and hand wheels to be properly installed.
- 9. Blow out preventer control to be located as close to driller's position as feasible.
- 10. Blow out preventer closing equipment to include minimum 40-gallon accumulator, two independent sources of pump power on each closing unit installation, and meet all API specifications.

'n

EOG Resources, Inc. Lucky Wolf 31 Fed (om 14



. a.~.>.

WELL NAME: Lucky Wolf 31 Fed lon 14 Exhibit 1a ۰.



5M CHOKE MANIFOLD EQUIPMENT - CONFIGURATION OF CHOKES MAY VARY

Although not required for any of the choke manifold systems, buffer tanks are sometimes installed downstream of the choke assemblies for the purpose of manifolding the bleed lines together. When buffer tanks are employed, valves shall be installed upstream to isolate a failure or malfunction without interrupting flow control. Though not shown on 2M, 3M, 10M, OR 15M drawings, it would also be applicable to those situations.

[54 FR 39528, Sept. 27, 1989]

ş

Profile View of Piping from Choke Manifold to the Mud Gas Separator



Aerial View of the Piping from the Choke Manifold to the Mud Gas Separator







Legals: Lucky Wolf 31 Fed. COM 1H Eddy Co. New Mexico 330' FNL & 330' FEL Surface Location 660' FNL & 3 Section 31 T-16-S, R-28-E Lat: N 32.8844148

Long: W 104.2071482

660' FNL & 330' FWL Bottom of Hole Location Section 31 T-16-S, R-28-E Lat: N 32.8834244 Long: W 104.2223601

<section-header><section-header>



Safety Solutions, LLC 3222 Commercial Dr. (432) 686-8555 Midland, TX 79701



I. H₂S Contingency Plan

а ар с э э

- a. Scope
- b. Objective
- c. Discussion of Plan

II. Emergency Procedures

- a. Emergency Procedures
- b. Emergency Reaction Steps
- c. Simulated Blowout Control Drills

III. Ignition Procedures

- a. Responsibility
- b. Instructions

IV. Training Requirements

V. Emergency Equipment

VI. Check Lists

- a. Status Check List
- b. Procedural Check List

VII. Briefing Procedures

VIII. Evacuation Plan

- a. General Plan
- b. Emergency Phone Lists

IX. Maps and Plats

- a. Location Plat
- b. Map to Location
- c. Radius of Exposure

X. General Information

- a. Drilling/Re-entry Permits
- b. H-9 Permit
- c. H₂S Permissible Limits
- d. Toxicity Table
- e. Physical Properties
- f. Respirator Use
- g. Emergency Rescue

H₂S CONTINGENCY PLAN SECTION

Scope:

• · · · ·

This contingency plan provides an organized plan of action for alerting and protecting the public within an area of exposure prior to an intentional release, or following the accidental release of a potentially hazardous volume of hydrogen sulfide. The plan establishes guidelines for all personnel whose work activity may involve exposure to Hydrogen Sulfide Gas (H_2S).

Objective:

Prevent any and all accidents, and prevent the uncontrolled release of H₂S into the atmosphere.

Provide proper evacuation procedures to cope with emergencies.

Provide immediate and adequate medical attention should an injury occur.

Discussion of Plan:

Suspected Problem Zones:

Implementation: This plan, with all details, is to be fully implemented 1000' before drilling into the first sour zone.

Emergency Response Procedure: This section outlines the conditions and denotes steps to be taken in the event of an emergency.

Emergency Equipment and Procedure: This section outlines the safety and emergency equipment that will be required for the drilling of this well.

Training Provisions: This section outlines the training provisions that must be adhered to 1000' before drilling into the first sour zone.

Emergency call list: Included are the telephone numbers of all persons that would need to be contacted, should an H₂S emergency occur.

Briefing: This section deals with the briefing of all persons involved with the drilling of this well.

Public Safety: Public Safety Personnel will be made aware of the drilling of this well.

Check Lists: Status check lists and procedural check lists have been included to ensure adherence to the plan.

General Information: A general information section has been included to supply support information.



- I. In the event of any evidence of H₂S level above 10ppm, take the following steps immediately:
 - a. Secure breathing apparatus.
 - b. Order non-essential personnel out of the danger zone.
 - c. Take steps to determine if the H₂S level can be corrected or suppressed, and if so, proceed with normal operations.
- II. If uncontrollable conditions occur, proceed with the following:
 - a. Take steps to protect and/or remove any public downwind of the rig, including partial evacuation or isolation. Notify necessary public safety personnel and the New Mexico Oil Conservation Division of the situation.
 - b. Remove all personnel to the Safe Briefing Area.
 - c. Notify public safety personnel for help with maintaining roadblocks and implementing evacuation.
 - d. Determine and proceed with the best possible plan to regain control of the well. Maintain tight security and safety measures.
- III. Responsibility:

ι , **λ** λ

- a. The Company Approved Supervisor shall be responsible for the total implementation of the plan.
- b. The Company Approved Supervisor shall be in complete command during any emergency.
- c. The Company Approved Supervisor shall designate a back up Supervisor in the event that he/she is not available.

EMERGENCY PROCEDURE IMPLEMENTATION

I. Drilling or Tripping

1 1 2 1

a. All Personnel

- i. When alarm sounds, don escape unit and report to upwind Safe Briefing Area.
- ii. Check status of other personnel (buddy system).
- iii. Secure breathing apparatus.
- iv. Wait for orders from supervisor.

b. Drilling Foreman

- i. Report to the upwind Safe Briefing Area.
- **ii.** Don Breathing Apparatus and return to the point of release with the Tool Pusher or Driller (buddy system).
- iii. Determine the concentration of H₂S.
- iv. Assess the situation and take appropriate control measures.

c. Tool Pusher

- i. Report to the upwind Safe Briefing Area.
- **ii.** Don Breathing Apparatus and return to the point of release with the Drilling Foreman or the Driller (buddy system).
- iii. Determine the concentration of H₂S.
- iv. Assess the situation and take appropriate control measures.

d. Driller

- i. Check the status of other personnel (in a rescue attempt, always use the buddy system).
- **ii.** Assign the least essential person to notify the Drilling Foreman and Tool Pusher, in the event of their absence.
- **iii.** Assume the responsiblility of the Drilling Foreman and the Tool Pusher until they arrive, in the event of their absence.



- e. Derrick Man and Floor Hands
 - i. Remain in the upwind Safe Briefing Area until otherwise instructed by a supervisor.
- f. Mud Engineer
 - i. Report to the upwind Safe Briefing Area.
 - ii. When instructed, begin check of mud for pH level and H₂S level.

g. Safety Personnel

- i. Don Breathing Apparatus.
- ii. Check status of personnel.
- iii. Wait for instructions from Drilling Foreman or Tool Pusher.

II. Taking a Kick

- a. All Personnel report to the upwind Safe Briefing Area.
- b. Follow standard BOP procedures.

III. Open Hole Logging

- a. All unnecessary personnel should leave the rig floor.
- **b.** Drilling Foreman and Safety Personnel should monitor the conditions and make necessary safety equipment recommendations.

IV. Running Casing or Plugging

- a. Follow "Drilling or Tripping" procedures.
- **b.** Assure that all personnel have access to protective equipment.

SIMULATED BLOWOUT CONTROL DRILLS

١

(7)

All drills will be initiated by activating alarm devices (air horn). One long blast, on the air horn, for ACTUAL and SIMULATED Blowout Control Drills. This operation will be performed by the Drilling Foreman or Tool Pusher at least one time per week for each of the following conditions, with each crew:

Drill #1	Bottom Drilling
	ŕ
Drill #2	Tripping Drill Pipe

In each of these drills, the initial reaction time to shutting in the well shall be timed as well as the total time for the crew to complete its entire pit drill assignment. The times must be recorded on the IADC Driller's Log as "Blowout Control Drill".

Drill No.: Reaction Time to Shut-In: minutes, seconds. Total Time to Complete Assignment: minutes, seconds.

I. Drill Overviews

- a. Drill No. 1 Bottom Drilling
 - i. Sound the alarm immediately.
 - ii. Stop the rotary and hoist Kelly joint above the rotary table.
 - iii. Stop the circulatory pump.
 - iv. Close the drill pipe rams.
 - v. Record casing and drill pipe shut-in pressures and pit volume increases.
- b. Drill No. 2 Tripping Drill Pipe
 - i. Sound the alarm immediately.
 - ii. Position the upper tool joint just above the rotary table and set the slips.
 - iii. Install a full opening valve or inside blowout preventer tool in order to close the drill pipe.
 - iv. Close the drill pipe rams.
 - v. Record the shut-in annular pressure.
- II. Crew Assignments
a. Drill No. 1 - Bottom Drilling

i. Driller

і э

- 1. Stop the rotary and hoist Kelly joint above the rotary table.
- 2. Stop the circulatory pump.
- 3. Check Flow.
- 4. If flowing, sound the alarm immediately
- 5. Record the shit-in drill pipe pressure
- 6. Determine the mud weight increase needed or other courses of action.
- ii. Derrickman
 - 1. Open choke line valve at BOP.
 - 2. Signal Floor Man #1 at accumulator that choke line is open.
 - 3. Close choke and upstream valve after pipe tam have been closed.
 - 4. Read the shut-in annular pressure and report readings to Driller.
- iii. Floor Man #1
 - 1. Close the pipe rams after receiving the signal from the Derrickman.
 - 2. Report to Driller for further instructions.
- iv. Floor Man #2
 - 1. Notify the Tool Pusher and Operator representative of the H₂S alarms.
 - 2. Check for open fires and, if safe to do so, extinguish them.
 - 3. Stop all welding operations.
 - 4. Turn-off all non-explosions proof lights and instruments.
 - 5. Report to Driller for further instructions.
- v. Tool Pusher
 - 1. Report to the rig floor.
 - 2. Have a meeting with all crews.



- 3. Compile and summarize all information.
- 4. Calculate the proper kill weight.
- 5. Ensure that proper well procedures are put into action.
- vi. Operator Representative
 - 1. Notify the Drilling Superintendent.
 - 2. Determine if an emergency exists and if so, activate the contingency plan.
- b. Drill No. 2 Tripping Pipe
 - i. Driller
 - 1. Sound the alarm immediately when mud volume increase has been detected.
 - 2. Position the upper tool joint just above the rotary table and set slips.
 - 3. Install a full opening valve or inside blowout preventer tool to close the drill pipe.
 - 4. Check flow.
 - 5. Record all data reported by the crew.
 - 6. Determine the course of action.
 - ii. Derrickman
 - 1. Come down out of derrick.
 - 2. Notify Tool Pusher and Operator Representative.
 - 3. Check for open fires and, if safe to do so, extinguish them.
 - 4. Stop all welding operations.
 - 5. Report to Driller for further instructions.
 - iii. Floor Man #1
 - 1. Pick up full opening valve or inside blowout preventer tool and stab into tool joint above rotary table (with Floor Man #2).
 - 2. Tighten valve with back-up tongs.

к т т

- 3. Close pipe rams after signal from Floor Man #2.
- 4. Read accumulator pressure and check for possible high pressure fluid leaks in valves or piping.
- 5. Report to Driller for further instructions.
- iv. Floor Man #2
 - 1. Pick-up full opening valve or inside blowout preventer tool and stab into tool joint above rotary table (with Floor Man #1).
 - 2. Position back-up tongs on drill pipe.
 - 3. Open choke line valve at BOP.
 - 4. Signal Floor Man #1 at accumulator that choke line is open.
 - 5. Close choke and upstream valve after pipe rams have been closed.
 - 6. Check for leaks on BOP stack and choke manifold.
 - 7. Read annular pressure.
 - 8. Report readings to the Driller.
- v. Tool Pusher
 - 1. Report to the rig floor.
 - 2. Have a meeting with all of the crews.
 - 3. Compile and summarize all information.
 - 4. See that proper well kill procedures are put into action.
- vi. Operator Representative
 - 1. Notify Drilling Superintendent
 - 2. Determine if an emergency exists, and if so, activate the contingency plan.

IGNITION PROCEDURES

Responsibility:

4 I 3 P

The decision to ignite the well is the responsibility of the DRILLING FOREMAN in concurrence with the STATE POLICE. In the event the Drilling Foreman is incapacitated, it becomes the responsibility of the RIG TOOL PUSHER. This decision should be made only as a last resort and in a situation where it is clear that:

- 1. Human life and property are endangered.
- 2. There is no hope of controlling the blowout under the prevailing conditions.

If time permits, notify the main office, but do not delay if human life is in danger. Initiate the first phase of the evacuation plan.

Instructions for Igniting the Well:

- Two people are required for the actual igniting operation. Both men must wear self-contained breathing apparatus and must use a full body harness and attach a retrievable safety line to the D-Ring in the back. One man must monitor the atmosphere for explosive gases with the LEL monitor, while the Drilling Foreman is responsible for igniting the well.
- 2. The primary method to ignite is a 25mm flare gun with a range of approximately 500 feet.
- 3. Ignite from upwind and do not approach any closer than is warranted.
- 4. Select the ignition site best suited for protection and which offers an easy escape route.
- 5. Before igniting, check for the presence of combustible gases.
- 6. After igniting, continue emergency actions and procedures as before.
- 7. All unassigned personnel will limit their actions to those directed by the Drilling Foreman.

Note: After the well is ignited, burning Hydrogen Sulfide will convert to Sulfur Dioxide, which is also highly toxic. Do not assume the area is safe after the well is ignited.

TRAINING PROGRAM

When working in an area where Hydrogen Sulfide (H_2S) might be encountered, definite training requirements must be carried out. The Company Supervisor will ensure that all personnel, at the well site, have had adequate training in the following:

- 1. Hazards and characteristics of Hydrogen Sulfide.
- 2. Physicals effects of Hydrogen Sulfide on the human body.
- 3. Toxicity of Hydrogen Sulfide and Sulfur Dioxide.
- 4. H₂S detection, Emergency alarm and sensor location.
- 5. Emergency rescue.
- 6. Resuscitators.

· , · ,

- 7. First aid and artificial resuscitation.
- 8. The effects of Hydrogen Sulfide on metals.
- 9. Location safety.

Service company personnel and visiting personnel must be notified if the zone contains H_2S , and each service company must provide adequate training and equipment for their employees before they arrive at the well site.

EMERGENCY EQUIPMENT REQUIREMENTS

Lease Entrance Sign:

. ، بد د

Should be located at the lease entrance with the following information:

CAUTION – POTENTIAL POISON GAS HYDROGEN SULFIDE NO ADMITTANCE WITHOUT AUTHORIZATION

Respiratory Equipment:

.

- Fresh air breathing equipment should be placed at the safe briefing areas and should include the following:
- Two SCBA's at each briefing area.
- Enough air line units to operate safely, anytime the H₂S concentration reaches the IDLH level (100 ppm).
- Cascade system with enough breathing air hose and manifolds to reach the rig floor, the derrickman and the other operation areas.

Windsocks or Wind Streamers:

- A minimum of two 10" windsocks located at strategic locations so that they may be seen from any point on location.
- Wind streamers (if preferred) should be placed at various locations on the well site to ensure wind consciousness at all times. (Corners of location).

Hydrogen Sulfide Detector and Alarms:

- 1 Four channel H₂S monitor with alarms.
- Four (4) sensors located as follows: #1 Rig Floor, #2 Bell Nipple, #3 Shale Shaker, #4 Mud Pits.
- Gastec or Draeger pump with tubes.
- Sensor test gas.

Well Condition Sign and Flags:

د د

The Well Condition Sign w/flags should be placed a minimum of 150' before you enter the location. It should have three (3) color coded flags (green, yellow and red) that will be used to denote the following location conditions:

GREEN – Normal Operating Conditions YELLOW – Potential Danger RED – Danger, H₂S Gas Present

Auxiliary Rescue Equipment:

- Stretcher
- 2 100' Rescue lines.
- First Aid Kit properly stocked.

Mud Inspection Equipment:

Garret Gas Train or Hach Tester for inspection of Hydrogen Sulfide in the drilling mud system.

Fire Extinguishers:

Adequate fire extinguishers shall be located at strategic locations.

Blowout Preventer:

- The well shall have hydraulic BOP equipment for the anticipated BHP.
- The BOP should be tested upon installation.
- BOP, Choke Line and Kill Line will be tested as specified by Operator.

Confined Space Monitor:

There should be a portable multi-gas monitor with at least 3 sensors (O_2 , LEL H_2S). This instrument should be used to test the atmosphere of any confined space before entering. It should also be used for atmospheric testing for LEL gas before beginning any type of Hot Work. Proper calibration documentation will need to be provided.

Communication Equipment:

- Proper communication equipment such as cell phones or 2-way radios should be available at the rig.
- Radio communication shall be available for communication between the company man's trailer, rig floor and the tool pusher's trailer.

• Communication equipment shall be available on the vehicles.

Special Control Equipment:

- Hydraulic BOP equipment with remote control on the ground.
- Rotating head at the surface casing point.

Evacuation Plan:

· ,

- Evacuation routes should be established prior to spudding the well.
- Should be discussed with all rig personnel.

Designated Areas:

Parking and Visitor area:

- All vehicles are to be parked at a pre-determined safe distance from the wellhead.
- Designated smoking area.

Safe Briefing Areas:

- Two Safe Briefing Areas shall be designated on either side of the location at the maximum allowable distance from the well bore so they offset prevailing winds or they are at a 180 degree angle if wind directions tend to shift in the area.
- Personal protective equipment should be stored at both briefing areas or if a moveable cascade trailer is used, it should be kept upwind of existing winds. When wind is from the prevailing direction, both briefing areas should be accessible.

Note:

- Additional equipment will be available at the Safety Solutions, LLC office.
- Additional personal H₂S monitors are available for all employees on location.
- Automatic Flare Igniters are recommended for installation on the rig.

CHECK LISTS

Status Check List

Note: Date each item as they are implemented.

3

,

х <u>,</u>

1. Sign at location entrance.	
2. Two (2) wind socks (in required locations).	
3. Wind Streamers (if required).	
4. SCBA's on location for all rig personnel and mud loggers.	
5. Air packs, inspected and ready for use.	
6. Spare bottles for each air pack (if required).	
7. Cascade system for refilling air bottles.	
8. Cascade system and hose line hook up.	
 Choke manifold hooked-up and tested. (before drilling out surface casing.) 	
 Remote Hydraulic BOP control (hooked-up and tested before drilling out surface casing). 	
11. BOP tested (before drilling out surface casing).	
12. Mud engineer on location with equipment to test mud for H_2S .	
13. Safe Briefing Areas set-up	
14. Well Condition sign and flags on location and ready.	
15. Hydrogen Sulfide detection system hooked -up & tested.	
16. Hydrogen Sulfide alarm system hooked-up & tested.	
17. Stretcher on location at Safe Briefing Area.	
18. 2 – 100' Life Lines on location.	
19. 1 – 20# Fire Extinguisher in safety trailer.	
20. Confined Space Monitor on location and tested.	
21. All rig crews and supervisor trained (as required).	

22. Access restricted for unauthorized personnel.	
23. Drills on H_2S and well control procedures.	
24. All outside service contractors advised of potential H_2S on the well.	
25. NO SMOKNG sign posted.	
26. H_2S Detector Pump w/tubes on location.	
27. 25mm Flare Gun on location w/flares.	
28. Automatic Flare Igniter installed on rig.	

•

Procedural Check List

Perform the following on each tour:

• •

- 1. Check fire extinguishers to see that they have the proper charge.
- 2. Check breathing equipment to insure that they have not been tampered with.
- 3. Check pressure on the supply air bottles to make sure they are capable of recharging.
- 4. Make sure all of the Hydrogen Sulfide detection systems are operative.

Perform the following each week:

- 1. Check each piece of breathing equipment to make sure that they are fully charged and operational. This requires that the air cylinder be opened and the mask assembly be put on and tested to make sure that the regulators and masks are properly working. Negative and Positive pressure should be conducted on all masks.
- 2. BOP skills.
- 3. Check supply pressure on BOP accumulator stand-by source.
- 4. Check all breathing air mask assemblies to see that straps are loosened and turned back, ready for use.
- 5. Check pressure on cascade air cylinders to make sure they are fully charged and ready to use for refill purposes if necessary.
- 6. Check all cascade system regulators to make sure they work properly.
- 7. Perform breathing drills with on-site personnel.
- 8. Check the following supplies for availability:
 - Stretcher
 - Safety Belts and Ropes
 - Spare air Bottles
 - Spare Oxygen Bottles (if resuscitator required)
 - Gas Detector Pump and Tubes
 - Emergency telephone lists
- 9. Test the Confined Space Monitor to verify the batteries are good

BRIEFING PROCEDURES

• . i ;

ç

The following scheduled briefings will be held to ensure the effective drilling and operation of this project:

١

Pre-Spud Meeting

Date: Prior to spudding the well. Attendance: Drilling Supervisor Drilling Engineer Drilling Foreman Rig Tool Pushers Rig Drillers Mud Engineer All Safety Personnel Key Service Company Personnel

Purpose: Review and discuss the well program, step-by-step, to insure complete understanding of assignments and responsibilities.

EVACUATION PLAN

General Plan

The direct lines of action prepared by SAFETY SOLUTIONS, LLC to protect the public from hazardous gas situations are as follows:

- 1. When the company approved supervisor (Drilling Foreman, Tool Pusher or Driller) determine that Hydrogen Sulfide gas cannot be limited to the well location, and the public will be involved, he will activate the evacuation plan. Escape routes are noted on the area map.
- 2. Company safety personnel or designee will notify the appropriate local government agency that a hazardous condition exists and evacuation needs to be implemented.
- 3. Company approved safety personnel that have been trained in the use of the proper emergency equipment will be utilized.
- 4. Law enforcement personnel (State Police, Local Police Department, Fire Department, and the Sheriff's Department) will be called to aid in setting up and maintaining road blocks. Also, they will aid in evacuation of the public if necessary.
- NOTE: Law enforcement personnel will not be asked to come into a contaminated area. Their assistance will be limited to uncontaminated areas. Constant radio contact will be maintained with them.
 - 5. After the discharge of gas has been controlled, "Company" safety personnel will determine when the area is safe for re-entry.

See Emergency Action Plan

Emergency Assistance Telephone List

، د ، د

PUBLIC SAFETY:		911
Eddy County Sheriff's Department	(575) 887	-7551
Kent Waller		
Fire Department:		
Carlsbad	(575) 885	-3125
Artesia	(575) 746	-5050
Hospitals:		
Carlsbad	(575) 887	-4121
Artesia	(575) 748	-3333
Hobbs	(575) 392	-1979
Dept. of Public Safety/Carlsbad	(575) 748	-9718
Highway Department	(575) 885	-3281
New Mexico Oil Conservation	(575) 476	-3440
U.S. Dept. of Labor	(575) 887	-1174
EOG Resources, Inc.		
EOG / Midland	Office (432) 686	-3600
Company Drilling Consultants:		
Danny Kiser	Cell (281) 833	-2749
Drilling Engineer		
Steve Munsell	Office (432) 686	-3609
	Cell (432) 894	
Operations Manager		1200
Joel Pettit	Office (432) 686	-3705
	Cell (432)894	
Drilling Superintendent	(,	
Barney Thompson	Office (432) 686	5-3678
	Cell (432) 254	
Field Drilling Superintendent	(,	
Ron Welch	Cell (432) 386	5-0592
McVay Drilling		
McVay Drilling / Hobbs	Office (575) 397	-3311
McVay Drilling Rig #4	Rig (575) 370	
	0 (-)	
Tool Pusher:	C-II /F7F) 27	
Terry Johnson	Cell (575) 370	J-562U
Safety Consultants		
Safety Solutions, LLC	Office (432) 686	
Cliff Strasner	Cell (432) 894	
Craig Strasner	Cell (432) 894	1.02/1

MAPS AND PLATS (Maps & Plats Attached)

و و م م

Affected Notification List

(within a 65' radius of exposure @100ppm)

The geologic zones that will be encountered during drilling are known to contain hazardous quantities of H_2S . The accompanying map illustrates the affected areas of the community. The residents within this radius will be notified via a hand delivered written notice describing the activities, potential hazards, conditions of evacuation, evacuation drill siren alarms and other precautionary measures.

Evacuee Description:

Residents: THERE ARE NO RESIDENTS WITHIN 3000' ROE.

Notification Process:

а а , , , , ,

A continuous siren audible to all residence will be activated, signaling evacuation of previously notified and informed residents.

Evacuation Plan: All evacuees will migrate lateral to the wind direction.

The Oil Company will identify all home bound or highly susceptible individuals and make special evacuation preparations, interfacing with the local and emergency medical service as necessary.

GENERAL INFORMATION

· •

Toxic Effects of H₂S Poisoning

Hydrogen Sulfide is extremely toxic. The acceptable ceiling concentration for eight-hour exposure is 10 PPM, which is .001% by volume. Hydrogen Sulfide is heavier than air (specific gravity – 1.192) and is colorless and transparent. Hydrogen Sulfide is almost as toxic as Hydrogen Cyanide and is 5-6 times more toxic than Carbon Monoxide. Occupational exposure limits for Hydrogen Sulfide and other gases are compared below in Table 1. Toxicity table for H_2S and physical effects are shown in Table 2.

Permissible Exposure Limits of Various Gases					
Common Name	Symbol	Sp. Gravity	TLV	STEL	IDLH
Hydrogen Cyanide	HCN	.94	4.7 ppm	С	
Hydrogen Sulfide	H₂S	1.192	10 ppm	15 ppm	100 ppm
Sulfide Dioxide	SO ₂	2.21	2 ppm	5 ppm	
Chlorine	CL	2.45	.5 ppm	1 ppm	
Carbon Monoxide	со	.97	25 ppm	200 ppm	
Carbon Dioxide	CO ₂	1.52	5000 ppm	30,000 ppm	
Methane	CH₄	.55	4.7% LEL	14% UEL	

Table 1 Permissible Exposure Limits of Various Gases

Definitions

- A. TLV Threshold Limit Value is the concentration employees may be exposed based on a TWA (time weighted average) for eight (8) hours in one day for 40 hours in one (1) week. This is set by ACGIH (American Conference of Governmental Hygienists) and regulated by OSHA.
- B. STEL Short Term Exposure Limit is the 15 minute average concentration an employee may be exposed to providing that the highest exposure never exceeds the OEL (Occupational Exposure Limit). The OEL for H₂S is 19 PPM.
- C. IDLH Immediately Dangerous to Life and Health is the concentration that has been determined by the ACGIH to cause serious health problems or death if exposed to this level. The IDLH for H₂S is 100 PPM.
- D. TWA Time Weighted Average is the average concentration of any chemical or gas for an eight
 (8) hour period. This is the concentration that any employee may be exposed based on an TWA.

	TABLE 2
	Toxicity Table of H ₂ S
PPM	Physical Effects
1	Can smell less than 1 ppm.
10	TLV for 8 hours of exposure.
15	STEL for 15 minutes of exposure.

• • • 1 • •

Percent %

.0001

.001 .0015

.01	100	Immediately Dangerous to Life & Health. Kills sense of smell in 3 to 5 minutes.
.02	200	Kills sense of smell quickly, may burn eyes and throat.
.05	500	Dizziness, cessation of breathing begins in a few minutes.
.07	700	Unconscious quickly, death will result if not rescued promptly.
.10	1000	Death will result unless rescued promptly. Artificial resuscitation may be necessary.

PHYSICAL PROPERTIES OF H₂S

The properties of all gases are usually described in the context of seven major categories:

COLOR ODOR VAPOR DENSITY EXPLOSIVE LIMITS FLAMMABILITY SOLUBILITY (IN WATER) BOILING POINT

Hydrogen Sulfide is no exception. Information from these categories should be considered in order to provide a fairly complete picture of the properties of the gas.

COLOR – TRANSPARENT

Hydrogen Sulfide is colorless so it is invisible. This fact simply means that you can't rely on your eyes to detect its presence. In fact that makes this gas extremely dangerous to be around.

ODOR – ROTTEN EGGS

Hydrogen Sulfide has a distinctive offensive smell, similar to "rotten eggs". For this reason it earned its common name "sour gas". However, H₂S, even in low concentrations, is so toxic that it attacks and quickly impairs a victim's sense of smell, so it could be fatal to rely on your nose as a detection device.

VAPOR DENSITY - SPECIFIC GRAVITY OF 1.192

Hydrogen Sulfide is heavier than air so it tends to settle in low-lying areas like pits, cellars or tanks. If you find yourself in a location where H_2S is known to exist, protect yourself. Whenever possible, work in an area upwind and keep to higher ground.

EXPLOSIVE LIMITS – 4.3% TO 46%

Mixed with the right proportion of air or oxygen, H_2S will ignite and burn or explode, producing another alarming element of danger besides poisoning.

FLAMMABILITY

Hydrogen Sulfide will burn readily with a distinctive clear blue flame, producing Sulfur Dioxide (SO_2) , another hazardous gas that irritates the eyes and lungs.

SOLUBILITY - 4 TO 1 RATIO WITH WATER

Hydrogen Sulfide can be dissolved in liquids, which means that it can be present in any container or vessel used to carry or hold well fluids including oil, water, emulsion and sludge. The solubility of H_2S is dependent on temperature and pressure, but if conditions are right, simply agitating a fluid containing H_2S may release the gas into the air.

BOILING POINT – (-76 degrees Fahrenheit)

Liquefied Hydrogen Sulfide boils at a very low temperature, so it is usually found as a gas.

RESPIRATOR USE

The Occupational Safety and Health Administration (OSHA) regulate the use of respiratory protection to protect the health of employees. OSHA's requirements are written in the Code of Federal Regulations, Title 29, Part 1910, Section 134, Respiratory Protection. This regulation requires that all employees who might be required to wear respirators, shall complete a OSHA mandated medical evaluation questionnaire. The employee then should be fit tested prior to wearing any respirator while being exposed to hazardous gases.

Written procedures shall be prepared covering safe use of respirators in dangerous atmospheric situations, which might be encountered in normal operations or in emergencies. Personnel shall be familiar with these procedures and the available respirators.

Respirators shall be inspected prior to and after each use to make sure that the respirator has been properly cleaned, disinfected and that the respirator works properly. The unit should be fully charged prior to being used.

Anyone who may use respirators shall be properly trained in how to properly seal the face piece. They shall wear respirators in normal air and then in a test atmosphere. (Note: Such items as facial hair (beard or sideburns) and eyeglass temple pieces will not allow a proper seal.) Anyone that may be expected to wear respirators should have these items removed before entering a toxic atmosphere. A special mask must be obtained for anyone who must wear eyeglasses. Contact lenses should not be allowed.

Respirators shall be worn during the following conditions:

ì

.

- A. Any employee who works near the top or on the top of any tank unless tests reveal less than 20 ppm of H_2S .
- B. When breaking out any line where H₂S can reasonably be expected.
- C. When sampling air in areas where H_2S may be present.
- D. When working in areas where the concentration of H₂S exceeds the Threshold Limit Value for H₂S (10 ppm).
- E. At any time where there is a doubt as to the H_2S level in the area to be entered.

EMERGENCY RESCUE PROCEDURES

DO NOT PANIC!!!

Remain Calm – Think

- 1. Before attempting any rescue you must first get out of the hazardous area yourself. Go to a safe briefing area.
- 2. Sound alarm and activate the 911 system.
- 3. Put on breathing apparatus. At least two persons should do this, when available use the buddy system.
- 4. Rescue the victim and return them to a safe briefing area.
- 5. Perform an initial assessment and begin proper First Aid/CPR procedures.
- 6. Keep victim lying down with a blanket or coat, etc.., under the shoulders to keep airway open. Conserve body heat and do not leave unattended.
- 7. If the eyes are affected by H₂S, wash them thoroughly with potable water. For slight irritation, cold compresses are helpful.
- 8. In case a person has only minor exposure and does not lose consciousness totally, it's best if he doesn't return to work until the following day.
- 9. Any personnel overcome by H₂S should always be examined by medical personnel. They should always be transported to a hospital or doctor.

SURFACE USE PLAN OF OPERATION

SHL: 330' FNL & 330' FEL, Unit A, Section 31, T16S-R28E, N.M.P.M., Eddy, NM BHL: 660' FNL & 330' FWL, Unit D, Section 31, T16S-R28E, N.M.P.M., Eddy, NM

1. EXISTING ROADS:

4

' **;**

- a. The well site and elevation plat for the proposed well are reflected on the well site layout; Form C-102. The well was staked by Terry Asel, RPL 15079.
- b. All roads into the location are depicted on Exhibit 2, 2a & 2b.
- c. <u>Directions to Locations</u>: Beginning in Artesia, NM, From Jct. of Hwy 285 & Hwy 82, go east on Hwy 82 for approximately 9.5 miles, turn north and County Road 202 (Southern Union Road) for 2.8 miles, turn northeast on County Road 202 for 1.3 miles, turn northwest for 0.1 miles, turn north on lease road for 1.8 miles, turn east on trail road for 0.7 miles, turn north for 0.1 miles to location.

2. NEW OR RECONSTRUCTED ACCESS ROAD:

- a. Exhibit 2a shows the layout. Applicant will construct new lease road with compact caliche a distance of 0.8 miles as depicted on Exhibit 2b.
- b. The maximum width of the road will be 15'. It will be crowned and made of 6" of rolled and compacted caliche. Water will be deflected, as necessary, to avoid accumulation and prevent soil erosion.
- c. Surface material will be native caliche. This material will be obtained from a BLM approved pit nearest in proximity to the location. The average grade will be approximately 1%.
- d. No cattleguards, gates or fence cuts will be required. No turnouts are planned.

3. LOCATION OF EXISTING WELLS:

Exhibit #3 shows all existing wells within a one-mile radius of this well.

4. LOCATION OF EXISTING AND/OR PROPOSED PRODUCTION FACILITIES:

- a. In the event the well is found to be productive, the necessary production equipment will be installed at the well site. See Production Facilities Layout diagram.
- b. As a proposed oil well, operator will contact Central Valley Electric Coop to provide electrical service to the well.
- c. All flow lines will adhere to API standards.
- d. Refer to b above.
- e. If the well is productive, rehabilitation plans are as follows:

- i. Within 120 days subsequent to the first date of sales, the location shall be reduced as determined by operator to the minimum area necessary to safely and effectively operate the well.
- ii. The original topsoil from the well site will be returned to the location. The location will be contoured as close as possible to match the original topography.

5. LOCATION AND TYPE OF WATER SUPPLY:

This location will be drilled using a combination of water mud systems (outlined in the drilling program). The water will be obtained from commercial water stations in the area and hauled to location by transport truck using existing and proposed roads shown in Exhibit 2, 2a & 2b. On occasion, water will be obtained from existing water wells. In these cases where a poly pipeline is used to transport water for drilling purposes, proper authorizations will be secured. If poly pipeline is used to transport fresh water to the location, proper authorization will be secured by the contractor.

6. CONSTRUCTION MATERIALS

All caliche utilized for the drilling pad and proposed access road will be obtained from an existing BLM approved pit or from prevailing deposits found under the location. All roads will be constructed of rolled and compacted caliche. Will use BLM recommended use of extra caliche from other locations close by roads, if available.

7. METHODS OF HANDLING WASTE MATERIALS

a. Drill cuttings shall be disposed of in a steel cuttings bin (catch tanks) on the drilling pad (behind the steel mud tanks). The bin and cuttings shall be hauled to an approved cuttings dumpsite.

At the site, the cuttings shall be removed from the bin & the bin shall be returned to the drilling site for reuse.

- b. All trash, junk, and other waste material shall be contained in trash cages or trash bins to prevent scattering. When a job is completed, all contents shall be removed and disposed of in an approved landfill.
- c. The supplier, including broken sacks, shall pick up salts remaining after completion of well.
- d. If necessary, a porto-john shall be provided for the rig crews. This equipment shall be properly maintained during the drilling and completion operations and shall be removed when all operations are complete.
- e. Remaining drilling fluids shall be hauled off by transports to a state approved disposal site. Water produced during completion shall be put in storage tanks and disposed of in a state approved disposal. Oil and condensate produced shall be put in a storage tank and sold.

- f. Disposal of fluids to be transported by the following companies:
 - i. RGB TRUCKING
 - ii. LOBO TRUCKING
 - iii. I & W TRUCKING
 - iv. CRANE HOT OIL & TRANSPORT
 - v. JWS
 - vi. QUALITY TRUCKING

8. ANCILLARY FACILITIES:

a. No airstrip, campsite, or other facilities will be built.

9. WELL SITE LAYOUT:

- a. Exhibit 4 shows the proposed location of reserve and sump pits, living facilities and well site layout with dimensions of the pad layout.
- b. Mud pits in the active circulating system shall be steel pits and the catch tanks shall be steel tanks set in shallow sumps behind the steel circulating tanks and sumps.
- c. The area where the catch tanks are placed shall be reclaimed and the surface vegetation restored to as or near the same condition that existed prior to operations.

10. PLANS FOR SURFACE RECLAMATION:

- a. After concluding the drilling and/or completion operations, if the well is found non-commercial, the caliche shall be removed from the pad and transported to the original caliche pit or used for other drilling locations and roads. The road shall be reclaimed and the surface vegetation restored to as or near the same condition that existed prior to operations. The catch tank area shall be broken out and leveled after drying to a condition where these are feasible. The original topsoil shall again be returned to the pad and contoured, as close as possible, to the original topography.
- b. After the well is plugged and abandoned, the location and road shall be reclaimed and the surface vegetation restored to as or near the same condition that existed prior to operations.
- c. If the well is deemed commercially productive, the catch tank area shall be restored as described in 10(a) within 120 days subsequent to the first date of sales. Caliche from areas of the pad site not required for operations shall be reclaimed. The original topsoil shall be returned to the area of the drill pad not necessary to operate the well. These unused areas of the drill pad shall be contoured, as close as possible, to match the original topography.

EOG RESOURCES INC. LUCKY WOLF 31 FED COM 1H TANNER OCD COPY

11. SURFACE OWNERSHIP

The surface is owned by the Bureau of Land Management. The surface is multiple use with the primary uses of the region for the grazing of livestock and the production of oil and gas.

12. OTHER INFORMATION:

- a. The area surrounding the well is grassland. The topsoil is sandy in nature. The vegetation is moderately sparse with native prairie grass, mesquite, cactus and shinnery oak. No wildlife was observed but it is likely that deer, rabbits, coyotes, birds and rodents transverse the area.
- b. There are not dwellings within 2 miles of location.
- c. There is no permanent or live water within 2 miles of the location.
- d. A Cutural Resources Examination will be conducted by Danny Boone and registered with BLM office in Carlsbad, New Mexico.

13. BOND COVERAGE:

a. Bond Coverage is Nationwide; Bond No. NM 2308

at the app

COMPANY REPRESENTATIVES:

Representatives responsible for ensuring compliance of the surface use plan are listed below:

Permitting & Land

Mr. Donny G. Glanton Senior Lease Operations ROW Representative EOG Resources, Inc. P.O. Box 2267 Midland, TX 79702 (432) 686-3642 Office (432) 770-0602 Cell

Drilling

Operations

Mr. Steve Munsell Drilling Engineer EOG Resources, Inc. P.O. Box 2267 Midland, TX 79702 (432) 686-3609 Office (432) 894-1256 Cell Mr. Howard Kemp Production Manager EOG Resources, Inc P.O. Box 2267 Midland, TX 79702 (432) 686-3704 Office (432) 634-1001 Cell

OPERATOR CERTIFICATION

I certify that I, or someone under my direct supervision, have inspected the drill site and access route proposed herein; that I am familiar with the conditions that presently exist; that I have full knowledge of State and Federal Laws applicable to this operation; that the statements made in this APD package are, to the best of my knowledge, true, and correct; and that the work associated with the operations proposed herein will be performed in conformity with this APD package and the terms and conditions under which it is approved. I also certify that I, or the company I represent, am responsible for the operations conducted under this application. These statements are subject to the provisions of 18 U.S.C. 1001 for the filing of false statements. Executed this 10^{-rh} day of A_{mywst} , 200 9.

Name: <u>Donny G. Glanton</u> Position: <u>Sr. Lease Operations ROW Representative</u> Address: <u>P.O. Box 2267 Midland, TX 79705</u> Telephone: <u>432-686-3642</u> Email: <u>donny_glanton@eogresources.com</u>

Signed: ____ J. Mut

PECOS DISTRICT CONDITIONS OF APPROVAL

OPERATOR'S NAME:		· .
LEASE NO.:	NM12110	
WELL NAME & NO.:	Lucky Wolf 31 Fed. Com # 1H	-
SURFACE HOLE FOOTAGE:	330' FNL & 330' FEL	,
BOTTOM HOLE FOOTAGE	660' FNL & 330' FWL	
LOCATION:	Section 31, T. 16 S., R 28 E., NMPM	
COUNTY:	Eddy County, New Mexico	

TABLE OF CONTENTS

Standard Conditions of Approval (COA) apply to this APD. If any deviations to these standards exist or special COAs are required, the section with the deviation or requirement will be checked below.

- General Provisions
- **Permit Expiration**
 - Archaeology, Paleontology, and Historical Sites
 - Noxious Weeds

Special Requirements

Ditching/Berming Well Pad

- Cave/Karst
- Communitization Agreement

Specify Completion Formation

Construction

Notification

Topsoil '

Closed Loop System

Federal Mineral Material Pits

Well Pads

Roads

Road Section Diagram

Drilling

High Cave/Karst Requirements

Logging Requirements

Production (Post Drilling)

Well Structures & Facilities

Interim Reclamation

Final Abandonment/Reclamation

GENERAL PROVISIONS

The approval of the Application For Permit To Drill (APD) is in compliance with all applicable laws and regulations: 43 Code of Federal Regulations 3160, the lease terms. Onshore Oil and Gas Orders, Notices To Lessees, New Mexico Oil Conservation Division (NMOCD) Rules, National Historical Preservation Act As Amended, and instructions and orders of the Authorized Officer. Any request for a variance shall be submitted to the Authorized Officer on Form 3160-5, Sundry Notices and Report on Wells.

II. PERMIT EXPIRATION

If the permit terminates prior to drilling and drilling cannot be commenced within 60 days after expiration, an operator is required to submit Form 3160-5, Sundry Notices and Reports on Wells, requesting surface reclamation requirements for any surface disturbance. However, if the operator will be able to initiate drilling within 60 days after the expiration of the permit, the operator must have set the conductor pipe in order to allow for an extension of 60 days beyond the expiration date of the APD. (Filing of a Sundry Notice is required for this 60 day extension.)

III. ARCHAEOLOGICAL, PALEONTOLOGY & HISTORICAL SITES

Any cultural and/or paleontological resource discovered by the operator or by any person working on the operator's behalf shall immediately report such findings to the Authorized Officer. The operator is fully accountable for the actions of their contractors and subcontractors. The operator shall suspend all operations in the immediate area of such discovery until written authorization to proceed is issued by the Authorized Officer. An evaluation of the discovery shall be made by the Authorized Officer to determine the appropriate actions that shall be required to prevent the loss of significant cultural or scientific values of the discovery. The operator shall be held responsible for the cost of the proper mitigation measures that the Authorized Officer assesses after consultation with the operator on the evaluation and decisions of the discovery. Any unauthorized collection or disturbance of cultural or paleontological resources may result in a shutdown order by the Authorized Officer.

IV. NOXIOUS WEEDS

The operator shall be held responsible if noxious weeds become established within the areas of operations. Weed control shall be required on the disturbed land where noxious weeds exist, which includes the roads, pads, associated pipeline corridor, and adjacent land affected by the establishment of weeds due to this action. The operator shall consult with the Authorized Officer for acceptable weed control methods, which include following EPA and BLM requirements and policies.

SPECIAL REQUIREMENT(S)

Ditching/Berming of Well Pad

The north side (uphill side) of the well pad shall be ditched and bermed appropriately to divert water flow around the well pad. This will create a proper water flow into the drainage, lessen the probability of contamination in the drainage and allow a safer working environment on the well pad. Additional berming requirements are located below in Cave and Karst stipulations.

Cave and Karst

Depending on location, additional Drilling, Casing, and Cementing procedures may be required by engineering to protect critical karst groundwater recharge areas.

Cave/Karst Surface Mitigation

The following stipulations will be applied to minimize impacts during construction, drilling and production.

Construction:

In the advent that any underground voids are opened up during construction activities, construction activities will be halted and the BLM will be notified immediately.

No Blasting:

No blasting will be utilized for pad construction. The pad will be constructed and leveled by adding the necessary fill and caliche.

Pad Berming:

The pad will be bermed to prevent oil, salt, and other chemical contaminants from leaving the pad. All sides will be bermed.

Tank Battery Liners and Berms:

Tank battery locations will be lined and bermed. A 20 mil permanent liner will be installed with a 4 oz. felt backing to prevent tears or punctures. Tank battery berms must be large enough to contain $1\frac{1}{2}$ times the content of the largest tank.

Leak Detection System:

A method of detecting leaks is required. The method could incorporate gauges to measure loss, situating values and lines so they can be visually inspected, or installing electronic sensors to alarm when a leak is present. Leak detection plan will be submitted to BLM for approval.

Automatic Shut-off Systems:

Automatic shut off, check values, or similar systems will be installed for pipelines and tanks to minimize the effects of catastrophic line failures used in production or drilling.

Cave/Karst Subsurface Mitigation

The following stipulations will be applied to protect cave/karst and ground water concerns:

Rotary Drilling with Fresh Water:

Fresh water will be used as a circulating medium in zones where caves or karst features are expected. SEE ALSO: Drilling COAs for this well.

Directional Drilling:

Kick off for directional drilling will occur at least 100 feet below the bottom of the cave occurrence zone. SEE ALSO: Drilling COAs for this well.

Lost Circulation:

ALL lost circulation zones from the surface to the base of the cave occurrence zone will be logged and reported in the drilling report.

Regardless of the type of drilling machinery used, if a void of four feet or more and circulation losses greater than 70 percent occur simultaneously while drilling in any cavebearing zone, the BLM will be notified immediately by the operator. The BLM will assess the situation and work with the operator on corrective actions to resolve the problem.

Abandonment Cementing:

Upon well abandonment in high cave karst areas additional plugging conditions of approval may be required. The BLM will assess the situation and work with the operator to ensure proper plugging of the wellbore.

Pressure Testing:

Annual pressure monitoring will be performed by the operator on all casing annuli and reported in a sundry notice. If the test results indicated a casing failure has occurred, remedial action will be undertaken to correct the problem to the BLM's approval.

Communitization Agreement

A Communitization Agreement covering the acreage dedicated to this well must be filed for approval with the BLM. The effective date of the agreement shall be prior to any sales. Operator to supply NMOCD order, which details the vertical and horizontal extent of pool to verify that requested communitization is within an approved and established pool.

Prior to completion, NMOCD must specify completion formation (Abo/Wolfcamp).

A. CONSTRUCTION

NOTIFICATION

The BLM shall administer compliance and monitor construction of the access road and well pad. Notify the Carlsbad Field Office at (575) 234-5972 at least 3 working days prior to commencing construction of the access road and/or well pad.

When construction operations are being conducted on this well, the operator shall have the approved APD and Conditions of Approval (COA) on the well site and they shall be made available upon request by the Authorized Officer.

B. TOPSOIL

E.

The operator shall stockpile the topsoil of the well pad. The topsoil shall not be used to backfill the reserve pit and will be used for interim and final reclamation.

C. CLOSED LOOP SYSTEM

Tanks are required for drilling operations: No Pits.

The operator shall properly dispose of drilling contents at an authorized disposal site.

D. FEDERAL MINERAL MATERIALS PIT

If the operator elects to surface the access road and/or well pad, mineral materials extracted during construction of the reserve pit may be used for surfacing the well pad and access road and other facilities on the lease.

Payment shall be made to the BLM prior to removal of any additional federal mineral materials from any site other than the reserve pit. Call the Carlsbad Field Office at (575) 234-5972.

WELL PAD SURFACING

Surfacing of the well pad is not required.

If the operator elects to surface the well pad, the surfacing material may be required to be removed at the time of reclamation.

The well pad shall be constructed in a manner which creates the smallest possible surface disturbance, consistent with safety and operational needs.

ON LEASE ACCESS ROADS

Road Width

The access road shall have a driving surface that creates the smallest possible surface disturbance and does not exceed fourteen (14) feet in width. The maximum width of surface disturbance, when constructing the access road, shall not exceed thirty (30) feet.

Surfacing

Surfacing material is not required on the new access road driving surface. If the operator elects to surface the new access road or pad, the surfacing material may be required to be removed at the time of reclamation.

Where possible, no improvements should be made on the unsurfaced access road other than to remove vegetation as necessary, road irregularities, safety issues, or to fill low areas that may sustain standing water.

The Authorized Officer reserves the right to require surfacing of any portion of the access road at any time deemed necessary. Surfacing may be required in the event the road deteriorates, erodes, road traffic increases, or it is determined to be beneficial for future field development. The surfacing depth and type of material will be determined at the time of notification.

Crowning

Crowning shall be done on the access road driving surface. The road crown shall have a grade of approximately 2% (i.e., a 1" crown on a 14' wide road). The road shall conform to Figure 1; cross section and plans for typical road construction.

Ditching

Ditching shall be required on both sides of the road.

Turnouts

Vehicle turnouts shall be constructed on the road. Turnouts shall be intervisible with interval spacing distance less than 1000 feet. Turnouts shall be constructed on all blind curves. Turnouts shall conform to the following diagram:



Drainage

Drainage control systems shall be constructed on the entire length of road (e.g. ditches, sidehill outsloping and insloping, lead-off ditches, culvert installation, and low water crossings).

A typical lead-off ditch has a minimum depth of 1 foot below and a berm of 6 inches above natural ground level. The berm shall be on the down-slope side of the lead-off ditch.



All lead-off ditches shall be graded to drain water with a 1 percent minimum to 3 percent maximum ditch slope. The spacing interval are variable for lead-off ditches and shall be determined according to the formula for spacing intervals of lead-off ditches, but may be amended depending upon existing soil types and centerline road slope (in %);

Formula for Spacing Interval of Lead-off Ditches

Example - On a 4% road slope that is 400 feet long, the water flow shall drain water into a lead-off ditch. Spacing interval shall be determined by the following formula:

400 foot road with 4% road slope: 400'/4% + 100' = 200' lead-off ditch interval **Culvert Installations**

Appropriately sized culvert(s) shall be installed at the deep waterway channel flow crossing.

Cattleguards

An appropriately sized cattleguard(s) sufficient to carry out the project shall be installed and maintained at fence crossing(s).

Any existing cattleguard(s) on the access road shall be repaired or replaced if they are damaged or have deteriorated beyond practical use. The operator shall be responsible for the condition of the existing cattleguard(s) that are in place and are utilized during lease operations.

A gate shall be constructed and fastened securely to H-braces.

Fence Requirement

Where entry is required across a fence line, the fence shall be braced and tied off on both sides of the passageway prior to cutting.

The operator shall notify the private surface landowner or the grazing allotment holder prior to crossing any fence(s).

Public Access

Public access on this road shall not be restricted by the operator without specific written approval granted by the Authorized Officer.



Figure 1 – Cross Sections and Plans For Typical Road Sections

VII. DRILLING

DRILLING OPERATIONS REQUIREMENTS

The BLM is to be notified a minimum of 4 hours in advance for a representative to witness:

- a. Spudding well
- b. Setting and/or Cementing of all casing strings
- c. BOPE tests
 - Eddy County

Call the Carlsbad Field Office, 620 East Greene St., Carlsbad, NM 88220, (575) 361-2822

1. Hydrogen Sulfide has been reported, but no measurements have been recorded. It is recommended that monitoring equipment be onsite for potential Hydrogen Sulfide. If Hydrogen Sulfide is encountered, please report measurements and formations to the BLM.

2. Unless the production casing has been run and cemented or the well has been properly plugged, the drilling rig shall not be removed from over the hole without prior approval.

3. Floor controls are required for 3M or Greater systems. These controls will be on the rig floor, unobstructed, readily accessible to the driller and will be operational at all times during drilling and/or completion activities. Rig floor is defined as the area immediately around the rotary table; the area immediately above the substructure on which the draw works are located, this does not include the dog house or stairway area.

4. The record of the drilling rate along with the CAL/GR/N well log run from TD to surface will be submitted to the BLM office as well as all other logs run on the borehole 30 days from completion. The Rustler top and top and bottom of Salt are to be recorded on the Completion Report.

B. CASING

Changes to the approved APD casing and cement program require submitting a sundry and receiving approval prior to work. Failure to obtain approval prior to work will result in an Incident of Non-Compliance being issued.

Centralizers required on surface casing per Onshore Order 2.III.B.1.f.

Wait on cement (WOC) time for a primary cement job will be a minimum 18 hours for a water basin, 24 hours in the potash area, or 500 pounds compressive strength, whichever is greater for all casing strings. Provide compressive strengths including hours to reach required 500 pounds compressive strength prior to cementing each casing string. See individual casing strings for details regarding lead cement slurry requirements.

No pea gravel permitted for remedial or fall back remedial without prior authorization from the BLM engineer.

High cave/karst

Possible brine flows in the Salado Formation. Possible lost circulation in the Salado, Grayburg and San Andres Formations.

1. The **13-3/8** inch surface casing shall be set at approximately 500 feet and cemented to the surface.

- a. If cement does not circulate to the surface, the appropriate BLM office shall be notified and a temperature survey utilizing an electronic type temperature survey with a surface log readout will be used or a cement bond log shall be run to verify the top of the cement.
- b. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry.
- c. Wait on cement (WOC) time for a remedial job will be a minimum of 4 hours after bringing cement to surface or 500 pounds compressive strength, whichever is greater.
- d. If cement falls back, remedial cementing will be done prior to drilling out that string.

If 75% or greater lost circulation occurs while drilling the intermediate casing hole, the BLM is to be contacted prior to setting the 7" intermediate casing as an additional casing string will be required due to high cave/karst.

2. The minimum required fill of cement behind the 7 inch intermediate casing is:

Cement to surface. If cement does not circulate see B.1.a, c-d above. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry due to cave/karst. Pilot hole is required to have a plug at the bottom of the hole. If two plugs are set, the BLM is to be contacted (575-361-2822) prior to tag of bottom plug, which must be a minimum of 170' in length. Operator can set one plug from bottom of pilot hole to kick-off point and save the WOC time for tagging the first plug.

- 3. Cement not required on the 4-1/2" casing. Packer system being used.
- 4. If hardband drill pipe is rotated inside casing, returns will be monitored for metal. If metal is found in samples, drill pipe will be pulled and rubber protectors which have a larger diameter than the tool joints of the drill pipe will be installed prior to continuing drilling operations.

PRESSURE CONTROL

C.

- 1. All blowout preventer (BOP) and related equipment (BOPE) shall comply with well control requirements as described in Onshore Oil and Gas Order No. 2 and API RP 53 Sec. 17.
- 2. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the surface casing shoe shall be **2000 (2M)** psi.
- Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the 7' intermediate casing shoe shall be 5000 (5M) psi. 5M system requires an HCR valve, remote kill line and annular to match. The remote kill line is to be installed prior to testing the system and tested to stack pressure.

The appropriate BLM office shall be notified a minimum of 4 hours in advance for a representative to witness the tests.

a. The tests shall be done by an independent service company.

b. The results of the test shall be reported to the appropriate BLM office.

- c. All tests are required to be recorded on a calibrated test chart. A copy of the BOP/BOPE test chart and a copy of independent service company test will be submitted to the appropriate BLM office.
- d. The BOP/BOPE test shall include a low pressure test from 250 to 300 psi. The test will be held for a minimum of 10 minutes if test is done with a test plug and 30 minutes without a test plug.

BOP/BOPE must be tested by an independent service company within 500 feet of the top of the **Wolfcamp** formation if the time between the setting of the intermediate casing and reaching this depth exceeds 20 days. This test does not exclude the test prior to drilling out the casing shoe as per Onshore Order No. 2.

D. DRILLING MUD

e.

Mud system monitoring equipment, with derrick floor indicators and visual and audio alarms, shall be operating before drilling into the **Wolfcamp** formation, and shall be used until production casing is run and cemented.

Page 13 of 17

DRILL STEM TEST

If drill stem tests are performed, Onshore Order 2.III.D shall be followed.

CRW 091009

E.

VIII. PRODUCTION (POST DRILLING)

- WELL STRUCTURES & FACILITIES .

Placement of Production Facilities

Production facilities should be placed on the well pad to allow for maximum interim recontouring and revegetation of the well location.

Containment Structures

A. .

The containment structure shall be constructed to hold the capacity of the entire contents of the largest tank, plus 24 hour production, unless more stringent protective requirements are deemed necessary by the Authorized Officer.

Painting Requirement

All above-ground structures including meter housing that are not subject to safety requirements shall be painted a flat non-reflective paint color Shale Green, Munsell Soil Color Chart # 5Y 4/2

IX. INTERIM RECLAMATION

If the well is a producer, interim reclamation shall be conducted on the well site in accordance with the orders of the Authorized Officer. The operator shall submit a Sundry Notices and Reports on Wells (Notice of Intent), Form 3160-5, prior to conducting interim reclamation.

During the life of the development, all disturbed areas not needed for active support of production operations should undergo interim reclamation in order to minimize the environmental impacts of development on other resources and uses.

The operators should work with BLM surface management specialists to devise the best strategies to reduce the size of the location. Any reductions should allow for remedial well operations, as well as safe and efficient removal of oil and gas.

During reclamation, the removal of caliche is important to increasing the success of revegetating the site. Removed caliche may be used for road repairs, fire walls or for building other roads and locations. In order to operate the well or complete workover operations, it may be necessary to drive, park and operate on restored interim vegetation within the previously disturbed area. Disturbing revegetated areas for production or workover operations will be allowed. If there is significant disturbance and loss of vegetation, the area will need to be revegetated. Communicate with the appropriate BLM office for any exceptions/exemptions if needed.

Seed Mixture 1, for Loamy Sites

The holder shall seed all disturbed areas with the seed mixture listed below. The seed mixture shall be planted in the amounts specified in pounds of pure live seed (PLS)* per acre. There shall be <u>no</u> primary or secondary noxious weeds in the seed mixture. Seed will be tested and the viability testing of seed will be done in accordance with State law(s) and within nine (9) months prior to purchase. Commercial seed will be either certified or registered seed. The seed container will be tagged in accordance with State law(s) and available for inspection by the authorized officer.

Seed will be planted using a drill equipped with a depth regulator to ensure proper depth regulator to ensure proper depth of planting where drilling is possible. The seed mixture will be evenly and uniformly planted over the disturbed area (small/heavier seeds have a tendency to drop the bottom of the drill and are planted first). The holder shall take appropriate measures to ensure this does not occur. Where drilling is not possible, seed will be broadcast and the area shall be raked or chained to cover the seed. When broadcasting the seed, the pounds per acre are to be doubled. The seeding will be repeated until a satisfactory stand is established as determined by the authorized officer. Evaluation of growth will not be made before completion of at least one full growing season after seeding.

Species to be planted in pounds of pure live seed* per acre:

Species	lb/acre
Plains lovegrass (Eragrostis intermedia)	0.5
Sand dropseed (Sporobolus cryptandrus)	1.0
Sideoats grama (Bouteloua curtipendula)	5.0

*Pounds of pure live seed:

Pounds of seed \mathbf{x} percent purity \mathbf{x} percent germination = pounds pure live seed

X. FINAL ABANDONMENT & REHABILITATION REQUIREMENTS

- Upon abandonment of the well and/or when the access road is no longer in service the Authorized Officer shall issue instructions and/or orders for surface reclamation and restoration of all disturbed areas.
- On private surface/federal mineral estate land the reclamation procedures on the road and well pad shall be accomplished in accordance with the private surface land owner agreement.