

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, New Mexico 87505

WELL API NO.

30-015-01632

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

B-11538

7. Lease Name or Unit Agreement Name

Red Lake Sand Unit

8. Well No.

1

9. Pool name or Wildcat

Red Lake; Queen-Grayburg-SA

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

RECEIVED

2. Name of Operator

Mack Energy Corporation

JAN 1 2 2004

3. Address of Operator

P.O. Box 960, Artesia, NM 88211-0960

OCD-ARTESIA

4. Well Location

Unit Letter G : 1650 Feet From The North Line and 1650 Feet From The East Line

Section 30 Township 17S Range 28E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon well as follows:

1. Notify OCD 24 hours prior to starting plugging operations.

2. Set 100' cement plug from 1697-1597'. WOC and tag.

3. Circulate hole with mud gel.

4. Perforate @ 365' squeeze 100' cement above and below 8 5/8 casing. WOC and tag.

5. Perforate @ 200' squeeze 100' cement back to 100'.

6. Perforate @ 60' circulate cement to surface. in & out of Both csg. strings WOC-24 HRS- TAG

7. Install dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Jerry W. Sherrell

TITLE

Production Clerk

DATE

1/12/2004

TYPE OR PRINT NAME

Jerry W. Sherrell

TELEPHONE NO.

(This space for State Use)

APPROVED BY

[Signature]

TITLE

[Signature]

DATE

JAN 21 2004

CONDITIONS OF APPROVAL, IF ANY:

MACK ENERGY CORPORATION
RED LAKE SAND UNIT #1
Sec 30 T17S R28E 1650FNL 1650 FEL

'8 5/8"-28#

1. Notify OCD 24 hrs. prior to any work done.
2. Set 100' cmt plug 1697'-1597' and tag.
3. Circ hole with mud gel.
4. Perf @ 365' squeeze 100' cmt plug 50' above & below 8 5/8" and tag.
5. Perf @ 200' squeeze 100' cmt plug 50' above & below back to 100'
6. Perf @ 60' circ cmt to surface
7. Install Dry Hole Marker

8 5/8"-28# Set @ 315' w/50sks

7" -20# Set @ 1647' w/50sks

OPEN HOLE 1647'-1750'