

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, New Mexico 87505

WELL API NO. 30-015-01615
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-5084
7. Lease Name or Unit Agreement Name Red Lake Sand Unit
8. Well No. 9
9. Pool name or Wildcat Red Lake; Queen-Grayburg-SA

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS).	
1. Type Of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	RECEIVED JAN 22 2004 OCD-ARTESIA
2. Name of Operator Mack Energy Corporation	
3. Address of Operator P.O. Box 960, Artesia, NM 88211-0960	
4. Well Location Unit Letter <u>A</u> : <u>330</u> Feet From The <u>North</u> Line and <u>330</u> Feet From The <u>East</u> Line Section <u>30</u> Township <u>17S</u> Range <u>28E</u> NMPM <u>Eddy</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon well as follows:

1. Notify OCD 24 hours prior to starting plugging operations.

2. Set 100' cement plug from 1705-1605'. WOC and tag.

3. Circulate hole with mud gel.

4. Perforate @ 505' squeeze 100' cement plug 50' above and below 8 5/8 casing. WOC and tag.

6. Perforate @ 60' circulate cement to surface. - Plug Both Csg. Strings - place 60' of cmt inside & outside

7. Install dry hole marker.

Both strings 0'-60' - WOC 24 HRS. tag

★ Plug Both csg. strings @ 350' - Place 100' of cmt. inside & outside of
Both strings 250-350' - (Yates)

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jerry W. Sherrell TITLE Production Clerk DATE 1/22/04

TYPE OR PRINT NAME Jerry W. Sherrell TELEPHONE NO.

(This space for State Use)

APPROVED BY [Signature] TITLE Wild Sep ID DATE JAN 26 2004

CONDITIONS OF APPROVAL, IF ANY:

STATE

MACK ENERGY CORPORATION
RED LAKE SAND UNIT #9
Sec 30 T17S R28E 330FNL 330FEL

'8 5/8"-28#

1. Notify OCD 24 hrs. prior to any work done.
2. Set 100' cmt plug 1705-1605' and tag.
3. Circ hole with mud gel.
4. Perf @ 505' squeeze 100' cmt plug 50' above & below 8 5/8" and tag.
5. Perf @ 60' circ cmt to surface
6. Install Dry Hole Marker

8 5/8"-28# Set @ 465' w/50sks

7" -20# Set @ 1665' w/50sks

OPEN HOLE 1665-1800'