

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
June 19, 2008

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

RECEIVED

APR - 17 2010

NMOC-D ARTESIA

WELL API NO.  
30-015-35749

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name  
STATE 2

8. Well Number 008

9. OGRID Number  
246083

10. Pool name or Wildcat  
LIVINGSTON RIDGE; DELAWARE, SE

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator  
REEF EXPLORATION, L.P.

3. Address of Operator  
1901 N. CENTRAL EXPWY, SUITE 300 RICHARDSON, TEXAS 75080

4. Well Location

Unit Letter L : 1980 feet from the S line and 660 feet from the W line

Section 2 Township 23S Range 31E NMPM EDDY County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3411 GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

OTHER: CONVERT WELL TO INJECTION ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- POOH with rods and tbg.
- RIH and set a CIBP at 6050' and dump 30' of cmt on top of the plug.
- Perforate 5860' - 5880' and 5760' - 5770' @ 3 SPF.
- Frac the section with 100,000 #'s of 16/30 Brown sand
- Set a composite bridge plug at 5660'.
- RIH and perforate 5550' - 5580' @ 3 SPF and frac with 100,000#'s of 16/30 brown sand
- Set a composite bridge plug at 5300'.
- RIH and perforate 5150' - 5170' @ 3 SPF and frac with 100,000#'s of 16/30 sand
- Set a composite bridge plug at 5000'.
- RIH and perforate from 4600' - 4620' @ 3 SPF and frac with 100,000#'s of 16/30 sand.
- Set a composite bridge plug at 4000'.
- RIH with 2-7/8" tubing and drill out all four plugs to PBTD.
- POOH and lay down tbg.
- RIH with 3-1/2", 9.2#, SMLS, J-55 Ultra FJ/PC tubing and set injection packer at 4560' +/- (40' above top perf.)
- Turn well to injection.

Spud Date: 11/17/2007

Rig Release Date: 01/12/2008

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE REGULATORY AFFAIRS DATE 3/30/10

Type or print name JOSE L. VELEZ E-mail address: JOSEV@REEFOGC.COM PHONE: 972-437-6792

For State Use Only

APPROVED BY: RICHARD INAES TITLE 4/27/10 Compliance Officer DATE 4/27/10  
Conditions of Approval (if any):