

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

RECEIVED

OCT 31 1975

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator The Superior Oil Company ✓	5. State Oil & Gas Lease No.
3. Address of Operator P. O. Box 1900, Midland, Texas 79701	7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>G</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>6-S</u> RANGE <u>28-E</u> NMPM.	8. Farm or Lease Name Chatten & Muncy "A"
	9. Well No. 1
	10. Field and Pool, or Wildcat Denton Camp Miss. Gas
15. Elevation (Show whether DF, RT, GR, etc.) RKB: 3973', GL: 3959'	12. County Chaves

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

### 17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On 10-24-75, the subject well was treated thru 5-1/2" casing perfs 6458'-6462', in the Mississippian Zone with 3000 gal gelled 3% acid and 4500 lb of 20-40 mesh sand. After this treatment, well was swab tested and has proved non-commercial in the Mississippian Zone.

We plan to displace hole with water and set bridge plug at 6200' with 20' of cement on top. Perforate the Cisco (Bough C) Zone 6006'-6010'. Swab and acidize with 500 gal acid. If these perfs are non-commercial, load hole with water, set bridge plug at 5950' with 20' cement on top.

Perforate Wolfcamp Zone 5880'-5884'. Swab and acidize with 500 gal acid. If this zone is non-commercial, load hole with water. Set bridge plug at about 5700' with 20' cement on top. Perforate 5566'-5569'. Swab and acidize with 500 gal acid. If zone is non-commercial, we will submit a plugging procedure.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED P. R. Blancett P. R. Blancett TITLE Petroleum Engineer DATE 10-29-75

APPROVED BY W. A. Gussert TITLE SUPERVISOR, DISTRICT II DATE OCT 31 1975

CONDITIONS OF APPROVAL, IF ANY: