

RECEIVED BY

MAR 5 1985

O. C. D.  
ARTESIA, OFFICEUNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYForm Approved.  
Budget Bureau No. 42-R1424

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☐ other ☒ Non-producing2. NAME OF OPERATOR  
Penroc Oil Corporation3. ADDRESS OF OPERATOR  
P O DRAWER 831 MIDLAND TX 79702

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

AT SURFACE: 330' fSL, 380' fWL

AT TOP PROD. INTERVAL:

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐CHANGE ZONES ☐ABANDON\* ☒

(other)

5. LEASE  
LC-068127

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Elliott Federal9. WELL NO.  
1-Y

10. FIELD OR WILDCAT NAME

Linda San Andres

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
29-6S-26E12. COUNTY OR PARISH  
Chaves13. STATE  
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
3668 DF 3661 GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Well spudded 10/23/77, Total Depth - 1095'.

9 5/8", 47#, N-80 Casing set at 450' w/200sxs. cement circ. 4 1/2", 10.50#,

K-55 casing set @ 1085' w/175sxs. cement est. 350'. Perfs: 968'-1000'.

Per my telephone conversation w/Peter Chester 2/26/85. Desire to change plugging procedure indicated on Sundry Notice dated 8/30/84. Your verbal approval given.

Program now is to plug this well through open-ended tubing by:

1. Run tubing to TD. Pump 25 sacks cement (29.5 cu.ft. (323')/in 4 1/2" csg.)  
Est. top would be 729'. *Tag plug*

2. Pull tubing up 350', pump 10 lb. bentonite mud. Pull tubing to 130' from surface. Pump 10 sacks cement to surface. Set marker.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

President

DATE

2/26/85

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

PETER W. CHESTER

TITLE

DATE

MAR 1 1985

BUREAU OF LAND MANAGEMENT  
ROSWELL RESOURCE AREA

See instructions on Reverse Side