

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - M" (FORM C-101) FOR SUCH PROPOSALS.)

1. CIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input checked="" type="checkbox"/> P&A ARTESIA, OFFICE	7. Unit Agreement Name
2. Name of Operator Coronado Exploration Corp.	8. Farm or Lease Name J.P. White E
3. Address of Operator 1005 Marquette NW Albuquerque, NM 87102	9. Well No. #1
4. Location of Well UNIT LETTI <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>28</u> TOWNSHIP <u>10S</u> RANGE <u>28E</u> NMPM.	10. Field and Pool, or Wildcat Und. I.E. Ranch-SA
15. Elevation (Show whether DF, RT, GR, etc.) 3788.1 Gr	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Began plugging on January 25th and completed plugging on January 26th, 1980.

Cut 4 1/2" casing at 1000' and pulled out of hole. Set 25 sack plug on bottom over perfs. Filled hole to 1100' with gel. Set 45 sack plug from the bottom of the plug at 1100'. Top tagged at 1050'. Set 3 bbl of cement on top of plug to get top of cement approximately 1000'. Spotted gel. Set 35 sack plug at bottom at 450' and top at 350'. Set 10 sack plug at top with dry hole marker.

Cleaned location and collapsed pits.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CORONADO EXPLORATION CORP.

BY: [Signature]

TITLE ENGINEER

DATE FEBRUARY 4, 1980

APPROVED BY [Signature]  
CONDITIONS OF APPROVAL, IF ANY:

TITLE Geologist

DATE 1-30-84