

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

SEP 09 1996

OIL CON. DIV.

WELL API NO. 30-005-60663
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Miller and Olsen
8. Well No. 1
9. Pool name or Wildcat Railroad Mountain SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER

2. Name of Operator
Vintage Petroleum Corp.

3. Address of Operator
4200 One Williams Center, Tulsa, OK 74172

4. Well Location
Unit Letter I : 1980 Feet From The South Line and 660 Feet From The East Line
Section 3 Township 8-S Range 28-E NMPM Chaves County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4006.5 K.B.

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set 4½ CIBP @ 2428' cap with 35 sx cement
- 2) Load hole with mud
- 3) Spot 200' cement plug @ 850' - 650'
- 4) Pump 70 sx cement down 4½ csg and into formation @ 650' displace to 192' Pump 70 sx cement between 4½ & 8-5/8 left cement @ surface between casings
- 5) Spot cement from 122' to surface inside 4½ csg set PA marker
- 6) Job completed 7-29-96

Post ID-2
10-4-96
P4 17

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Elrica K Kleck TITLE District Secretary DATE 8-5-96

TYPE OR PRINT NAME Elrica K Kleck

TELEPHONE NO. 915-683-5321

(This space for State Use)

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

CONDITIONS OF APPROVAL, IF ANY: