

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.

30-005-60717

5. Indicate Type of Lease

STATE ☐

FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

Twin Lakes San Andres Unit

8. Well No.

44

9. Pool name or Wildcat

Twin Lakes San Andres (Assoc.)

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

Managan Petroleum Corporation

3. Address of Operator

P.O. Box 1737 - Roswell, NM 88202

4. Well Location

Unit Letter P : 330 Feet From The South Line and 990 Feet From The East Line

Section 35 Township 8S Range 28E NMPM Chaves County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug & Abandon as follows:

Notify NMOCD-Artesia, 24 hours prior to commencement of procedure

- 1) Set CIBP @ approx. 2550' & cap w/35' of cement (Top perf @ 2568').
- 2) Fill hole w/mud and set 100' plug across T/San Andres from 1960' to 1860'.
- 3) Fill hole w/mud and set 160' plug from 160' to surface (surface casing shoe @ 126').
- 4) Set Dry Hole marker & clean location.

(2) Perforate 4 1/2" cs; 21500' Spot Bal CMT. Plug 100' inside & 100' outside 4 1/2" cs; TA

(3) Perforate 4 1/2" cs; 2160'. Circulate cement to surface inside & outside 4 1/2" cs.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

President

DATE 5/13/98

TYPE OR PRINT NAME

Michael G. Hanagan

TELEPHONE NO. 505/623-5053

(This space for State Use)

APPROVED BY

TITLE

Field Rep II

DATE

May 22 98

CONDITIONS OF APPROVAL, IF ANY: