

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIP  
(Other instruction  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 12268

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Grynberg-Elkins

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

Wildcat

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec 17-T7S-R29E

12. COUNTY OR PARISH

Chaves

13. STATE

NM

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Fred Pool Operating Company /

3. ADDRESS OF OPERATOR

1300 Clovis Star Route, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

Section 17 1650 FWL, 2310 FSL

14. PERMIT NO.

279

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4027.00 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☒CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*

We intend to plug and abandon the subject well as follows:

- {1} Set CIBP @ 2600' (52 feet above top perf.)
- {2} Place 35 linear feet of cement on top of plug.
- {3} Shoot casing off at top of cement, approx. 1700'; (calculated.)
- {4} Place 35 sx cement plug from 1750' to 1650', across stub.
- {5} Place 35 sx cement plug from 950' to 850', across Yates formation.
- {6} Place 35 sx cement plug from 258' to 158', across base of surface casing.
- {7} Place 10 sx cement plug at surface & install regulation dry hole marker.
- {8} Clean & rehab. location.

NOTE: All plugs are Class "C" neat. Plugs will be placed via casing.

18. I hereby certify that the foregoing is true and correct

SIGNED

*Fred L. Pool*

TITLE

Petroleum Engineer

DATE

April 9, 1982

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED AS ATTENDED

DATE

\*See Instructions on Reverse Side

APR 14 1982

JAMES A. GILHAM  
DISTRICT SUPERVISOR