

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	5. LEASE DESIGNATION AND SERIAL NO. NM 14294
2. NAME OF OPERATOR McClellan Oil Corporation ✓	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR Post Office Drawer 730, Roswell, New Mexico 88201	7. UNIT AGREEMENT NAME RECEIVED
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FSL & 660' FWL	8. FARM OR LEASE NAME DEC 23 1980 "MP" Federal
14. PERMIT NO.	9. WELL NO. 1
15. ELEVATIONS (Show whether DF, M, L, or S.) 3744.6 G. L.	10. FIELD AND POOL, OR WILDCAT Wildcat Also
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 5-T9S-R26E
	12. COUNTY OR PARISH Chaves
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Will plug and abandon well following proposed procedure:

- Shoot off tubing from Baker Model R packer set at 4405'; pull tubing and leave packer in hole (Packer could not be retrieved conventionally).
- Pull 4½" casing from 3800' or cement top to surface.
- Set 100' plug from 4405' to 4305'.
- Set 100' plug from 3750' to 3850' inside and out of 4½" casing.
- Set 100' plug from 1950' to 2050' across Glorieta.
- Set 100' plug from 850' to 950' inside and out of the 8-5/8" casing and tag plug.
- Spot 10 sack plug at surface and install dry hole marker.
Note: salt gel mud will be placed between all plugs.
- Clean location of debris and fill and level all working pits and restore to as near as possible to original condition.

18. I hereby certify that the foregoing is true and correct

SIGNED

Paul Reynolds

TITLE

Engineer

DATE

12/18/80

(This space for Federal or State office use)

(Orig. Sd.) GEORGE H. STEWART

ACTING DISTRICT ENGINEER

TITLE

DATE

DEC 22 1980

CONDITIONS OF APPROVAL, IF ANY: