

WATER CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

AUG 5 1982

O. C. D.

ARTESIA, OFFICE

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Ralph Nix	8. Farm or Lease Name Skip
Address of Operator P. O. Box 617 Artesia, New Mexico 88210	9. Well No. 1
4. Location of Well UNIT LETTER <u>P</u> <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>660</u> FEET FROM THE <u>South</u> LINE, SECTION <u>26</u> TOWNSHIP <u>7S</u> RANGE <u>28E</u> N.M.P.M.	10. Field and Pool, or Wildcat Wildcat
11. Elevation (Show whether DF, RT, GR, etc.) 4079' GL	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <u>Plug Back</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug back to bottom of 8 5/8" casing 2820" & attempt an San Andres P-1 completion as follows:  
Set 5 1/2" cast iron bridge plug in 5 1/2" casing @ 6835' with a 35' cement plug on top (4sx).  
Run free point w/5 1/2" casing & cut casing @ this point & pull (estimate free point @ 3000').  
Set 100' cement plug from 5950' to 5850'.  
Set 100' plug from 5280' to 5180'.  
Set 100' plug from 4530' to 4430'.  
Set 100' plug in stub of 5 1/2" casing @ approx 3050' to 2950' & bump plug.  
Set 175' cement plug from 2875' to 2700' & bump plug.  
Perforate San Andres P1 from 2495' to 2521' & acidize 3000 gals 20% NEFE.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ralph Nix, Jr. TITLE Ralph Nix, Jr. DATE 8/4/82

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT 11 DATE AUG 6 1982

CONDITIONS OF APPROVAL, IF ANY: