

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.O.S.	
LAND OFFICE	
OPERATOR	1

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
L-5347

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT DEPTH. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	Campbell Station Unit
Carl A. Schellinger	8. Farm or Lease Name
3. Address of Operator	Campbell Station Unit
P. O. Box 447 Roswell, New Mexico 88201	9. Well No.
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER M, 660' FEET FROM THE South LINE AND 660' FEET FROM THE West LINE, SECTION 34 TOWNSHIP 8-5 RANGE 27-E N.M.P.M.	Wildcat
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3871' G.R. 3882' K.B.	Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input checked="" type="checkbox"/>	OTHER Run 8-5/8" Intermediate <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5-19-81: Drilled 12-1/4" hole to 2175', Schlumberger ran SNP, DLL-MSFL from 2177' to surface. Loggers TD-2177'.

5-20-81: Ran: Howco Guide Shoe, Float Collar on 52 joints 8-5/8" O.D. 24#/Ft., J-55, R-3, ST&C casing (2160.50') Set pipe @ 2175.00' K.B.

CEMENT: Cement out shoe with 700 sacks Class "C" with 2% CACL<sub>2</sub>, 1/4#/sack Flocele, Followed by 300 sacks Class "C" with 2% CACL<sub>2</sub>. Bumped plug at 10:30 PM with 1200 psig, float held. Did not circulate.

Ran Temperature Survey - T.O.C. 810'.

5-21-81: CEMENT: Cement thru 1" at 800' with 230 sacks Class "C" with 2% CACL<sub>2</sub>. Followed by 250 sacks Neat. Circulated 10 sacks to reserve. W.O.C. 16 hours.

5-22-81: Pressure test 8-5/8" casing to 1000 psig. O.K. Drill out with 7-7/8" bit.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ronald J. Murphy TITLE Consultant DATE 6/19/81

APPROVED BY W. A. Gussitt TITLE SUPERVISOR, DISTRICT II DATE JUL 16 1981

CONDITIONS OF APPROVAL, IF ANY: