

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

OCT 17 '88

O. C. D.

ARTESIA, OFFICE

Form C-103
Revised 10-1-78

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Pelto Oil Company	8. Farm or Lease Name O'Brien "N"
3. Address of Operator 500 Dallas, One Allen Center, Suite 1800, Houston, TX 77002	9. Well No. 2
4. Location of Well UNIT LETTER <u>M</u> <u>560</u> FEET FROM THE <u>South</u> LINE AND <u>480</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>8S</u> RANGE <u>29E</u> NMPM.	10. Field and Pool, or Wildcat Twin Lakes-San Andres Assoc.
15. Elevation (Show whether DF, RT, GR, etc.) 3974.75' GR	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug and Abandon well as follows:

1. Notify NMOCD of time plug and abandonment operations to start.
2. RUPU. Pick up & run 2-3/8" tbg (open-ended) to TD @ ±765'.
3. Mix gel mud & load 8-5/8" csg.
4. Mix & spot 100' Class "C" cmt plug from TD up to ±665'. Pull tbg to 136' & spot Class "C" cmt from 136' to surface. Pull 2-3/8" tbg.
5. RDPU. Cut off 8-5/8" csg below ground level & install dry hole marker as required by NMOCD Rule 202-A. Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Linda Crossley TITLE Production Clerk DATE 10/11/88

APPROVED BY Mike Williams TITLE SUPERVISOR, DISTRICT II DATE OCT 20 1988

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.D. in sufficient time to witness

Plugging