

DISTRICT I

P.O. Box 1980, Hobbs NM 88240

DISTRICT II

P.O. Drawer DD, Artesia NM 88210

DISTRICT III


1000 Rio Brazos Rd., Aztec NM 87410

State of New Mexico
Energy, Minerals and Natural Resources Department

OIL CONSERVATION DIVISION

P.O. Box 2088

Santa Fe, New Mexico 87504-2088



CISF
DP

WELL API NO. 30-005-60950

5. Indicate Type of Lease
State ☒ FEE ☐

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK A
DIFFERENT RESERVOIR. USE " APPLICATION FOR PERMIT
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name
BOSWELL STATE

8. Well No. 1

9. Pool Name or Wildcat
PECOS SLOPE ABO, WEST

1. Type of Well:
OIL GAS
WELL ☒ WELL ☐ OTHER

2. Name of Operator
Yates Petroleum Corporation

3. Address of Operator
105 South 4th., Artesia, NM 88210

4. Well Location
Unit Letter J : 1650 Feet From The SOUTH Line and 1650 Feet From The EAST Line
Section 30 Township 5S Range 21E NMPM CHAVES COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

YATES PETROLEUM CORPORATION RESPECTFULLY REQUESTS PERMISSION TO PLUG & ABANDON AS FOLLOW

1. Notify MNOCD 24 hours before starting operations. MIRU WSU & safety equipment as needed. Load tubing & casing w/ 2% KCL water, ND wellhead, & NU BOP; POH w/ tubing.
2. RU wireline, RIH w/ 4-1/2" gauge ring to 2450' to make sure casing is clear, then RIH w/ 4-1/2" CIBP & set plug at 2450'. MU dump bailer & RIH w/ bailer & dump 35' cement on top of CIBP. RD wireline.
3. RIH w/ tubing to 2315' & circ hole w/ 10.0 ppg brine plugging mud w/ 25# gel/bbl in mud; POH w/ tubing.
4. Pull tubing to 1050' & spot 25 sack cement plug to cover base of 8-5/8" casing. Wait 3 hrs & tag plug @ 850+/- before moving up to set next plug. Pull tubing up to 60' +/- & set a 10 sack plug @ surface.
5. ND BOP & remove wellhead. Install regulation marker & clean location.


* 25 sx plug @ 2402'
** 100' plug 307-407 - Tag

I hereby certify that the information above is a true and complete to the best of my knowledge and belief.

SIGNATURE Donna Clack TITLE Operations Technician DATE 4/3/02
TYPE OR PRINT NAME DONNA CLACK TELEPHONE NO. 505-748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE APR 5 2002
CONDITIONS OF APPROVAL, IF ANY:



4

44

SECRET *
CONFIDENTIAL *