

Submit 3 Copies To Appropriate
District Office
DISTRICT I
1625 N. French Dr., Hobbs, NM 88240
DISTRICT II
1301 Grand Ave., Artesia NM 88210
DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 S. Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO. 30-005-61891

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
L-978

7. Lease Name or Unit Agreement Name:
ACME

8. Well No. 1

9. Pool name or Wildcat ACME

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3931' GR

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

JULIAN ARD PETROLEUM

3. Address of Operator

222 W. 4 th St., Ft. Worth, Texas 76102

4. Well Location

Unit letter C : 660 feet from the EAST line and 1980 feet from the SOUTH line

Section

4

Township

8S

Range

27E

NMPM

Chaves County

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

PLUGGING PROCEDURE

1. CUT TUBING OFF AT THE TOP OF THE PACKER, +/- 6180', P.O.H. WITH TUBING.
2. R.I.H. AND SET CIBP AT 6175' AND CAP WITH 35' OF CEMENT.
3. T.I.H. WITH TUBING AND CIRCULATE HOLE WITH 9 PPG MUD.
4. PUMP DOWN CASING AND ESTABLISH CIRCULATION AROUND THE ANNULUS.
5. PUMP 800 SX. 50/50 POZMIX "C" CEMENT AND LEAVE CASING AND ANNULUS FULL OF CEMENT.
6. CUT OFF WELLHEAD, ANCHORS AND CLEAN LOCATION. REMOVE ALL EQUIPMENT.
7. INSTALL DRY HOLE MARKER WITH WELL AND LOCATION INFORMATION.
8. RIP LOCATION AND ROAD AND RESEED.

25' plug @ 5450'
25' plug @ 4808'
100' plug 3940-4040
Perf cs @ 2300' - Squeeze 100' of cmt
Outside & inside cs 2200-2300
Perf cs @ 863' - Squeeze 100' of cmt
inside & outside cs 763-863' Tag
Perf cs @ 60' - cmt to surface - RESEED CS?
Annulus - ARTESIA

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE B. Stubbs TITLE ENGINEER DATE 12-20-01

Type or print name BRUCE A. STUBBS

(This space for State use)

APPROVED BY [Signature] TITLE Field Rep DATE JAN 23 2002

Conditions of approval, if any: