

Submit 3 Copies To Appropriate District
Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

811 South First, Artesia, NM 87210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION

1220 South St. Francis Dr. 1920212
Santa Fe, NM 87505

Form C-103

Revised March 25, 1999

WELL API NO
30-005-61935

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
STA-NM-LG-564

7. Lease Name or Unit Agreement Name:
Horse Creek State Com

8. Well No.
2

9. Pool name or Wildcat
Abo

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
3990 GR

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Jack J. Grynberg

3. Address of Operator

5299 DTC Blvd. Suite 500, Greenwood Village, CO 80111

4. Well Location

Unit Letter C : 660 feet from the North line and 1980 feet from the West line

Section 4

Township 55

Range 24E

NMPM

County Chaves

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
3990 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Well will be plugged as follows:

1. See CIBP at 3400' and cap w/ 35' cement
2. Circ hole with salt gel mixed w/25#/bbl brine water
3. Equalize 100' cement plug inside 4 1/2" casing from 1360' to 1260'
4. Perforate 4 1/2" casing at 950: Equalize 75 sk blue inside and outside 4 1/2" casing. Tag plug ← 100' plug inside! outside as 372-472'
5. Cut off casing strings 2' below ground level
6. Lay 15 sk cement plug inside 4 1/2" casing at surface
7. Install dry hole marker 4' above ground level
8. Cut off anchors and flow line 1' below ground level
9. Clean and level location

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Engineer DATE 3/7/2002

Type or print name

(This space for State use)

Telephone No.

APPROVED BY [Signature] TITLE Field Rep DATE MAR 22 2002

Conditions of approval, if any:

