

DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

LEASE DESIGNATION AND SERIAL NO.

2157

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER ☒ DRY HOLE

2. NAME OF OPERATOR
McClellan Oil Corporation

3. ADDRESS OF OPERATOR
P.O. Drawer 730, Roswell, NM 88202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface
1980 FSL & 660 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3686' G.L.

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
PJ Federal

9. WELL NO.
4

10. FIELD AND POOL, OR WILDCAT
South Pecos Slope A60

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 7-T9S-R26E

12. COUNTY OR PARISH
Chaves

13. STATE
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	SHOOTING OR ACIDIZING	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	(Other)	<input type="checkbox"/>
(Other)	<input type="checkbox"/>		
PULL OR ALTER CASING	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>	ABANDONMENT*	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>		

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Plugged and abandoned on 4-20-89 by

1. Loaded hole with heavy mud
2. Set plug #1 at 4390 ft with 35 sx Class C with 3% CaCl₂. Tagged plug at 3910' after 2 hrs.
3. Set plug #2 at 1000 ft with 50 sx Class C with 3% CaCl₂. Tagged plug at 590 ft after 2 hrs.
4. Set Plug #3 at surface with 15 sx of Class C neat. Lay down all tubing. Install dry hole marker.

NOTE: No plugs were set behind the casing because the casing was one inch from 1500 ft to surface on 12/10/84 with 250 sx Class C. Circulated 20 sx cement.

Post FD-2
6-9-89
PFA

18. I hereby certify that the foregoing is true and correct

SIGNED Paul Ragidale TITLE Operations Manager DATE 4/27/89

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

Approved as to plugging of the well bore.
Liability under bond is retained until
surface restoration is completed.

*See Instructions on Reverse Side

APPROVED
PETER W. CHESTER
JUN 1 1989
BUREAU OF LAND MANAGEMENT
ROSWELL RESOURCE AREA