

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-005-62595

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

LG-9805

7. Lease Name or Unit Agreement Name

Enron AEY State

8. Well No.

1

9. Pool name or Wildcat

Foor Ranch Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL  
WELL ☐

GAS  
WELL ☒

OTHER ☐

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South 4th St., Artesia, NM 88210

4. Well Location

Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line

Section 25

Township 9S

Range 26E

NMPM

Chaves

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3810.6' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: Abandon Ordovician & add new perms to ☒  
existing Wolfcamp perms & produce

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to abandon perforations 5931-5946' (Ordovician) and add new perforations in Wolfcamp to existing Wolfcamp perforations and acidize, then place into production as follows:

1. Nipple down wellhead & nipple up BOP. TOOH with tubing and packer. TIH with retrieving head and latch onto RBP at 5952'. TOOH with RBP and tubing.
2. Set CIBP at 5900' and cap with 35' of cement.
3. Perforate 5538-5546' (Wolfcamp), acidize as necessary for production.
4. Swab/flow test.
5. Acidize existing perforations 5302-5307' (Wolfcamp) as necessary for production.
6. Swab/flow test.
7. Place perforations 5302-5307' & 5538-5546' (Wolfcamp) together and place well into production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Operations Technician

DATE March 15, 2001

TYPE OR PRINT NAME

Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY

TITLE

Field Rep. II

DATE 3/28/2001

CONDITIONS OF APPROVAL, IF ANY: