

Form 3160-5
(November 1983)
(Formerly 9-331)

UNITED STATES ^{ARTESIA, SUBMITTER'S DUPLICATE*}
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-069817

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. OIL WELL ☐ GAS WELL ☒ OTHER Plug & Abandon JUL 10 1991

2. NAME OF OPERATOR

McClellan Oil Corporation

O. C. D.

3. ADDRESS OF OPERATOR

ARTESIA, OFFICE

P.O. Drawer 730 Roswell, NM 88202-0730

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface

1980' FSL & 1650' FEL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Patrick Fed

9. WELL NO.

#2

10. FIELD AND POOL, OR WILDCAT

Double L Queen Assoc.

11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA

Sec 12-T15S-R29E

12. COUNTY OR PARISH

Chaves

13. STATE

NM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3916 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Csg - 4½ 11.5# 2100'


8 5/8 csg to 335' (Circulated)

Perfs - 1956' to 1970'

2 3/8 tbg

1. Set CIBP at 1900' & put 35' cmt on top.
2. Circulate hole w/heavy gel H₂O.
3. Set cmt plug from 950' to 850' 25 sx
4. Set cmt plug from 350' to surface (Circulate cmt.)
5. Run 1" tbg to 380' between 4½ & 8 5/8 35 sx plug

Install dry hole marker and prep to finalize.



18. I hereby certify that the foregoing is true and correct

SIGNED

Walter Lee

TITLE Drlg. & Comp. Engineer

DATE

6-28-91

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

DATE

APPROVED
WALTER LEE
JUL 8 1991

*See Instructions on Reverse Side