

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

811 South First, Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87504

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87504

Form C-103
Revised March 25, 1999

WELL API NO.

30-005-60415

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

K6844

7. Lease Name or Unit Agreement Name:

Lula

8. Well No.

2

9. Pool name or Wildcat

Buffalo Valley Penn

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Matador Operating Company

3. Address of Operator

310 W. Wall, Suite 906 Midland, Tx 79701

4. Well Location

Unit Letter D : 990 feet from the North line and 990 feet from the West line

Section 7 Township 15S Range 28E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3691 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Plug and abandon well as follows:

CIBP @ 8940 with 10' of cement from 8400-8410. Spot 35' cement on CIBP.

Cut and retrieve 4 1/2" csg @ 7000' (or 500' above calculated free point)

Spot 25 sx plug from 7050 to 6950 (stub plug) TAG

Spot 25 sx plug from 1590 to 1690 (shoe plug) TAG

Perf 8 5/8" csg @ 430'. Spot 25 sx plug inside and outside 8 5/8" csg from 430 to 330 (shoe plug)

Spot 10 sx surface plug. Weld on plate and dry hole marker.

Fill cellar and remove deadmen.

Hole will be filled with 10 ppg mud between plugs.

* Spot 25 sx cement Plug 6350'-6250'.

* Spot 25 sx cement Plug 5236'-5136'. * Brine Gel between all cement plugs.

* Spot 25 sx cement Plug 2720'-2620'. Notice N.M.O.C.D. to witness plugging operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Russ Mathis TITLE Production Manager DATE 05/02/01

Type or print name Russ Mathis

Telephone No. 915-687-5955

(This space for State use)

APPROVED BY Mike Stullfield TITLE Envir. Eng. Spec. I DATE 5/14/2001

Conditions of approval, if any:



30-005-60415

D-7-15s-28e

Matador Oper. Co.

Lula #2

Tops

* Spot 10 sx cement Surface Plug.

T. S.A. - 1642'

* Perf. 8 5/8" csg to 430'. Squeeze 100' cement Plug

T. Gloria - 2670'

Inside + Outside 8 5/8" csg. TAG

T. Aho. - 5186'

* Spot 25 sx cement Plug 1690' - 1590'. TAG

T. W. C. - 6300'

T. AtoKa - 8323'

* Spot 25 sx cement Plug 2720' - 2620'.

* Spot 25 sx cement Plug 5236' - 5136'.

* Spot 25 sx cement Plug 6350' - 6250'.

* Spot 25 sx cement Plug 50' in + 50' out 4 1/2" csg stub. TAG

* Cut + Pull 4 1/2" csg to 7000'.

* Circulate brine gel.

What is CSE
Depth

* Run + set CSBP to 8940'.

Perf. - 8494' - 8546'

4 1/2" csg

8762'

w/390sx

TOC -

13 3/8" csg
380'
w/525sx
cement.

8 5/8" csg
1643'

TOC - 630'

Keep surface
circ.