

Submit 3 copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

157
12

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240
DISTRICT II
P.O. Drawer DD, Artesia, NM 88210
DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504 -2088

WELL API NO. 30-015- 0173 01373
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-8617
7. Lease Name or Unit Agreement Name Spurck F State
8. Well No. 3
9. Pool name or Wildcat Red Lake QN, GRB

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL Well <input checked="" type="checkbox"/> GAS Well <input type="checkbox"/> OTHER	2. Name of Operator Yates Drilling Company	3. Address of Operator 105 South 4 th Street, Artesia, NM 88210
4. Well Location Unit Letter <u>E</u> : <u>2310</u> Feet From The <u>North</u> Line <u>990</u> Feet From The <u>West</u> Line Section 15 Township 17S Range 28E NMPM Eddy County		

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
See attachment



* Brine Gel between all Plugs.
Notific N.M.O.C.D. to witness Plugging operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Karen J. Leishman TITLE Engineering Technician DATE 6-14-01
TYPE OR PRINT NAME Karen J. Leishman TELEPHONE NO. 505-746-0308

(This space for State Use)

APPROVED BY Micael Stueffert TITLE Envir. Eng. Spec. I DATE 7/11/2001
CONDITIONS OF APPROVAL, IF ANY:

SPURCK F STATE #3
2310' FNL & 990' FWL
Section 15-17S-28E
Eddy County, NM
30-015-01373

Proposed Plug and Abandonment Procedure

- 1) Clear and level location.
- 2) Check anchors and replace, as necessary.
- 3) Rig up workover unit.
- 4) Pull rods, pump and tubing out of hole.
- 5) Inspect tubing.
- 6) Pick up rental tubing, if necessary.
- 7) RIH w/ CIBP and set at +/- 1862' (50' above lower perforation 1912' - 1926')
- 8) Circulate hole w/ 10ppg mud.
- 9) Spot 100' cement plug on top of CIBP (1762' - 1862').
- 10) Set CIBP at +/- 1384' (50' above upper perforation 1434' - 1444').
- 11) Spot cement plug on top of CIBP 1184' - 1384'.
- 12) POH with tubing.
- 13) Cut and pull 5 1/2" casing at 580'. *472'*
- 14) RIH w/ tubing and spot cement plug from ~~530'~~ *472'* - 630'. *Min. cement Plug 25 ex.*
- 15) POH w/ tubing.
- 16) WOC.
- 17) RIH and tag cement.
- 18) Spot additional cement as necessary.
- 19) Spot cement plug 0 - 100'.
- 20) Erect regulation dry hole marker.
- 21) Remove all equipment from location.