

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well ☐ gas ☐ well ☐ other Injection
2. NAME OF OPERATOR
Kersey & Company
3. ADDRESS OF OPERATOR
P.O. Box 316, Artesia, NM 88211-0316
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE:
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

- | REQUEST FOR APPROVAL TO: | | SUBSEQUENT REPORT OF: |
|--------------------------|-------------------------------------|--------------------------|
| TEST WATER SHUT-OFF | <input type="checkbox"/> | <input type="checkbox"/> |
| FRACTURE TREAT | <input type="checkbox"/> | <input type="checkbox"/> |
| SHOOT OR ACIDIZE | <input type="checkbox"/> | <input type="checkbox"/> |
| REPAIR WELL | <input type="checkbox"/> | <input type="checkbox"/> |
| PULL OR ALTER CASING | <input type="checkbox"/> | <input type="checkbox"/> |
| MULTIPLE COMPLETE | <input type="checkbox"/> | <input type="checkbox"/> |
| CHANGE ZONES | <input type="checkbox"/> | <input type="checkbox"/> |
| ABANDON* | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| (other) | | |

5. LEASE
Delhi-Reid #1 → LC-048477(A)
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
RLPSU Flood
8. FARM OR LEASE NAME
RLPSU - Tract 2
9. WELL NO.
1
10. FIELD OR WILDCAT NAME
Red Lake-Q-G-SA
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Unif F
2310 N, 2310 W, Sec. 20-17S-28E
12. COUNTY OR PARISH
Eddy
13. STATE
NM
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
3622.2

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Dump at least 200' cement 1971-1802'(TAG PLUG)
2. Estimated TOC 800 - Perforate at 750', set cement retainer at 725' and attempt to squeeze annulus to bring cement back to surface casing - but preferably surface.
3. Sting out retainer & leave 55' cement on retainer.
4. Spot 100' cement, 50' above and 50' below 8 5/8" casing shoe(TAG)
5. Leave 50' surface plug- erect marker.
6. Restore surface

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Harold Kersey TITLE Co-Owner DATE 9-24-87

(This space for Federal or State office use)

APPROVED BY Paul L. Mannes TITLE _____ DATE 10-7-87

CONDITIONS OF APPROVAL, IF ANY:

6-3671

Les 50

RECEIVED

SEP 25 11 05 AM '87

PRR OK - BLM
Carlsbad
10-19-87