

7. TIH w/ retrievable packer on 2-7/8" workstring to 6055'. Spot 100 gals 15% NEFE HCl acid across Abo perms 6030'-55'. PUH, reverse 5 bbls and set packer @ 5930'. Pressure annulus to 500 psi.
8. Acidize Abo 6030'-55' w/ 4000 gals NEFE HCL acid @ 1-2 BPM dropping 90- 1.3 SG ball sealers in sets of 3, evenly spaced throughout. Maximum pressure: 1500 psi. Flush to bottom perf w/ formation water. SI for 30 min.
9. Flow/swab back load and evaluate w/ Engineering.
10. Release packer. TOH, laying down 2-7/8" workstring. Test in hole w/ CA to 4000# below slips as per production department specifications. ND BOP. NU WH. RD PU. Clean location. Release rig. TOFS.

*Note: May want to do acid job through hole-set pkr
Set pkr. above squeeze holes.*

L. M. Thompson
L. M. Thompson

Approval:

RDR 6-20-90

R. D. Reynolds

JES

J. E. Shields